# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | GM-Basic module | | | √ | √ | √ | √ | – | √ |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | MR- engine control | | | √ | √ | √ | √ | – | – |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | INS-Dashboard | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | BS-Brake control | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ZHE-Assit heater | | | √ | √ | √ | √ | – | √ |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | FM-Front module | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | MSF-Switch panel | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | MTCO-Conversion Tab | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | GS-Gear Shift control | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | FR-Drive control | | | √ | √ | √ | √ | – | √ |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | HM-Rear module | | | √ | √ | √ | √ | – | √ |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | TMF-Driver Door Module | | | √ | √ | √ | – | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ABA-Active Brake Assist | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | DTCO-digital tachograph | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | EHZ electro-hydraulic auxiliary steering | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | BNT navigation or telephone operating unit | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | BTS battery disconnect switch | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | HPS hydraulic pneumatic shift | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | PSM Parameterizable Special Module | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | RDK tire pressure control | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | SPA Lane Assistant | | | √ | √ | √ | √ | √ | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | Steering wheel angle sensor | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | WS Maintenance System | | | √ | √ | √ | √ | – | √ |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | WSK torque converter clutch or TK turbo clutch | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ZDS Central data memory | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | FLA flame starting system | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | GM-Basic module | | | √ | √ | √ | √ | – | √ |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | MR- engine control | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | INS-Dashboard | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | BS-Brake control | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | ZHE-Assit heater | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | FM-Front module | | | √ | √ | √ | √ | – | √ |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | MSF-Switch panel | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | MTCO-Conversion Tab | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | GS-Gear Shift control | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | FR-Drive control | | | √ | √ | √ | √ | – | √ |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | HM-Rear module | | | √ | √ | √ | √ | – | √ |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | TMF-Driver Door Module | | | √ | √ | √ | – | – | - |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | ABA-Active Brake Assist | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | DTCO-digital tachograph | | | √ | √ | √ | √ | – | - |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | EHZ electro-hydraulic auxiliary steering | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | BNT navigation or telephone operating unit | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | BTS battery disconnect switch | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | HPS hydraulic pneumatic shift | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | PSM Parameterizable Special Module | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | RDK tire pressure control | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | SPA Lane Assistant | | | √ | √ | √ | √ | √ | - |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | Steering wheel angle sensor | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | WS Maintenance System | | | √ | √ | √ | √ | – | √ |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | WSK torque converter clutch or TK turbo clutch | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | ZDS Central data memory | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB950.0 - 954.0(14 pin socket) | FLA flame starting system | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB930.004(16-pin socket) | BS-Brake Control | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB930.004(16-pin socket) | FM-Front module | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB930.004(16-pin socket) | FR-Drive control | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB930.004(16-pin socket) | GM-Basic Modules | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB930.004(16-pin socket) | GS II gear control | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB930.004(16-pin socket) | HM-Rear Module | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB930.004(16-pin socket) | MR-Engine Control | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB930.004(16-pin socket) | INS-Dashboard | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB930.004(16-pin socket) | MSF-Switch Panel | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB930.004(16-pin socket) | TCO tachograph | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB930.004(16-pin socket) | PSM Parameterizable Special Module | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB930.004(16-pin socket) | TMB-PASSENGER door module | | √ | √ | √ | – | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB930.004(16-pin socket) | TMF-Driver door module | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB930.004(16-pin socket) | WS Maintenance System | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB930.004(16-pin socket) | ZDS Central data memory | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | ABA Active Brake Assist | | √ | √ | √ | √ | – | – |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | ART-Autonomous intelligent cruise control | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | DTCO-digital tachometer | | √ | √ | √ | √ | – | – |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | FLA -Flame starting system | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | FR - drive control | | √ | √ | √ | √ | √ | √ |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | GM-Basic Modules | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | HPS - Hydraulic pneumatic shift | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | Steering wheel angle sensor | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | MR - Engine control | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | MSF - Modular switch panel | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | PSM - Parameterizable Special Module | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | RDK - tire pressure control | | √ | √ | √ | – | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | ZDS Central data memory | | √ | √ | √ | √ | – | - |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | BS - Brake control | | √ | √ | √ | √ | √ | √ |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | FM-Front module | | √ | √ | √ | √ | – | – |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | GS II gear control | | √ | √ | √ | √ | – | – |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | HM - Rear module | | √ | √ | √ | √ | – | – |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | MTCO Modular tachograph | | √ | √ | √ | √ | – | – |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | SPA Lane Assistant | | √ | √ | √ | √ | √ | – |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | BNT - navigation or telephone operating unit | | √ | √ | √ | √ | – | – |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | WSK torque converter clutch or TK turbo clutch | | √ | √ | √ | √ | – | – |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | TMB-PASSENGER door module | | √ | √ | √ | √ | – | – |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | TMF-Driver door module | | √ | √ | √ | √ | – | – |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | WS Maintenance System | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | ZHE-Auxiliary heater | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS | ACTROS WDB930.0 - 934.0(16 pin socket) | ACTROS WDB934.233(16-pin socket) | INS-Instrument | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | ABA Active brake assist | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | BS Brake control | | | √ | √ | √ | √ | √ | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | BTS battery disconnect switch | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | DTCO Digital tachograph | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | EDW Anti-theft alarm | | | √ | √ | √ | √ | √ | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | EHZ electro-hydraulic auxiliary steering | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | FLA Flame starting system | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | FM Front module | | | √ | √ | √ | √ | √ | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | FR Drive control | | | √ | √ | √ | √ | √ | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | GM Basic Modules | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | GS II gear control | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | HM Rear Module | | | √ | √ | √ | √ | √ | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | HPS Hydraulic pneumatic shift | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | HZR Heating control | | | √ | √ | √ | √ | √ | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | INS Instrument | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | KOM Communication interface | | | √ | √ | √ | – | – | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | Steering wheel angle sensor | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | MR Engine control | | | √ | √ | √ | √ | √ | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | MSF Switch Panel | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | MTCO Modular tachograph | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | PSM Parameterizable Special Module | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | RDK Tire pressure control | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | RS Retarder contro | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | SRS | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | BNT Navigation/telephone operating unit | | | √ | √ | √ | √ | √ | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | WSK torque converter clutch or TK turbo clutch | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | TMB PASSENGER door module | | | √ | √ | √ | √ | √ | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | TMF Driver door module | | | √ | √ | √ | √ | √ | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | WS Maintenance System | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | ZDS Central data memory | | | √ | √ | √ | √ | – | - |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | ACTROS 2,3 | ACTROS WDB930.0 - 934.0(16 pin socket) | ZHE-Auxiliary heater | | | √ | √ | √ | √ | √ | - |
| benz diesel | ACTROS MP II | ACTROS MP II WDB930.0 - 934.0(16 pin socket) | VDO FR-Drive control vehicle- engineECU | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS MP II | ACTROS MP II WDB930.0 - 934.0(16 pin socket) | FM-Front module | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS MP II | ACTROS MP II WDB930.0 - 934.0(16 pin socket) | HM-Rear module | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS MP II | ACTROS MP II WDB950.0 - 954.0(14 pin socket) | VDO FR-Drive control vehicle- engineECU | | | √ | √ | √ | – | – | - |
| benz diesel | ACTROS MP II | ACTROS MP II WDB950.0 - 954.0(14 pin socket) | FM-Front module | | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS MP II | ACTROS MP II WDB950.0 - 954.0(14 pin socket) | HM-Rear module | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego II | ATEGO WDB970-976,NAB374.4 | ABS anti-lock braking system | | | √ | √ | √ | √ | √ | - |
| benz diesel | Atego II | ATEGO WDB970-976,NAB374.4 | DTCO Digital tachograph | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego II | ATEGO WDB970-976,NAB374.4 | FFB Radio remote control | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego II | ATEGO WDB970-976,NAB374.4 | FR Drive control | | | √ | √ | √ | √ | √ | - |
| benz diesel | Atego II | ATEGO WDB970-976,NAB374.4 | HPS Hydraulic pneumatic shift | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego II | ATEGO WDB970-976,NAB374.4 | MR engine control | | | √ | √ | √ | √ | √ | - |
| benz diesel | Atego II | ATEGO WDB970-976,NAB374.4 | MTCO Modular tachograph | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego II | ATEGO WDB970-976,NAB374.4 | NR Level control | | | √ | √ | √ | √ | √ | - |
| benz diesel | Atego II | ATEGO WDB970-976,NAB374.4 | PSM Parameterizable Special Module | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego II | ATEGO WDB970-976,NAB374.4 | ZV Contral locking system | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego II | ATEGO NMB375.1 | ABS anti-lock braking system | | | √ | √ | √ | √ | √ | - |
| benz diesel | Atego II | ATEGO NMB375.1 | DTCO Digital tachograph | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego II | ATEGO NMB375.1 | FFB Radio remote control | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego II | ATEGO NMB375.1 | FR Drive control | | | √ | √ | √ | √ | √ | - |
| benz diesel | Atego II | ATEGO NMB375.1 | MR engine control | | | √ | √ | √ | √ | √ | - |
| benz diesel | Atego II | ATEGO NMB375.1 | MTCO Modular tachograph | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego II | ATEGO NMB375.1 | PSM Parameterizable Special Module | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego II | ATEGO NMB375.1 | ZV Contral locking system | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego II | ATEGO 9BM958.0 | ABS anti-lock braking system | | | √ | √ | √ | √ | √ | - |
| benz diesel | Atego II | ATEGO 9BM958.0 | FFB Radio remote control | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego II | ATEGO 9BM958.0 | FR Drive control | | | √ | √ | √ | √ | √ | - |
| benz diesel | Atego II | ATEGO 9BM958.0 | MR engine control | | | √ | √ | √ | √ | √ | - |
| benz diesel | Atego II | ATEGO 9BM958.0 | TCO Modular tachograph | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego II | ATEGO 9BM958.0 | PSM Parameterizable Special Module | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego II | ATEGO 9BM958.0 | ZV Contral locking system | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego | ATEGO WDB970 - 976, NAB374.4 | MR engine control | | | √ | √ | √ | √ | √ | - |
| benz diesel | Atego | ATEGO WDB970 - 976, NAB374.4 | PSM Parameterizable Special Module | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego | ATEGO WDB970 - 976, NAB374.4 | NR level control | | | √ | √ | √ | √ | √ | - |
| benz diesel | Atego | ATEGO WDB970 - 976, NAB374.4 | INS Instrument | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego | ATEGO WDB970 - 976, NAB374.4 | FR drive control | | | √ | √ | √ | √ | √ | - |
| benz diesel | Atego | ATEGO WDB970 - 976, NAB374.4 | ABS anti-lock braking system | | | √ | √ | √ | √ | √ | - |
| benz diesel | Atego | ATEGO WDB970 - 976, NAB374.4 | FFB radio remote control | | | √ | √ | √ | √ | √ | - |
| benz diesel | Atego | ATEGO WDB970 - 976, NAB374.4 | HPS hydraulic pneumatic shift | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego | ATEGO WDB970 - 976, NAB374.4 | ZV central locking system | | | √ | √ | √ | √ | – | - |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | Atego | ATEGO WDB970 - 976, NAB374.4 | ANG Automatic transmission commercial vehicle | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego | ATEGO WDB970 - 976, NAB374.4 | SRS supplemental restraint system | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego | ATEGO 970.273 | MR engine control | | | √ | √ | √ | √ | √ | - |
| benz diesel | Atego | ATEGO 970.273 | MTCO Modular tachograph | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego | ATEGO 970.273 | NR level control | | | √ | √ | √ | √ | √ | - |
| benz diesel | Atego | ATEGO 970.273 | INS Instrument | | | √ | √ | √ | √ | – | - |
| benz diesel | Atego | ATEGO 970.273 | FR drive control | | | √ | √ | √ | √ | √ | √ |
| benz diesel | Atego | ATEGO 970.273 | ABS anti-lock braking system | | | √ | √ | √ | √ | √ | √ |
| benz diesel | AXOR II | AXOR -R WDB950.5-95.6,NAB374.5 | MR engine control | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II | AXOR -R WDB950.5-95.6,NAB374.5 | FR drive control | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II | AXOR -R WDB950.5-95.6,NAB374.5 | ABS anti-lock braking system | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II | AXOR -R WDB950.5-95.6,NAB374.5 | INS Instrument | | | √ | √ | √ | – | – | √ |
| benz diesel | AXOR II | AXOR -R WDB950.5-95.6,NAB374.5 | FFB radio remote control | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II | AXOR -R WDB950.5-95.6,NAB374.5 | HPS hydraulic pneumatic shift | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II | AXOR -R WDB950.5-95.6,NAB374.5 | NR level control | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II | AXOR -R WDB950.5-95.6,NAB374.5 | WS Maintenance System | | | √ | √ | √ | √ | – | √ |
| benz diesel | AXOR II | AXOR -R WDB950.5-95.6,NAB374.5 | ZV central locking system | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R WDB950.5-954.6,NAB374.5 | MR Engine control | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R WDB950.5-954.6,NAB374.5 | FR Drive control | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R WDB950.5-954.6,NAB374.5 | ABS Anti-lock braking system | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R WDB950.5-954.6,NAB374.5 | FR Drive control | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R WDB950.5-954.6,NAB374.5 | ABS Anti-lock braking system | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R WDB950.5-954.6,NAB374.5 | DTCO Digital tachograph | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R WDB950.5-954.6,NAB374.5 | GS gear control | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R WDB950.5-954.6,NAB374.5 | HPS hydraulic pneumatic shift | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R WDB950.5-954.6,NAB374.5 | MTCO - Modular tachograph | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R WDB950.5-954.6,NAB374.5 | NR Level control | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R WDB950.5-954.6,NAB374.5 | PSM Parameterizable Special Module | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R WDB950.5-954.6,NAB374.5 | WS Maintenance System | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R WDB950.5-954.6,NAB374.5 | ZV Contral locking system | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R NMB375.3 | MR Engine control | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R NMB375.3 | FR Drive control | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R NMB375.3 | ABS Anti-lock braking system | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R NMB375.3 | DTCO Digital tachograph | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R NMB375.3 | FFB Radio remote control | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R NMB375.3 | GS gear control | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R NMB375.3 | HPS hydraulic pneumatic shift | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R NMB375.3 | MTCO - Modular tachograph | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R NMB375.3 | NR Level control | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R NMB375.3 | PSM Parameterizable Special Module | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R NMB375.3 | WS Maintenance System | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -R NMB375.3 | ZV Contral locking system | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -C WDB940-944,NAB374.6 | MR Engine control | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -C WDB940-944,NAB374.6 | FR Drive control | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -C WDB940-944,NAB374.6 | ABS Anti-lock braking system | | | √ | √ | √ | √ | – | - |
| benz diesel | AXOR II(374-958) | AXOR -C WDB940-944,NAB374.6 | DTCO Digital tachograph | | | √ | √ | √ | √ | – | - |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | AXOR II(374-958) | AXOR -C WDB940-944,NAB374.6 | FFB Radio remote control | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C WDB940-944,NAB374.6 | HPS hydraulic pneumatic shift | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C WDB940-944,NAB374.6 | MTCO Modular tachograph | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C WDB940-944,NAB374.6 | NR Level control | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C WDB940-944,NAB374.6 | PSM Parameterizable Special Module | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C WDB940-944,NAB374.6 | WS Maintenance System | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C WDB940-944,NAB374.6 | ZV Contral locking system | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C WDF940-944,NMB940-944 | MR Engine control | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C WDF940-944,NMB940-944 | FR Drive control | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C WDF940-944,NMB940-944 | ABS Anti-lock braking system | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C WDF940-944,NMB940-944 | DTCO Digital tachograph | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C WDF940-944,NMB940-944 | FFB Radio remote control | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C WDF940-944,NMB940-944 | HPS hydraulic pneumatic shift | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C WDF940-944,NMB940-944 | MTCO Modular tachograph | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C WDF940-944,NMB940-944 | NR Level control | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C WDF940-944,NMB940-944 | PSM Parameterizable Special Module | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C WDF940-944,NMB940-944 | WS Maintenance System | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -CI NMB375.4 | MR Engine control | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -CI NMB375.4 | FR Drive control | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -CI NMB375.4 | ABS Anti-lock braking system | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -CI NMB375.4 | DTCO Digital tachograph | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -CI NMB375.4 | FFB Radio remote control | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -CI NMB375.4 | NR Level control | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -CI NMB375.4 | PSM Parameterizable Special Module | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -CI NMB375.4 | WS Maintenance System | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -CI NMB375.4 | ZV Contral locking system | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C 9BM958.4 | MR Engine control | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C 9BM958.4 | FR Drive control | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C 9BM958.4 | ABS Anti-lock braking system | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C 9BM958.4 | FFB Radio remote control | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C 9BM958.4 | TCO Tachograph | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C 9BM958.4 | NR Level control | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C 9BM958.4 | PSM Parameterizable Special Module | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C 9BM958.4 | WS Maintenance System | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -C 9BM958.4 | ZV Contral locking system | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -R 9BM958.2 | MR Engine control | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -R 9BM958.2 | FR Drive control | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -R 9BM958.2 | ABS Anti-lock braking system | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -R 9BM958.2 | FFB Radio remote control | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -R 9BM958.2 | TCO Tachograph | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -R 9BM958.2 | NR Level control | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -R 9BM958.2 | PSM Parameterizable Special Module | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -R 9BM958.2 | WS Maintenance System | | | √ | √ | √ | √ | - | - |
| benz diesel | AXOR II(374-958) | AXOR -R 9BM958.2 | ZV Contral locking system | | | √ | √ | √ | √ | - | - |
| benz diesel | ECONIC | ECONIC 957.5 - 957.6 | MR engine control | | | √ | √ | √ | √ | - | - |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | ECONIC | ECONIC 957.5 - 957.6 | PSM Parameterizable Special Module | | | √ | √ | √ | √ | – | - |
| benz diesel | ECONIC | ECONIC 957.5 - 957.6 | NR level control | | | √ | √ | √ | √ | √ | - |
| benz diesel | ECONIC | ECONIC 957.5 - 957.6 | INS Instrument | | | √ | √ | √ | √ | – | - |
| benz diesel | ECONIC | ECONIC 957.5 - 957.6 | FR drive control | | | √ | √ | √ | √ | √ | - |
| benz diesel | ECONIC | ECONIC 957.5 - 957.6 | ABS anti-lock braking system | | | √ | √ | √ | √ | √ | - |
| benz diesel | ECONIC | ECONIC 957.5 - 957.6 | WS Maintenance System | | | √ | √ | √ | √ | – | - |
| benz diesel | Vario 512 | Vario 512 WDB930.0 - 934.0(16 pin socket) | ABS Bosch 5.3 | | | √ | | √ | – | – | - |
| benz diesel | Vario 512 | Vario 512 WDB930.0 - 934.0(16 pin socket) | Bosch MR PF Pump(PLD/PLN injection system) | | | √ | √ | √ | – | – | - |
| benz diesel | Truck | 16PIN Socket | Actros MPII | GM Base module | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | Actros MPII | MR Engine control | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | Actros MPII | FR drive control | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | Actros MPII | BS Brake control | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | Actros MPII | EDW Anti-theft alarm | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | Actros MPII | GS Gear control | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | Actros MPII | INS Instrument | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | Actros MPII | MTC0 Modular tachograph | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | Actros MPII | PSM Parameterizable Special Module | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | Actros MPII | WS Maintenance System | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | Actros MPII | FLA Flame starting system | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | Actros MPII | RS Retarder control | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | Actros MPII | SPA Lane Assistant | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | Actros MPII | FM front module | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | Actros MPII | ABA Active Brake Assist | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | Actros MPII | EHZ electro-hydraulic auxiliary steering | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | Actros MPII | RDK tire pressure control | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | Actros MPII | Steering wheel angle sensor | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | Actros MPII | HM Rear module | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | Actros MPII | MSF Modular switch panel | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO WDB970-976,NAB374,4 | MR Engine control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO WDB970-976,NAB374,4 | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO WDB970-976,NAB374,4 | MTCO Modular tachograph | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO WDB970-976,NAB374,4 | PSM Parameterizable Special Module | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO WDB970-976,NAB374,4 | WS Maintenance System | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO WDB970-976,NAB374,4 | GS Gear control(AGS) | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO WDB970-976,NAB374,4 | BS Brake control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO WDB970-976,NAB374,4 | EHZ Electro-hydraulic auxiliary steering | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO WDB970-976,NAB374,4 | NR Level control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO WDB970-976,NAB374,4 | ABS anti-lock braking system | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO NMB375.1 | MR Engine control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO NMB375.1 | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO NMB375.1 | MTCO Modular tachograph | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO NMB375.1 | PSM Parameterizable Special Module | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO NMB375.1 | EHZ Electro-hydraulic auxiliary steering | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO NMB375.1 | ABS anti-lock braking system | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO NMB375.1 | NR Level control | √ | √ | √ | √ | – | - |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO 9BM958.0 | MR Engine control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO 9BM958.0 | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO 9BM958.0 | MTCO Modular tachograph | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO 9BM958.0 | PSM Parameterizable Special Module | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO 9BM958.0 | WS Maintenance System | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO 9BM958.0 | NR Level control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | ATEGO | ATEGO 9BM958.0 | ABS anti-lock braking system | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -R WDB950.5 - 954.6,NAB374.5 | MR Engine control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -R WDB950.5 - 954.6,NAB374.5 | FR drive control | √ | √ | √ | √ | – | √ |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -R WDB950.5 - 954.6,NAB374.5 | GS Gear control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -R WDB950.5 - 954.6,NAB374.5 | MTCO Modular tachograph | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -R WDB950.5 - 954.6,NAB374.5 | PSM Parameterizable Special Module | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -R WDB950.5 - 954.6,NAB374.5 | WS Maintenance System | √ | √ | √ | √ | – | √ |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -R WDB950.5 - 954.6,NAB374.5 | GS Gear control(AGS) | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -R WDB950.5 - 954.6,NAB374.5 | BS Brake control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -R WDB950.5 - 954.6,NAB374.5 | EHZ Electrol-hydraulic auxiliary steering | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -R WDB950.5 - 954.6,NAB374.5 | Steering wheel angle sensor | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -R WDB950.5 - 954.6,NAB374.5 | ABS anti-lock braking system | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -R WDB950.5 - 954.6,NAB374.5 | NR Level control | √ | √ | √ | √ | – | √ |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR NMB375.3 | MR Engine control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -R WDB950.5 - 954.6,NAB374.5 | NR Level control | √ | √ | √ | √ | – | √ |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR NMB375.3 | MR Engine control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR NMB375.3 | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR NMB375.3 | GS Gear control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR NMB375.3 | MTCO Modular tachograph | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR NMB375.3 | PSM Parameterizable Special Module | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR NMB375.3 | WS Maintenance System | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR NMB375.3 | BS Brake control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR NMB375.3 | EHZ Electro-hydraulic auxiliary steering | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR NMB375.3 | ABS anti-lock braking system | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR NMB375.3 | NR Level control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR NMB375.3 | Steering wheel angle sensor | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -C WDB940-944,NAB374.6 | MR Engine control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -C WDB940-944,NAB374.6 | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -C WDB940-944,NAB374.6 | GS Gear control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -C WDB940-944,NAB374.6 | MTCO Modular tachograph | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -C WDB940-944,NAB374.6 | PSM Parameterizable Special Module | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -C WDB940-944,NAB374.6 | WS Maintenance System | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -C WDB940-944,NAB374.6 | BS Brake control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -C WDB940-944,NAB374.6 | EHZ Electro-hydraulic auxiliary steering | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -C WDB940-944,NAB374.6 | ABS anti-lock braking system | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -C WDB940-944,NAB374.6 | NR Level control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXOR | AXOR -C WDB940-944,NAB374.6 | Steering wheel angle sensor | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXORII | AXOR -R WDB950.5 - 954.6, NAB374.5 | ABS anti-lock braking system | √ | √ | √ | √ | – | √ |
| benz diesel | Truck | 16PIN Socket | AXORII | AXOR -R WDB950.5 - 954.6, NAB374.5 | FFB radio remote control | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 16PIN Socket | AXORII | AXOR -R WDB950.5 - 954.6, NAB374.5 | FR drive control | √ | √ | √ | √ | – | √ |
| benz diesel | Truck | 16PIN Socket | AXORII | AXOR -R WDB950.5 - 954.6, NAB374.5 | HPS hydraulic pneumatic shift | √ | √ | √ | √ | – | √ |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | Truck | 16PIN Socket | AXORII | AXOR -R WDB950.5 - 954.6, NAB374.5 | INS Instrument | √ | √ | √ | – | – | √ |
| benz diesel | Truck | 16PIN Socket | AXORII | AXOR -R WDB950.5 - 954.6, NAB374.5 | MR engine control | √ | √ | √ | √ | √ | √ |
| benz diesel | Truck | 16PIN Socket | AXORII | AXOR -R WDB950.5 - 954.6, NAB374.5 | NR level control | √ | √ | √ | √ | – | √ |
| benz diesel | Truck | 16PIN Socket | AXORII | AXOR -R WDB950.5 - 954.6, NAB374.5 | WS Maintenance System | √ | √ | √ | √ | – | √ |
| benz diesel | Truck | 16PIN Socket | AXORII | AXOR -R WDB950.5 - 954.6, NAB374.5 | ZV central locking system | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 14PIN_Socket | ACTROS | MR Engine control | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 14PIN_Socket | ACTROS | MTCO Modular tachograph | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 14PIN_Socket | ACTROS | PSM Parameterizable Special Module | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 14PIN_Socket | ACTROS | FLA Flame starting system | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 14PIN_Socket | ACTROS | WS Maintenance System | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 14PIN_Socket | ACTROS | SPA Lane Assistant | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 14PIN_Socket | ACTROS | AG automatic gear selection (AGE) | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 14PIN_Socket | ACTROS | GS Gear control | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 14PIN_Socket | ACTROS | ABS anti-lock braking system | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 14PIN_Socket | ACTROS | NR level control | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 14PIN_Socket | ACTROS | TCO Tachograph | | √ | √ | √ | √ | – | - |
| benz diesel | Truck | 14PIN_Socket | ACTROS | EDW Anti-theft alarm | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TRAVEGO | MR-Engine Control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TRAVEGO | FR drive control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TRAVEGO | GS-Gear control (AGS) | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TRAVEGO | ABS-antilock braking system | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TRAVEGO | ZV-central locking system | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TRAVEGO | ZHE-Auxiliary heater | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TRAVEGO | FPS variable programming control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TRAVEGO | DMUX (display mux) | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TRAVEGO | BS-Brake Control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TRAVEGO | RS-reducer control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TRAVEGO | ART-independent intelligent cruise control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TRAVEGO | NR1 single type passenger cars or car level control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TRAVEGO | SPA-lane change assistance systems | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TRAVEGO | ZL-power steering | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TRAVEGO | Steering angle sensor | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TRAVEGO | MTS door control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TRAVEGO | HLK heating - Ventilation - Refrigeration Equipment | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TRAVEGO | NR1 Level control solo bus or front vehicle | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TRAVEGO | ZL Auxiliary steering | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TRAVEGO | FPS Flexibly programmed control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTOURO | INTOURO(C632) | DTCO-digital tachometer | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTOURO | INTOURO(C632) | AGN automatic transmission EcoLife | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTOURO | INTOURO(C632) | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTOURO | INTOURO(C632) | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTOURO | INTOURO(C632) | ABS-antilock braking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTOURO | INTOURO(C632) | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTOURO | INTOURO(C632) | FPS variable programming control | √ | √ | √ | √ | – | - |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | Bus | 16-pin socket | INTOURO | INTOURO(C632) | DMUX (display mux) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTOURO | INTOURO(C632) | BS-Brake Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTOURO | INTOURO(C632) | RS-reducer control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTOURO | INTOURO(C632) | NR1 single type passenger cars or car level control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTOURO | INTOURO(C632) | Steering angle sensor | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTOURO | INTOURO(C632) | MTS door control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTOURO | INTOURO(C632) | HLK heating - Ventilation - Refrigeration Equipment | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTOURO | INTOURO(C632) | NR1 Level control solo bus or front vehicle | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTOURO | INTOURO(C632) | FPS Flexibly programmed control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTEGRO | INTEGRO(C633) | DTCO-digital tachometer | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTEGRO | INTEGRO(C633) | AGN automatic transmission E200 | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTEGRO | INTEGRO(C633) | AGN automatic transmission EcoLife | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTEGRO | INTEGRO(C633) | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTEGRO | INTEGRO(C633) | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTEGRO | INTEGRO(C633) | GS-Gear control (AGS) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTEGRO | INTEGRO(C633) | ABS-antilock braking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTEGRO | INTEGRO(C633) | ZV-central locking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTEGRO | INTEGRO(C633) | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTEGRO | INTEGRO(C633) | FPS variable programming control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTEGRO | INTEGRO(C633) | DMUX (display mux) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTEGRO | INTEGRO(C633) | BS-Brake Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTEGRO | INTEGRO(C633) | RS-reducer control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTEGRO | INTEGRO(C633) | NR1 single type passenger cars or car level control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTEGRO | INTEGRO(C633) | ZL-power steering | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTEGRO | INTEGRO(C633) | Steering angle sensor | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTEGRO | INTEGRO(C633) | MTS door control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTEGRO | INTEGRO(C633) | HLK heating - Ventilation - Refrigeration Equipment | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTEGRO | INTEGRO(C633) | NR1 Level control solo bus or front vehicle | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTEGRO | INTEGRO(C633) | ZL Auxiliary steering | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | INTEGRO | INTEGRO(C633) | FPS Flexibly programmed control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | CITARO | EGM electronic gas engine | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | CITARO | DTCO-digital tachometer | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | CITARO | AGN automatic transmission E200 | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | CITARO | AGN automatic transmission EcoLife | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | CITARO | MR-Engine Control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | CITARO | FR drive control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | CITARO | GS-Gear control (AGS) | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | CITARO | ZHE-Auxiliary heater | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | CITARO | FPS variable programming control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | CITARO | DMUX (display multiplexer | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | CITARO | BS-Brake Control | | √ | √ | √ | √ | – | - |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | Bus | 16-pin socket | CITARO | RS-reducer control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | CITARO | NR1 single type passenger cars or car level control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | CITARO | ZL-power steering | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | CITARO | Steering angle sensor | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | CITARO | MTS door control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | CITARO | HLK heating - Ventilation - Refrigeration Equipment | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | CITARO | NR1 Level control solo bus or front vehicle | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | CITARO | ZL Auxiliary steering | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | CITARO | FPS Flexibly programmed control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | OC500 | OC500 LF LFA | EGM electronic gas engine</NAME> | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | OC500 | OC500 LF LFA | DTCO-digital tachometer</NAME> | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | OC500 | OC500 LF LFA | AGN automatic transmission E200</NAME> | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | OC500 | OC500 LF LFA | MR-Engine Control</NAME> | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | OC500 | OC500 LF LFA | FR drive control</NAME> | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | OC500 | OC500 LF LFA | ZHE-Auxiliary heater</NAME> | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | OC500 | OC500 LF LFA | FPS variable programming control</NAME> | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | OC500 | OC500 LF LFA | DMUX (display mux)</NAME> | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | OC500 | OC500 LF LFA | BS-Brake Control</NAME> | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | OC500 | OC500 LF LFA | RS-reducer control</NAME> | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | OC500 | OC500 LF LFA | NR1 single type passenger cars or car level control</NAME> | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | OC500 | OC500 LF LFA | Steering angle sensor</NAME> | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | OC500 | OC500 LF LFA | MTS door control</NAME> | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | OC500 | OC500 LF LFA | NR1 Level control solo bus or front vehicle | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | OC500 | OC500 LF LFA | FPS Flexibly programmed control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass | DTCO-digital tachometer | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass | GS-Gear control (AGS) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass | ZV-central locking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass | FPS variable programming control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass | DMUX (display mux) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass | BS-Brake Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass | RS-reducer control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass | ART-independent intelligent cruise control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass | NR1 single type passenger cars or car level control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass | SPA-lane change assistance systems | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass | ZL-power steering | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass | Steering angle sensor | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass | MTS door control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass | HLK heating - Ventilation - Refrigeration Equipment | √ | √ | √ | √ | – | - |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass | CLS-convenient locking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 ComfortClass | DTCO-digital tachometer | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 ComfortClass | AGN automatic transmission EcoLife | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 ComfortClass | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 ComfortClass | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 ComfortClass | GS-Gear control (AGS) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 ComfortClass | ZV-central locking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 ComfortClass | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 ComfortClass | FPS variable programming control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 ComfortClass | DMUX (display mux) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 ComfortClass | BS-Brake Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 ComfortClass | RS-reducer control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 ComfortClass | ART-independent intelligent cruise control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 ComfortClass | NR1 single type passenger cars or car level control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 ComfortClass | SPA-lane change assistance systems | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 ComfortClass | ZL-power steering | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 ComfortClass | Steering angle sensor | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 ComfortClass | MTS door control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 ComfortClass | HLK heating - Ventilation - Refrigeration Equipment | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 ComfortClass | ABA-assisted brakes | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass | DTCO-digital tachometer | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass | AGN automatic transmission E200 | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass | AGN automatic transmission EcoLife | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass | ABS-antilock braking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass | GS-Gear control (AGS) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass | ZV-central locking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass | FPS variable programming control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass | DMUX (display mux) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass | BS-Brake Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass | RS-reducer control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass | NR1 single type passenger cars or car level control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass | ZL-power steering | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass | Steering angle sensor | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass | MTS door control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass | HLK heating - Ventilation - Refrigeration Equipment | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass | ABA-assisted brakes | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass(NC) | DTCO-digital tachometer | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass(NC) | AGN automatic transmission E200 | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass(NC) | AGN automatic transmission EcoLife | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass(NC) | MR-Engine Control | √ | √ | √ | √ | – | - |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass(NC) | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass(NC) | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass(NC) | FPS variable programming control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass(NC) | DMUX (display mux) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass(NC) | BS-Brake Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass(NC) | RS-reducer control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass(NC) | NR1 single type passenger cars or car level control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass(NC) | ZL-power steering | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass(NC) | Steering angle sensor | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass(NC) | MTS door control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 MultiClass(NC) | HLK heating - Ventilation - Refrigeration Equipment | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass USA | ZV-central locking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass USA | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass USA | FPS variable programming control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass USA | DMUX (display mux) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | BR400 | Setra BR400 TopClass USA | MTS door control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | TOURISMO(C632) | DTCO-digital tachometer | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | TOURISMO(C632) | AGN automatic transmission EcoLife | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | TOURISMO(C632) | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | TOURISMO(C632) | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | TOURISMO(C632) | GS-Gear control (AGS) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | TOURISMO(C632) | ABS-antilock braking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | TOURISMO(C632) | ZV-central locking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | TOURISMO(C632) | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | TOURISMO(C632) | FPS variable programming control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | TOURISMO(C632) | DMUX (display mux) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | TOURISMO(C632) | BS-Brake Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | TOURISMO(C632) | RS-reducer control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | TOURISMO(C632) | NR1 single type passenger cars or car level control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | TOURISMO(C632) | Steering angle sensor | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | TOURISMO(C632) | MTS door control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | TOURISMO(C632) | HLK heating - Ventilation - Refrigeration Equipment | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | TOURISMO(C632) | ABA-assisted brakes | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CONECTO 0345 | DTCO-digital tachometer | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CONECTO 0345 | AGN automatic transmission E200 | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CONECTO 0345 | AGN automatic transmission EcoLife | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CONECTO 0345 | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CONECTO 0345 | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CONECTO 0345 | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CONECTO 0345 | FPS variable programming control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CONECTO 0345 | DMUX (display mux) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CONECTO 0345 | BS-Brake Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CONECTO 0345 | NR1 single type passenger cars or car level control | √ | √ | √ | √ | – | - |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CONECTO 0345 | ZL-power steering | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CONECTO 0345 | Steering angle sensor | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CONECTO 0345 | HLK heating - Ventilation - Refrigeration Equipment | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CAPACITY | DTCO-digital tachometer | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CAPACITY | AGN automatic transmission E200 | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CAPACITY | AGN automatic transmission EcoLife | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CAPACITY | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CAPACITY | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CAPACITY | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CAPACITY | FPS variable programming control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CAPACITY | DMUX (display mux) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CAPACITY | BS-Brake Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CAPACITY | NR1 single type passenger cars or car level control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CAPACITY | ZL-power steering | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CAPACITY | Steering angle sensor | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CAPACITY | MTS door control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | TOURISMO 0403 | CAPACITY | HLK heating - Ventilation - Refrigeration Equipment | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 16-pin socket | OF/OH | | MR-Engine Control | √ | √ | √ | √ | √ | – |
| benz diesel | Bus | 16-pin socket | OF/OH | | FR drive control | √ | √ | √ | √ | – | √ |
| benz diesel | Bus | 16-pin socket | OF/OH | | INS Instrument | √ | √ | √ | – | – | – |
| benz diesel | Bus | 14-pin socket | O405-O408 | EMR | | √ | √ | – | √ | – | - |
| benz diesel | Bus | 14-pin socket | O405-O408 | EN1 | | √ | √ | – | √ | √ | √ |
| benz diesel | Bus | 14-pin socket | O405-O408 | AGN | | √ | √ | – | √ | – | - |
| benz diesel | Bus | 14-pin socket | TRAVEGO | DTCO-digital tachometer | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | TRAVEGO | MR-Engine Control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | TRAVEGO | FR drive control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | TRAVEGO | GS-Gear control (AGS) | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | TRAVEGO | ABS-antilock braking system | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | TRAVEGO | ZV-central locking system | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | TRAVEGO | ZHE-Auxiliary heater | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | TRAVEGO | FPS variable programming control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | TRAVEGO | DMUX (display mux) | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | TRAVEGO | BS-Brake Control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | TRAVEGO | RS-reducer control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | TRAVEGO | ART-independent intelligent cruise control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | TRAVEGO | NR1 single type passenger cars or car level control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | TRAVEGO | SPA-lane change assistance systems | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | TRAVEGO | ZL-power steering | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | TRAVEGO | Steering angle sensor | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | TRAVEGO | MTS door control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | TRAVEGO | HLK heating - Ventilation - Refrigeration Equipment | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTOURO | 0560 INTOURO Euro III | MR-Engine Control | √ | √ | √ | √ | – | - |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | Bus | 14-pin socket | INTOURO | 0560 INTOURO Euro III | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTOURO | 0560 INTOURO Euro III | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTOURO | 0560 INTOURO Euro III | RS-reducer control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTOURO | INTOURO(C632) | DTCO-digital tachometer | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTOURO | INTOURO(C632) | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTOURO | INTOURO(C632) | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTOURO | INTOURO(C632) | ABS-antilock braking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTOURO | INTOURO(C632) | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTOURO | INTOURO(C632) | FPS variable programming control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTOURO | INTOURO(C632) | DMUX (display mux) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTOURO | INTOURO(C632) | BS-Brake Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTOURO | INTOURO(C632) | RS-reducer control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTOURO | INTOURO(C632) | MTS door control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTOURO | INTOURO(C632) | HLK heating - Ventilation - Refrigeration Equipment | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | 0550 INTEGRO | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | 0550 INTEGRO | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | 0550 INTEGRO | GS-Gear control (AGS) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | 0550 INTEGRO | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | 0550 INTEGRO | RS-reducer control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | 0550 INTEGRO | MTS door control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | INTEGRO(C633) | DTCO-digital tachometer | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | INTEGRO(C633) | AGN automatic transmission E200 | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | INTEGRO(C633) | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | INTEGRO(C633) | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | INTEGRO(C633) | GS-Gear control (AGS) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | INTEGRO(C633) | ABS-antilock braking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | INTEGRO(C633) | ZV-central locking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | INTEGRO(C633) | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | INTEGRO(C633) | FPS variable programming control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | INTEGRO(C633) | DMUX (display mux) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | INTEGRO(C633) | BS-Brake Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | INTEGRO(C633) | RS-reducer control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | INTEGRO(C633) | NR1 single type passenger cars or car level control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | INTEGRO(C633) | MTS door control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | INTEGRO(C633) | HLK heating - Ventilation - Refrigeration Equipment | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | INTEGRO | INTEGRO(C633) | GS-Gear control (AGS) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | CITARO | EGM electronic gas engine | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | CITARO | DTCO-digital tachometer | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | CITARO | AGN automatic transmission E200 | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | CITARO | FR drive control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | CITARO | ZHE-Auxiliary heater | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | CITARO | FPS variable programming control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | CITARO | DMUX (display mux) | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | CITARO | BS-Brake Control | | √ | √ | √ | √ | – | - |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | Bus | 14-pin socket | CITARO | RS-reducer control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | CITARO | NR1 single type passenger cars or car level control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | CITARO | ZL-power steering | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | CITARO | Steering angle sensor | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | CITARO | MTS door control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | CITARO | HLK heating - Ventilation - Refrigeration Equipment | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | CITO | MR-Engine Control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | CITO | FR drive control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | CITO | ZHE-Auxiliary heater | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | CITO | FPS variable programming control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | CITO | BS-Brake Control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | CITO | MTS door control | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | CITO | HLK heating - Ventilation - Refrigeration Equipment | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | CITO | FE Drive electronics | | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | OC500 | OC500 LF LFA | EGM electronic gas engine | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | OC500 | OC500 LF LFA | DTCO-digital tachometer | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | OC500 | OC500 LF LFA | AGN automatic transmission E200 | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | OC500 | OC500 LF LFA | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | OC500 | OC500 LF LFA | AGN automatic transmission E200 | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | OC500 | OC500 LF LFA | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | OC500 | OC500 LF LFA | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | OC500 | OC500 LF LFA | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | OC500 | OC500 LF LFA | FPS variable programming control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | OC500 | OC500 LF LFA | DMUX (display mux) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | OC500 | OC500 LF LFA | BS-Brake Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | OC500 | OC500 LF LFA | RS-reducer control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | OC500 | OC500 LF LFA | NR1 single type passenger cars or car level control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | OC500 | OC500 LF LFA | Steering angle sensor | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0345 CONECTO | 0345 CONECTO Euro III single node passenger | AGN automatic transmission E200 | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0345 CONECTO | 0345 CONECTO Euro III single node passenger | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0345 CONECTO | 0345 CONECTO Euro III single node passenger | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0345 CONECTO | 0345 CONECTO Euro III single node passenger | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0345 CONECTO | 0345 CONECTO Euro III single node passenger | RS-reducer control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0345 CONECTO | 0345 CONECTO Euro III single node passenger | ADM adaptation module | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0345 CONECTO | 0345 CONECTO Euro III articulated bus | AGN automatic transmission E200 | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0345 CONECTO | 0345 CONECTO Euro III articulated bus | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0345 CONECTO | 0345 CONECTO Euro III articulated bus | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0345 CONECTO | 0345 CONECTO Euro III articulated bus | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0345 CONECTO | 0345 CONECTO Euro III articulated bus | RS-reducer control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0345 CONECTO | 0345 CONECTO Euro III articulated bus | ADM adaptation module | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR300 | Setra BR300 Kombilbus Euro III | AGN automatic transmission E200 | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR300 | Setra BR300 Kombilbus Euro III | MR-Engine Control | √ | √ | √ | √ | – | - |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | Bus | 14-pin socket | BR300 | Setra BR300 Kombilbus Euro III | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR300 | Setra BR300 Kombilbus Euro III | RS-reducer control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR300 | Setra BR300 Kombilbus Euro III | GS-Gear control (AGS) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR300 | Setra BR300 Kombilbus Euro III | MTS door control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR300 | Setra BR300 Kombilbus Euro III | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR300 | Setra BR300 Kombilbus Euro III | ADM adaptation module | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR300 | Setra BR300 Kombilbus Euro III | KWS bending angle control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR300 | BR 300 Reisebus 3 Euro III | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR300 | BR 300 Reisebus 3 Euro III | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR300 | BR 300 Reisebus 3 Euro III | RS-reducer control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR300 | BR 300 Reisebus 3 Euro III | GS-Gear control (AGS) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR300 | BR 300 Reisebus 3 Euro III | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR300 | BR 300 Reisebus 3 Euro III | ADM adaptation module | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | S315 | S315 HD China Euro III | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | S315 | S315 HD China Euro III | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | S315 | S315 HD China Euro III | RS-reducer control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | S315 | S315 HD China Euro III | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | S315 | S315 HD China Euro III | ADM adaptation module | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass | DTCO-digital tachometer | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass | GS-Gear control (AGS) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass | ZV-central locking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass | FPS variable programming control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass | DMUX (display mux) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass | BS-Brake Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass | RS-reducer control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass | ART-independent intelligent cruise control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass | NR1 single type passenger cars or car level control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass | SPA-lane change assistance systems | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass | ZL-power steering | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass | Steering angle sensor | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass | MTS door control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass | HLK heating - Ventilation - Refrigeration Equipment | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass | CLS-convenient locking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 ComfortClass | DTCO-digital tachometer | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 ComfortClass | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 ComfortClass | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 ComfortClass | GS-Gear control (AGS) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 ComfortClass | ZV-central locking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 ComfortClass | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 ComfortClass | FPS variable programming control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 ComfortClass | DMUX (display mux) | √ | √ | √ | √ | – | - |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 ComfortClass | BS-Brake Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 ComfortClass | RS-reducer control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 ComfortClass | ART-independent intelligent cruise control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 ComfortClass | NR1 single type passenger cars or car level control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 ComfortClass | SPA-lane change assistance systems | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 ComfortClass | ZL-power steering | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 ComfortClass | Steering angle sensor | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 ComfortClass | MTS door control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 ComfortClass | HLK heating - Ventilation - Refrigeration Equipment | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 MultiClass | DTCO-digital tachometer | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 MultiClass | AGN automatic transmission E200 | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 MultiClass | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 MultiClass | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 MultiClass | ABS-antilock braking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 MultiClass | GS-Gear control (AGS) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 MultiClass | ZV-central locking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 MultiClass | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 MultiClass | FPS variable programming control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 MultiClass | DMUX (display mux) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 MultiClass | BS-Brake Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 MultiClass | RS-reducer control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 MultiClass | NR1 single type passenger cars or car level control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 MultiClass | MTS door control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass USA | ZV-central locking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass USA | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass USA | FPS variable programming control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass USA | DMUX (display mux) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass USA | MTS door control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass USA | HLK heating - Ventilation - Refrigeration Equipment | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | BR400 | Setra BR400 TopClass USA | ABS-antilock braking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0350 TOURISMO 0403 | TOURISMO(C632) | DTCO-digital tachometer | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0350 TOURISMO 0403 | TOURISMO(C632) | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0350 TOURISMO 0403 | TOURISMO(C632) | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0350 TOURISMO 0403 | TOURISMO(C632) | GS-Gear control (AGS) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0350 TOURISMO 0403 | TOURISMO(C632) | ABS-antilock braking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0350 TOURISMO 0403 | TOURISMO(C632) | ZV-central locking system | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0350 TOURISMO 0403 | TOURISMO(C632) | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0350 TOURISMO 0403 | TOURISMO(C632) | FPS variable programming control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0350 TOURISMO 0403 | TOURISMO(C632) | DMUX (display mux) | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0350 TOURISMO 0403 | TOURISMO(C632) | BS-Brake Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0350 TOURISMO 0403 | TOURISMO(C632) | RS-reducer control | √ | √ | √ | √ | – | - |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | Bus | 14-pin socket | 0350 TOURISMO 0403 | TOURISMO(C632) | NR1 single type passenger cars or car level control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0350 TOURISMO 0403 | TOURISMO(C632) | Steering angle sensor | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0350 TOURISMO 0403 | TOURISMO(C632) | MTS door control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0350 TOURISMO 0403 | TOURISMO(C632) | HLK heating - Ventilation - Refrigeration Equipment | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0350 TOURISMO 0403 | TOURISMO(C632) | ADM adaptation module | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0350 TOURISMO 0403 | TOURISMO 0403 | MR-Engine Control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0350 TOURISMO 0403 | TOURISMO 0403 | FR drive control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0350 TOURISMO 0403 | TOURISMO 0403 | RS-reducer control | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0350 TOURISMO 0403 | TOURISMO 0403 | ZHE-Auxiliary heater | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | 0350 TOURISMO 0403 | TOURISMO 0403 | ADM adaptation module | √ | √ | √ | √ | – | - |
| benz diesel | Bus | 14-pin socket | ZAFIRO/TORINO/BOXER | | PLD Engine Control Module | √ | √ | √ | √ | √ | - |
| benz diesel | Bus | 14-pin socket | ZAFIRO/TORINO/BOXER | | ADM Adaptation Module | √ | √ | √ | √ | – | √ |
| benz diesel | Bus | 14-pin socket | OLD BENZ | | FMR | √ | √ | – | – | – | - |
| benz diesel | ATEGO HEAVY | MR engine control | | | | √ | √ | √ | √ | √ | - |
| benz diesel | ATEGO HEAVY | FR drive control | | | | √ | √ | √ | √ | √ | - |
| benz diesel | ATEGO HEAVY | ABS anti-lock braking system | | | | √ | √ | √ | √ | √ | - |
| benz diesel | ATEGO HEAVY | INS Instrument | | | | √ | √ | √ | √ | – | - |
| benz diesel | ATEGO HEAVY | FFB radio remote control | | | | √ | √ | √ | √ | √ | - |
| benz diesel | ATEGO HEAVY | ZV central locking system | | | | √ | √ | √ | √ | – | - |
| benz diesel | Unimogs | MR engine control | | | | √ | √ | √ | √ | √ | - |
| benz diesel | Unimogs | ABS anti-lock braking system | | | | √ | √ | √ | √ | √ | - |
| benz diesel | Unimogs | DTCO digital Tachograph | | | | √ | √ | √ | √ | – | - |
| benz diesel | Unimogs | FR drive control | | | | √ | √ | √ | √ | √ | - |
| benz diesel | Unimogs | GS Gear control | | | | √ | √ | √ | √ | – | - |
| benz diesel | Unimogs | HYD Power hydraulics | | | | √ | √ | √ | √ | – | - |
| benz diesel | Unimogs | INS Instrument | | | | √ | √ | √ | √ | – | - |
| benz diesel | Unimogs | KS clutch control | | | | √ | √ | √ | √ | √ | √ |
| benz diesel | ACTROS MP IV | diesel | ACM | | | √ | √ | √ | √ | – | √ |
| benz diesel | ACTROS MP IV | diesel | MCM | | | √ | √ | √ | √ | – | √ |
| benz diesel | ACTROS MP IV | brake | EBS | Knorr bremse | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS MP IV | brake | EBS | Wabco | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS MP IV | brake | RCM | Retarder | | √ | √ | √ | √ | – | √ |
| benz diesel | ACTROS MP IV | Climate | HVAC | Climate control | | √ | √ | √ | √ | – | √ |
| benz diesel | ACTROS MP IV | Climate | ITH | Auxiliary heating | | √ | √ | √ | √ | √ | – |
| benz diesel | ACTROS MP IV | Instrument | Brake | ICUC | | √ | √ | √ | √ | √ | - |
| benz diesel | ACTROS MP IV | Instrument | Brake | Tachograph | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS MP IV | Multifunction | ASA | Auxiliary steering | | √ | √ | √ | √ | √ | √ |
| benz diesel | ACTROS MP IV | Multifunction | CDS | Central data memory | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS MP IV | Multifunction | CGW | Central gateway | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS MP IV | Multifunction | COM | Communication Interface | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS MP IV | Multifunction | CPC | Drive control | | √ | √ | √ | √ | – | - |
| benz diesel | ACTROS MP IV | Multifunction | DCMD | Driver Door Module | | √ | √ | √ | √ | √ | - |
| benz diesel | ACTROS MP IV | Multifunction | DCMP | Passenger Door Module | | √ | √ | √ | √ | √ | - |
| benz diesel | ACTROS MP IV | Multifunction | EAPU | Haldex | | √ | √ | √ | √ | – | - |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | ACTROS MP IV | Multifunction | EAPU | Knorr Bremse | | √ | √ | √ | √ | - | - |
| benz diesel | ACTROS MP IV | Multifunction | EIS | Electronic ignition lock | | √ | √ | √ | √ | √ | - |
| benz diesel | ACTROS MP IV | Multifunction | MS | Maintenance System | | √ | √ | √ | √ | - | √ |
| benz diesel | ACTROS MP IV | Multifunction | MSF | Modularable Switch Module | | √ | √ | √ | √ | √ | - |
| benz diesel | ACTROS MP IV | Multifunction | PSM | Parameterable Special Module | | √ | √ | √ | √ | - | - |
| benz diesel | ACTROS MP IV | Multifunction | SAS | Steering wheel angle sensor | | √ | √ | √ | √ | - | - |
| benz diesel | ACTROS MP IV | Multifunction | SCA | Radio | | √ | √ | √ | √ | √ | - |
| benz diesel | ACTROS MP IV | Multifunction | SCH | Frame signal acquisition and actuation module control unit | | √ | √ | √ | √ | √ | - |
| benz diesel | ACTROS MP IV | Multifunction | SRS | Supplemental restraint system control unit | | √ | √ | √ | √ | - | - |
| benz diesel | ACTROS MP IV | Multifunction | TCC | Radio | | √ | √ | √ | √ | √ | - |
| benz diesel | ACTROS MP IV | Multifunction | TP | Telematics | | √ | √ | √ | - | - | - |
| benz diesel | ACTROS MP IV | Multifunction | TPM | Tyre pressure monitoring | | √ | √ | √ | √ | - | - |
| benz diesel | ACTROS MP IV | Gearbox | TCM | Transmission control | | √ | √ | √ | √ | - | √ |
| benz diesel | ACTROS MP IV | Service Light RESET(SLR) | MS | Maintenance System | | √ | √ | √ | √ | - | √ |
| benz diesel | ACTROS MP IV | Suspension | CLCS | Air suspension | Full air suspension | √ | √ | √ | √ | - | - |
| benz diesel | ACTROS MP IV | Suspension | CLCS | Air suspension | Half air suspension | √ | √ | √ | √ | - | - |
| benz diesel | Antos | diesel | ACM | Exhaust aftertreatment | | √ | √ | √ | √ | - | - |
| benz diesel | Antos | diesel | MCM | Engine Control | | √ | √ | √ | √ | - | √ |
| benz diesel | Antos | brake | EBS | Knorr bremse 2Axle | | √ | √ | √ | √ | - | - |
| benz diesel | Antos | brake | EBS | Wabco 3Axle | | √ | √ | √ | - | - | - |
| benz diesel | Antos | brake | RCM | Retarder | | √ | √ | √ | √ | - | - |
| benz diesel | Antos | Climate | HVAC | Climate control | | √ | √ | √ | √ | √ | - |
| benz diesel | Antos | Climate | ITH | Auxiliary heating | | √ | √ | √ | √ | - | - |
| benz diesel | Antos | Instrument | Brake | ICUC | | √ | √ | √ | √ | √ | - |
| benz diesel | Antos | Instrument | Brake | Tachograph | | √ | √ | √ | √ | - | - |
| benz diesel | Antos | Multifunction | ASA | Auxiliary steering | | √ | √ | √ | √ | - | - |
| benz diesel | Antos | Multifunction | CDS | Central data memory | | √ | √ | √ | √ | - | - |
| benz diesel | Antos | Multifunction | CGW | Central gateway | | √ | √ | √ | √ | - | - |
| benz diesel | Antos | Multifunction | COM | Communication Interface | | √ | √ | √ | √ | - | - |
| benz diesel | Antos | Multifunction | CPC | Drive control | | √ | √ | √ | √ | - | - |
| benz diesel | Antos | Multifunction | DCMD | Driver Door Module | | √ | √ | √ | √ | √ | - |
| benz diesel | Antos | Multifunction | DCMP | Passenger Door Module | | √ | √ | √ | √ | √ | - |
| benz diesel | Antos | Multifunction | EAPU | Haldex | | √ | √ | √ | √ | - | - |
| benz diesel | Antos | Multifunction | EAPU | Knorr Bremse | | √ | √ | √ | √ | - | - |
| benz diesel | Antos | Multifunction | EIS | Electronic ignition lock | | √ | √ | √ | √ | √ | - |
| benz diesel | Antos | Multifunction | MS | Maintenance System | | √ | √ | √ | √ | - | - |
| benz diesel | Antos | Multifunction | MSF | Modularable Switch Module | | √ | √ | √ | √ | √ | - |
| benz diesel | Antos | Multifunction | PSM | Parameterable Special Module | | √ | √ | √ | √ | - | - |
| benz diesel | Antos | Multifunction | SAS | Steering wheel angle sensor | | √ | √ | √ | √ | - | - |
| benz diesel | Antos | Multifunction | SCA | Radio | | √ | √ | √ | √ | √ | - |
| benz diesel | Antos | Multifunction | SCH | Frame signal acquisition and actuation module control unit | | √ | √ | √ | √ | √ | - |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | Antos | Multifunction | SRS | Supplemental restraint system control unit | | √ | √ | √ | – | – | - |
| benz diesel | Antos | Multifunction | TCC | Radio | | √ | √ | √ | √ | √ | - |
| benz diesel | Antos | Multifunction | TP | Telematics | | √ | √ | √ | – | – | - |
| benz diesel | Antos | Multifunction | TPM | Tyre pressure monitoring | | √ | √ | √ | √ | – | - |
| benz diesel | Antos | Gearbox | TCM | Transmission control | | √ | √ | √ | √ | – | √ |
| benz diesel | Antos | Service Light RESET(SLR) | MS | Maintenance System | | √ | √ | √ | √ | – | √ |
| benz diesel | Antos | Suspension | CLCS | Air suspension | | √ | √ | √ | √ | – | - |
| benz diesel | ATEGO III | diesel | ACM | Exhaust aftertreatment | | √ | √ | √ | √ | – | - |
| benz diesel | ATEGO III | diesel | MCM | Engine Control | | √ | √ | √ | √ | – | - |
| benz diesel | ATEGO III | brake | EBS | Knorr bremse 2Axle | | √ | √ | √ | √ | – | - |
| benz diesel | ATEGO III | brake | RCM | Retarder | | √ | √ | √ | √ | – | - |
| benz diesel | ATEGO III | Instrument | Brake | ICUC | | √ | √ | √ | – | – | - |
| benz diesel | ATEGO III | Instrument | Brake | Tachograph | | √ | √ | √ | – | – | - |
| benz diesel | ATEGO III | Multifunction | CDS | Central data memory | | √ | √ | √ | √ | – | - |
| benz diesel | ATEGO III | Multifunction | CGW | Central gateway | | √ | √ | √ | √ | – | - |
| benz diesel | ATEGO III | Multifunction | COM | Communication Interface | | √ | √ | √ | √ | – | - |
| benz diesel | ATEGO III | Multifunction | CPC | Drive control | | √ | √ | √ | – | – | - |
| benz diesel | ATEGO III | Multifunction | EAPU | Knorr Bremse | | √ | √ | √ | √ | – | - |
| benz diesel | ATEGO III | Multifunction | MS | Maintenance System | | √ | √ | √ | √ | – | - |
| benz diesel | ATEGO III | Multifunction | PSM | Parameterable Special Module | | √ | √ | √ | √ | – | - |
| benz diesel | ATEGO III | Multifunction | SAS | Steering wheel angle sensor | | √ | √ | √ | – | – | - |
| benz diesel | ATEGO III | Multifunction | SRS | Supplemental restraint system control unit | | √ | √ | √ | – | – | - |
| benz diesel | ATEGO III | Multifunction | TCC | Radio | | √ | √ | √ | √ | √ | - |
| benz diesel | ATEGO III | Multifunction | TP | Telematics | | √ | √ | √ | – | – | - |
| benz diesel | ATEGO III | Gearbox | TCM | Transmission control | | √ | √ | √ | – | – | - |
| benz diesel | ATEGO III | Service Light RESET(SLR) | MS | Maintenance System | | √ | √ | √ | √ | – | - |
| benz diesel | ATEGO III | Suspension | CLCS | Air suspension | | √ | √ | √ | √ | – | - |
| benz diesel | Arocs | diesel | ACM | Exhaust aftertreatment | | √ | √ | √ | √ | – | - |
| benz diesel | Arocs | diesel | MCM | Engine Control | | √ | √ | √ | √ | – | - |
| benz diesel | Arocs | brake | EBS | Knorr bremse | | √ | √ | √ | √ | – | - |
| benz diesel | Arocs | brake | RCM | Retarder | | √ | √ | √ | √ | – | - |
| benz diesel | Arocs | Climate | HVAC | Climate control | | √ | √ | √ | √ | – | - |
| benz diesel | Arocs | Climate | ITH | Auxiliary heating | | √ | √ | √ | √ | – | - |
| benz diesel | Arocs | Instrument | Brake | ICUC | | √ | √ | √ | √ | – | - |
| benz diesel | Arocs | Instrument | Brake | Tachograph | | √ | √ | √ | – | – | - |
| benz diesel | Arocs | Multifunction | ASA | Auxiliary steering | | √ | √ | √ | √ | – | - |
| benz diesel | Arocs | Multifunction | CDS | Central data memory | | √ | √ | √ | √ | – | - |
| benz diesel | Arocs | Multifunction | CGW | Central gateway | | √ | √ | √ | √ | – | - |
| benz diesel | Arocs | Multifunction | COM | Communication Interface | | √ | √ | √ | √ | – | - |
| benz diesel | Arocs | Multifunction | CPC | Drive control | | √ | √ | √ | – | – | - |
| benz diesel | Arocs | Multifunction | DCMD | Driver Door Module | | √ | √ | √ | √ | √ | - |
| benz diesel | Arocs | Multifunction | DCMP | Passenger Door Module | | √ | √ | √ | √ | √ | - |
| benz diesel | Arocs | Multifunction | EAPU | Knorr Bremse | | √ | √ | √ | √ | – | - |
| benz diesel | Arocs | Multifunction | EIS | Electronic ignition lock | | √ | √ | √ | – | – | - |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | Arocs | Multifunction | MS | Maintenance System | | √ | √ | √ | √ | – | - |
| benz diesel | Arocs | Multifunction | MSF | Modularable Switch Module | | √ | √ | √ | √ | – | - |
| benz diesel | Arocs | Multifunction | PSM | Parameterable Special Module | | √ | √ | √ | √ | – | - |
| benz diesel | Arocs | Multifunction | SAS | Steering wheel angle sensor | | √ | √ | √ | – | – | - |
| benz diesel | Arocs | Multifunction | SCA | Radio | | √ | √ | √ | √ | – | - |
| benz diesel | Arocs | Multifunction | SCH | Frame signal acquisition and actuation module control unit | | √ | √ | √ | √ | – | - |
| benz diesel | Arocs | Multifunction | SRS | Supplemental restraint system control unit | | √ | √ | √ | – | – | - |
| benz diesel | Arocs | Multifunction | TCC | Radio | | √ | √ | √ | √ | – | - |
| benz diesel | Arocs | Multifunction | TP | Telematics | | √ | √ | √ | – | – | - |
| benz diesel | Arocs | Multifunction | TPM | Tyre pressure monitoring | | √ | √ | √ | √ | – | - |
| benz diesel | Arocs | Gearbox | TCM | Transmission control | | √ | √ | √ | – | – | - |
| benz diesel | Arocs | Service Light RESET(SLR) | MS | Maintenance System | | √ | √ | √ | √ | – | - |
| benz diesel | Arocs | Suspension | CLCS | Air suspension | | √ | √ | √ | √ | – | - |
| benz diesel | LK | MR | | | | √ | √ | √ | √ | √ | - |
| benz diesel | LK | FR | | | | √ | √ | √ | √ | – | - |
| benz diesel | LK | ABS | | | | √ | √ | √ | √ | √ | - |
| benz diesel | LK | TCO | | | | √ | √ | √ | √ | – | - |
| benz diesel | LK | PSM | | | | √ | √ | √ | √ | – | - |
| benz diesel | MK | MR | | | | √ | √ | √ | √ | √ | - |
| benz diesel | LK | PSM | | | | √ | √ | √ | √ | – | - |
| benz diesel | MK | MR | | | | √ | √ | √ | √ | √ | - |
| benz diesel | MK | FR | | | | √ | √ | √ | √ | – | - |
| benz diesel | MK | ABS | | | | √ | √ | √ | √ | √ | - |
| benz diesel | MK | TCO | | | | √ | √ | √ | √ | – | - |
| benz diesel | MK | PSM | | | | √ | √ | √ | √ | – | - |
| benz diesel | SK | MR | | | | √ | √ | √ | √ | √ | - |
| benz diesel | SK | FR | | | | √ | √ | √ | √ | – | - |
| benz diesel | SK | ABS | | | | √ | √ | √ | √ | √ | - |
| benz diesel | SK | TCO | | | | √ | √ | √ | √ | – | - |
| benz diesel | SK | PSM | | | | √ | √ | √ | √ | – | - |
| benz diesel | Unimog 405 | MR | | | | √ | √ | √ | √ | √ | - |
| benz diesel | Unimog 405 | ABS | | | | √ | √ | √ | √ | √ | - |
| benz diesel | Unimog 405 | INS | | | | √ | √ | √ | √ | – | √ |
| benz diesel | Unimog 405 | TCO | | | | √ | √ | √ | √ | – | - |
| benz diesel | Unimog 405 | GS | | | | √ | √ | √ | √ | – | - |
| benz diesel | Unimog 405 | KS | | | | √ | √ | √ | √ | – | - |
| benz diesel | Unimog 405 | FR | | | | √ | √ | √ | √ | √ | √ |
| benz diesel | Unimog 405 | PSM | | | | √ | √ | √ | √ | – | - |
| benz diesel | Unimog 405 | HYD | | | | √ | √ | √ | √ | – | - |
| benz diesel | Unimog 437 | MR | | | | √ | √ | √ | √ | √ | - |
| benz diesel | Unimog 437 | ABS | | | | √ | √ | √ | √ | √ | √ |
| benz diesel | Unimog 437 | GS | | | | √ | √ | √ | √ | – | - |
| benz diesel | Unimog 437 | KS | | | | √ | √ | √ | √ | – | - |
| benz diesel | Unimog 437 | FR | | | | √ | √ | √ | √ | √ | √ |
| benz diesel | Unimog 437 | PSM | | | | √ | √ | √ | √ | – | - |

# Diagnostic List Benz Diesel_v8.03

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System Types | Protocol Types | Systems | | | Function | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | Version Info. | Read Dtc | Clear Dtc | Read data | Action test | Remark (other functions) |
| benz diesel | Unimog 437 | INS | | | | √ | √ | √ | √ | - | √ |
| benz diesel | Unimog 437 | TCO | | | | √ | √ | √ | √ | - | - |
| benz diesel | Unimog 405050 | MR | | | | √ | √ | √ | √ | √ | - |
| benz diesel | Unimog 405050 | ABS | | | | √ | √ | √ | √ | √ | √ |
| benz diesel | Unimog 405050 | Drive control | | | | √ | √ | √ | √ | √ | √ |
| benz diesel | Unimog 405050 | INS | | | | √ | √ | √ | √ | - | √ |
| benz diesel | Unimog 405050 | TCO | | | | √ | √ | √ | √ | - | - |
| benz diesel | Zetros(949.016-949.167) | MR | | | | √ | √ | √ | √ | √ | - |
| benz diesel | Zetros(949.016-949.167) | HPS | | | | √ | √ | √ | √ | - | - |
| benz diesel | Zetros(949.016-949.167) | ABS | | | | √ | √ | √ | √ | √ | - |
| benz diesel | Zetros(949.016-949.167) | TCO | | | | √ | √ | √ | √ | - | - |
| benz diesel | Zetros(949.016-949.167) | PSM | | | | √ | √ | √ | √ | - | - |
| benz diesel | Zetros(949.016-949.167) | WS | | | | √ | √ | √ | √ | - | - |
| benz diesel | Zetros(949.016-949.167) | ZHE | | | | √ | √ | √ | √ | √ | - |
| benz diesel | Zetros(949.016-949.167) | DTCO | | | | √ | √ | √ | √ | - | - |
| benz diesel | Zetros(949.016-949.167) | FR | | | | √ | √ | √ | √ | √ | - |
| benz diesel | Zetros(949.016-949.167) | AGN | | | | √ | √ | √ | √ | - | - |