CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function		
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data			
Tractors	PIN prefix LV - USA	John Deere	5300	√	√	√	√	1	9.0L VGT Calibration	-
Tractors	PIN prefix LV - USA	John Deere	5400	√	√	√	√	2	Actuator Test	-
Tractors	PIN prefix LV - USA	John Deere	5400N	√	√	√	√	3	Air Throttle Actuator Learn Value Reset	-
Tractors	PIN prefix LV - USA	John Deere	5500	√	√	√	√	4	Clear Aftertreatment Latched DTC	-
Tractors	PIN prefix LV - USA	John Deere	5500N	√	√	√	√	5	Cold Climate Low Idle Calibration	-
Tractors	2WD or MFWD - North American	John Deere	6200	√	√	√	√	6	Communication Error Test	-
Tractors	2WD or MFWD	John Deere	6200L	√	√	√	√	7	Control Unit Information	-
Tractors	2WD or MFWD - North American	John Deere	6300	√	√	√	√	8	Cylinder Cutout Test	√
Tractors	2WD or MFWD	John Deere	6300L	√	√	√	√	9	Cylinder Electronic Compression Test	-
Tractors	2WD or MFWD - North American	John Deere	6400	√	√	√	√	10	Cylinder Misfire Test	-
Tractors	2WD or MFWD	John Deere	6400L	√	√	√	√	11	DEF Header Coolant Purge	-
Tractors	2WD or MFWD - North American	John Deere	6500	√	√	√	√	12	DEF Pump Diagnostic Test	-
Tractors	2WD or MFWD	John Deere	6500L	√	√	√	√	13	DEF Quantity Test	-
Tractors	4WD Articulated	John Deere	8570	√	√	√	√	14	Diagnostics Idle Shutdown Override	-
Tractors	4WD Articulated	John Deere	8770	√	√	√	√	15	DOC Calibration	-
Tractors	4WD Articulated	John Deere	8870	√	√	√	√	16	DOC Outlet Temperature Transient Test	-
Tractors	4WD Articulated	John Deere	8970	√	√	√	√	17	DPF Calibration	-
Tractors	4WD Articulated	John Deere	9100	√	√	√	√	18	EGR Valve Clean Test	-
Tractors	4WD Articulated	John Deere	9200	√	√	√	√	19	EGR Valve Learn Value Reset	-
Tractors	4WD Articulated	John Deere	9300	√	√	√	√	20	EGR Valve Recalibration	-
Tractors	4WD Articulated	John Deere	9400	√	√	√	√	21	Enable Low Pressure Fuel Pump	-
Tractors	2WD or MFWD	John Deere	7200	√	√	√	√	22	Engine Fan Speed Change Test	-
Tractors	2WD or MFWD	John Deere	7210	√	√	√	√	23	Engine Hourmeter	-
Tractors	2WD or MFWD	John Deere	7400	√	√	√	√	24	Engine Load Profile Information	-
Tractors	2WD or MFWD	John Deere	7410	√	√	√	√	25	Engine Overspeed Verification Test	-
Tractors	2WD or MFWD	John Deere	7600	√	√	√	√	26	Engine Speed Change Test	-
Tractors	2WD or MFWD	John Deere	7610	√	√	√	√	27	Exhaust Filter Product Improvement Program	-
Tractors	2WD or MFWD	John Deere	7700	√	√	√	√	28	Exhaust Temperature Management Test	-
Tractors	2WD or MFWD	John Deere	7710	√	√	√	√	29	Exhaust Throttle Actuator Learn Value Reset	-

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function		
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data			
Tractors	2WD or MFWD	John Deere	7800	√	√	√	√	30	Fuel Dosing Injector Test	-
Tractors	2WD or MFWD - PIN prefix RW - USA	John Deere	7810	√	√	√	√	31	Fuel Dosing Pump Diagnostic Test	-
Tractors	2WD or MFWD	John Deere	8100	√	√	√	√	32	Fuel Dosing System Air Purge	-
Tractors	2WD or MFWD	John Deere	8200	√	√	√	√	33	Fuel Pump Calibration	-
Tractors	2WD or MFWD	John Deere	8300	√	√	√	√	34	Fuel Rail Pressure Relief Valve Counter Reset	-
Tractors	2WD or MFWD	John Deere	8400	√	√	√	√	35	Harness Diagnostic Mode Test	-
Tractors	Tracks	John Deere	8100T	√	√	√	√	36	Injector Calibration	-
Tractors	Tracks	John Deere	8200T	√	√	√	√	37	Injector Cleaning Test	-
Tractors	Tracks	John Deere	8300T	√	√	√	√	38	Injector Cutout Test	-
Tractors	Tracks	John Deere	8400T	√	√	√	√	39	Internal Data Monitor	-
Tractors	2WD or MFWD - North American	John Deere	6110	√	√	√	√	40	OEM Variable Fan Speed Test	-
Tractors	2WD or MFWD - North American	John Deere	6210	√	√	√	√	41	Oxygen Sensor Calibration	-
Tractors	2WD or MFWD - North American	John Deere	6310	√	√	√	√	42	Regeneration Abort Source Identification Test	-
Tractors	2WD or MFWD - North American	John Deere	6410	√	√	√	√	43	SCR Catalyst Calibration	-
Tractors	2WD or MFWD	John Deere	6110L	√	√	√	√	44	Service Regeneration	√
Tractors	2WD or MFWD	John Deere	6210L	√	√	√	√	45	Soot Selection Tool	-
Tractors	2WD or MFWD	John Deere	6310L	√	√	√	√	46	Spark Cutout Test	-
Tractors	2WD or MFWD	John Deere	6410L	√	√	√	√	47	Throttle Calibration Tractor Applications	-
Tractor	Utility Construction	John Deere	2350	√	√	√	√	48	Tractor Torque Curve Change Test	-
Tractors	2WD or MFWD	John Deere	6510L	√	√	√	√	49	UEGO Sensor Calibration	-
Tractors	2WD or MFWD	John Deere	6310S	√	√	√	√	50	VGT Actuator Travel Range Test	-
Tractors	2WD or MFWD	John Deere	6410S	√	√	√	√	51	VGT Learn Value Reset	-
Tractors	2WD or MFWD	John Deere	6510S	√	√	√	√	52	VGT or Exhaust Throttle Learn Value Reset	-
Sprayers	Self-Propelled Sprayers PIN Prefix N0 or 1N0	John Deere	4700	√	√	√	√	53	View Non-Clearable DTCs	-
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	6610	√	√	√	√			
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	6710	√	√	√	√			
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	6810	√	√	√	√			
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	6910	√	√	√	√			

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	6650	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	6750	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	6850	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	6950	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	9976	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	9965	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	9935	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	9970	√	√	√	√	
Cotton Harvesting	Cotton Strippers	John Deere	7450	√	√	√	√	
Cotton Harvesting	Cotton Strippers	John Deere	7455	√	√	√	√	
Hay and Forage	Self-Propelled Windrowers XXXXXX - 180000	John Deere	4890	√	√	√	√	
Hay and Forage	Auger Platforms	John Deere	890	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5210	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5310	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5410	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5510	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5310N	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5510N	√	√	√	√	
Combines and Headers	Combines	John Deere	9410	√	√	√	√	
Combines and Headers	Combines	John Deere	9510	√	√	√	√	
Combines and Headers	Combines	John Deere	9610	√	√	√	√	
Combines and Headers	Combines	John Deere	CTS II	√	√	√	√	
Combines and Headers	Combines	John Deere	9400	√	√	√	√	
Combines and Headers	Combines	John Deere	9500	√	√	√	√	
Combines and Headers	Combines	John Deere	9600	√	√	√	√	
Combines and Headers	Combines	John Deere	CTS	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	492	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	493	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Combines and Headers	Corn Heads	John Deere	494	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	592	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	692	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	693	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	694	√	√	√	√	
Combines and Headers	Auger Platforms	John Deere	890	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	892	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	893	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	894	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	1092	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	1290	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	1291	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	1293	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	344	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	444	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	543	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	546	√	√	√	√	
Combines and Headers	Header Equipment	John Deere	642	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	643	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	644	√	√	√	√	
Combines and Headers	Header Equipment	John Deere	645	√	√	√	√	
Combines and Headers	Header Equipment	John Deere	842	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	843	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	844	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	1243	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Combines and Headers	Platforms	John Deere	915	√	√	√	√	
Combines and Headers	Platforms	John Deere	918	√	√	√	√	
Combines and Headers	Platforms	John Deere	920	√	√	√	√	
Combines and Headers	Platforms	John Deere	922	√	√	√	√	
Combines and Headers	Platforms	John Deere	925	√	√	√	√	
Combines and Headers	Platforms	John Deere	930	√	√	√	√	
Combines and Headers	Header Equipment	John Deere	213	√	√	√	√	
Combines and Headers	Header Equipment	John Deere	215	√	√	√	√	
Combines and Headers	Header Equipment	John Deere	216	√	√	√	√	
Combines and Headers	Header Equipment	John Deere	218	√	√	√	√	
Combines and Headers	Header Equipment	John Deere	220	√	√	√	√	
Combines and Headers	Header Equipment	John Deere	222	√	√	√	√	
Combines and Headers	Header Equipment	John Deere	224	√	√	√	√	
Combines and Headers	Header Equipment	John Deere	230	√	√	√	√	
Combines and Headers	Row-Crop Heads	John Deere	453A	√	√	√	√	
Combines and Headers	Row-Crop Heads	John Deere	454A	√	√	√	√	
Combines and Headers	Row-Crop Heads	John Deere	653A	√	√	√	√	
Combines and Headers	Row-Crop Heads	John Deere	654A	√	√	√	√	
Combines and Headers	Row-Crop Heads	John Deere	655A	√	√	√	√	
Combines and Headers	Row-Crop Heads	John Deere	853A	√	√	√	√	
Combines and Headers	Row-Crop Heads	John Deere	854A	√	√	√	√	
Combines and Headers	Row-Crop Heads	John Deere	1253A	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	443	√	√	√	√	
Combines and Headers	Row-Crop Heads	John Deere	453	√	√	√	√	
Combines and Headers	Row-Crop Heads	John Deere	454	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Combines and Headers	Row-Crop Heads	John Deere	554	√	√	√	√	
Combines and Headers	Row-Crop Heads	John Deere	654	√	√	√	√	
Combines and Headers	Row-Crop Heads	John Deere	853	√	√	√	√	
Sprayers	Self-Propelled Sprayers PIN Prefix N0 or 1N0	John Deere	6100	√	√	√	√	
Sprayers	Self-Propelled Sprayers PIN Prefix N0 or 1N0	John Deere	6500	√	√	√	√	
Sprayers	Self-Propelled Sprayers PIN Prefix N0 or 1N0	John Deere	6600	√	√	√	√	
Sprayers	Self-Propelled Sprayers PIN Prefix N0 or 1N0	John Deere	6700	√	√	√	√	
Sprayers	Self-Propelled Sprayers PIN Prefix N0 or 1N0	John Deere	6700S	√	√	√	√	
Planting and Seeding	Planters	John Deere	7200	√	√	√	√	
Planting and Seeding	Planters	John Deere	1700	√	√	√	√	
Planting and Seeding	Planters	John Deere	1710	√	√	√	√	
Planting and Seeding	Planters	John Deere	1720	√	√	√	√	
Planting and Seeding	Planters	John Deere	1730	√	√	√	√	
Planting and Seeding	Planters	John Deere	1750	√	√	√	√	
Planting and Seeding	Planters	John Deere	1760	√	√	√	√	
Planting and Seeding	Planters	John Deere	1770	√	√	√	√	
Planting and Seeding	Planters	John Deere	1780	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	1900	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	1810	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	466	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	566	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	446	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	456	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	546	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	556	√	√	√	√	
Hay and Forage	Square Balers	John Deere	100	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	1600A	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	945	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	955	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	520	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	540	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	620	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	640	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	720	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	725	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	740	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	840	√	√	√	√	
Tractors	2WD or MFWD - North American	John Deere	6405	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6605	√	√	√	√	
Tractors	2WD or MFWD	John Deere	7405	√	√	√	√	
Combines and Headers	Combines	John Deere	9500SH	√	√	√	√	
Combines and Headers	Combines	John Deere	9510SH	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	594	√	√	√	√	
Combines and Headers	Header Equipment	John Deere	914	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	456S	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Combines and Headers	Platforms	John Deere	924	√	√	√	√	
Combines and Headers	Platforms	John Deere	913	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	466S	√	√	√	√	
Combines and Headers	Combines XXXXXX - 695100	John Deere	9450	√	√	√	√	
Combines and Headers	Combines XXXXXX - 695100	John Deere	9550	√	√	√	√	
Combines and Headers	Combines XXXXXX - 695100	John Deere	9550SH	√	√	√	√	
Combines and Headers	Combines XXXXXX - 695100	John Deere	9650	√	√	√	√	
Combines and Headers	Combines XXXXXX - 695100	John Deere	9650CTS	√	√	√	√	
Combines and Headers	Combines PIN Prefix H0 - XXXXXX - 695100	John Deere	9650STS	√	√	√	√	
Combines and Headers	Combines PIN Prefix H0 - XXXXXX - 695100	John Deere	9750STS	√	√	√	√	
Tractors	Tracks	John Deere	9300T	√	√	√	√	
Tractors	Tracks	John Deere	9400T	√	√	√	√	
Combines and Headers	Pickup Platforms	John Deere	914P	√	√	√	√	
Excavator	Compact	John Deere	50ZTS	√	√	√	√	
Tractors	Tracks	John Deere	8110T	√	√	√	√	
Tractors	Tracks	John Deere	8210T	√	√	√	√	
Tractors	Tracks	John Deere	8310T	√	√	√	√	
Tractors	Tracks	John Deere	8410T	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8110	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8210	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8310	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8410	√	√	√	√	
Skid Steer	Loader	John Deere	240	√	√	√	√	
Skid Steer	Loader	John Deere	250	√	√	√	√	
Skid Steer	Loader	John Deere	260	√	√	√	√	
Skid Steer	Loader	John Deere	270	√	√	√	√	
Skid Steer	Loader	John Deere	3375	√	√	√	√	
Skid Steer	Loader	John Deere	4475	√	√	√	√	
Skid Steer	Loader	John Deere	5575	√	√	√	√	
Skid Steer	Loader	John Deere	6675	√	√	√	√	
Skid Steer	Loader	John Deere	7775	√	√	√	√	
Skid Steer	Loader	John Deere	8875	√	√	√	√	
Excavator	Compact	John Deere	27ZTS	√	√	√	√	
Excavator	Compact	John Deere	35ZTS	√	√	√	√	
Combines and Headers	Combines	John Deere	7721	√	√	√	√	
Mate. Hand Cut. and Shredders	Flail Shredders	John Deere	27	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Bale Ejectors	John Deere	30	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	33	√	√	√	√	
Hay and Forage	Bale Ejectors	John Deere	40	√	√	√	√	
Hay and Forage	Bale Ejectors	John Deere	42	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	44	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	48	√	√	√	√	
Hay and Forage	Side-Delivery Rakes	John Deere	54	√	√	√	√	
Hay and Forage	Side-Delivery Rakes	John Deere	64	√	√	√	√	
Hay and Forage	Side-Delivery Rakes	John Deere	74	√	√	√	√	
Hay and Forage	Side-Delivery Rakes	John Deere	75	√	√	√	√	
Hay and Forage	Side-Delivery Rakes	John Deere	660	√	√	√	√	
Hay and Forage	Side-Delivery Rakes	John Deere	670	√	√	√	√	
Hay and Forage	Side-Delivery Rakes	John Deere	671	√	√	√	√	
Combines and Headers	Combines	John Deere	3300	√	√	√	√	
Combines and Headers	Combines	John Deere	4400	√	√	√	√	
Combines and Headers	Combines	John Deere	4420	√	√	√	√	
Combines and Headers	Combines	John Deere	4425	√	√	√	√	
Combines and Headers	Combines	John Deere	4435	√	√	√	√	
Combines and Headers	Combines	John Deere	6600	√	√	√	√	
Combines and Headers	Combines	John Deere	6601	√	√	√	√	
Combines and Headers	Combines	John Deere	6602	√	√	√	√	
Combines and Headers	Combines	John Deere	6622	√	√	√	√	
Combines and Headers	Combines	John Deere	7700	√	√	√	√	
Combines and Headers	Combines	John Deere	7701	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Combines and Headers	Combines	John Deere	7720	√	√	√	√	
Combines and Headers	Combines	John Deere	7722	√	√	√	√	
Combines and Headers	Combines	John Deere	8820	√	√	√	√	
Combines and Headers	Draper Platforms	John Deere	925D	√	√	√	√	
Combines and Headers	Draper Platforms	John Deere	930D	√	√	√	√	
Combines and Headers	Draper Platforms	John Deere	936D	√	√	√	√	
Combines and Headers	Header Equipment	John Deere	212	√	√	√	√	
Combines and Headers	Header Equipment	John Deere	214	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	9900	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	9910	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	9920	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	9940	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	9950	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	9930	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	9960	√	√	√	√	
Cotton Harvesting	Cotton Strippers	John Deere	283	√	√	√	√	
Cotton Harvesting	Cotton Strippers	John Deere	484	√	√	√	√	
Cotton Harvesting	Cotton Strippers	John Deere	740	√	√	√	√	
Cotton Harvesting	Cotton Strippers	John Deere	7440	√	√	√	√	
Cotton Harvesting	Cotton Strippers	John Deere	7445	√	√	√	√	
Tillage	Disks	John Deere	115	√	√	√	√	
Tillage	Disks	John Deere	230	√	√	√	√	
Tillage	Disks	John Deere	330	√	√	√	√	
Tillage	Disks	John Deere	331	√	√	√	√	
Tillage	Disks	John Deere	555	√	√	√	√	
Tillage	Field Cultivators	John Deere	1000	√	√	√	√	
Tillage	Field Cultivators	John Deere	940	√	√	√	√	
Tillage	Field Cultivators	John Deere	1050	√	√	√	√	
Tillage	Field Cultivators	John Deere	1100	√	√	√	√	
Tillage	Front Mount Cultivators	John Deere	FM	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Sprayers	Self-Propelled Sprayers PIN Prefix N0 or 1N0	John Deere	600A	√	√	√	√	
Tillage	Moldboard Plows	John Deere	2000	√	√	√	√	
Tillage	Moldboard Plows	John Deere	2600	√	√	√	√	
Tillage	Moldboard Plows	John Deere	2800	√	√	√	√	
Tillage	Moldboard Plows	John Deere	3600	√	√	√	√	
Tillage	Moldboard Plows	John Deere	3700	√	√	√	√	
Tillage	Moldboard Plows	John Deere	4200	√	√	√	√	
Tillage	Mulch Tillers	John Deere	1700	√	√	√	√	
Tillage	Mulch Tillers	John Deere	1710	√	√	√	√	
Tillage	Mulch Tillers	John Deere	1710A	√	√	√	√	
Tillage	Rear Mount Cultivators	John Deere	RM	√	√	√	√	
Tillage	Roller Harrows	John Deere	950	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	85	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	725	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	835	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	A20	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	RA4	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	RR2	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	250	√	√	√	√	
Sprayers	Mounted Sprayers	John Deere	220	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	520	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	535	√	√	√	√	
Sprayers	Sprayers	John Deere	550	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	29B	√	√	√	√	
Tillage	Rippers	John Deere	955	√	√	√	√	
Tillage	Rippers	John Deere	910	√	√	√	√	
Mate. Hand Cut. and Shredders	Scrapers	John Deere	1510C	√	√	√	√	
Mate. Hand Cut. and Shredders	Scrapers	John Deere	1812C	√	√	√	√	
Mate. Hand Cut. and Shredders	Scrapers	John Deere	1814C	√	√	√	√	
Hay and Forage	Carted Wheel Rakes	John Deere	702	√	√	√	√	
Hay and Forage	Forage Blowers	John Deere	150	√	√	√	√	
Hay and Forage	Tedders	John Deere	731	√	√	√	√	
Hay and Forage	Tedders	John Deere	751	√	√	√	√	
Hay and Forage	Tedders	John Deere	752	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	710	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	720	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Mower Conditioners	John Deere	820	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	910	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	915	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	920	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	925	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	930	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	935	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	946	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	956	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	1217	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	1219	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	1326	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	1327	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	1350	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	1360	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	1380	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	1424	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	1460	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	1525	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	1600	√	√	√	√	
Hay and Forage	Mowers	John Deere	240	√	√	√	√	
Hay and Forage	Mowers	John Deere	260	√	√	√	√	
Hay and Forage	Mowers	John Deere	265	√	√	√	√	
Hay and Forage	Mowers	John Deere	270	√	√	√	√	
Hay and Forage	Mowers	John Deere	275	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Mowers	John Deere	350	√	√	√	√	
Hay and Forage	Mowers	John Deere	450	√	√	√	√	
Hay and Forage	Mowers	John Deere	3700	√	√	√	√	
Hay and Forage	Pull-Type Forage Harvesters	John Deere	3940	√	√	√	√	
Hay and Forage	Pull-Type Forage Harvesters	John Deere	3950	√	√	√	√	
Hay and Forage	Pull-Type Forage Harvesters	John Deere	3960	√	√	√	√	
Hay and Forage	Pull-Type Forage Harvesters	John Deere	3970	√	√	√	√	
Hay and Forage	Pull-Type Forage Harvesters	John Deere	4720	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	John Deere	704	√	√	√	√	
Mate. Hand Cut. and Shredders	Choppers	John Deere	16A	√	√	√	√	
Hay and Forage	Round Balers	John Deere	330	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	335	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	375	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	385	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	410	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	435	√	√	√	√	
Hay and Forage	Round Balers	John Deere	510	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	530	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	535	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	5200	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	5400	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	5440	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	5460	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	5720	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	5730	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	5820	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	5830	√	√	√	√	
Hay and Forage	Self-Propelled Windrowers XXXXXX - 180000	John Deere	2280	√	√	√	√	
Hay and Forage	Self-Propelled Windrowers XXXXXX - 180000	John Deere	2320	√	√	√	√	
Hay and Forage	Self-Propelled Windrowers XXXXXX - 180000	John Deere	2360	√	√	√	√	
Hay and Forage	Self-Propelled Windrowers XXXXXX - 180000	John Deere	2420	√	√	√	√	
Hay and Forage	Self-Propelled Windrowers XXXXXX - 180000	John Deere	3430	√	√	√	√	
Hay and Forage	Self-Propelled Windrowers XXXXXX - 180000	John Deere	3830	√	√	√	√	
Hay and Forage	Self-Propelled Windrowers XXXXXX - 180000	John Deere	4990	√	√	√	√	
Hay and Forage	Square Balers	John Deere	327	√	√	√	√	
Hay and Forage	Square Balers	John Deere	328	√	√	√	√	
Hay and Forage	Square Balers	John Deere	336	√	√	√	√	
Hay and Forage	Square Balers	John Deere	337	√	√	√	√	
Hay and Forage	Square Balers	John Deere	338	√	√	√	√	
Hay and Forage	Square Balers	John Deere	346	√	√	√	√	
Hay and Forage	Square Balers	John Deere	347	√	√	√	√	
Hay and Forage	Square Balers	John Deere	348	√	√	√	√	
Hay and Forage	Square Balers	John Deere	467	√	√	√	√	
Hay and Forage	Square Balers	John Deere	468	√	√	√	√	
Hay and Forage	Twin Rakes	John Deere	700	√	√	√	√	
Hay and Forage	Twin Rakes	John Deere	705	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Mate. Hand Cut. and Shredders	Loaders	John Deere	80	√	√	√	√	
Mate. Hand Cut. and Shredders	Feed Mixers	John Deere	127	√	√	√	√	
Mate. Hand Cut. and Shredders	Feed Mixers	John Deere	135	√	√	√	√	
Mate. Hand Cut. and Shredders	Feed Mixers	John Deere	152	√	√	√	√	
Mate. Hand Cut. and Shredders	Flail Mowers	John Deere	360	√	√	√	√	
Mate. Hand Cut. and Shredders	Flail Mowers	John Deere	370	√	√	√	√	
Mate. Hand Cut. and Shredders	Flail Mowers	John Deere	390	√	√	√	√	
Mate. Hand Cut. and Shredders	Flail Mowers	John Deere	25A	√	√	√	√	
Mate. Hand Cut. and Shredders	Flail Shredders	John Deere	115	√	√	√	√	
Mate. Hand Cut. and Shredders	Flail Shredders	John Deere	118	√	√	√	√	
Mate. Hand Cut. and Shredders	Flail Shredders	John Deere	120	√	√	√	√	
Mate. Hand Cut. and Shredders	Flail Shredders	John Deere	220	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	70	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	110	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	143	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	145	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	146	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Mate. Hand Cut. and Shredders	Loaders	John Deere	148	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	158	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	168	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	175	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	240	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	245	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	260	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	265	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	280	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	410	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	420	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	430	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	460	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	521	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	541	√	√	√	√	
Mate. Hand Cut. and Shredders	Rear Mounted Blades	John Deere	95	√	√	√	√	
Mate. Hand Cut. and Shredders	Rear Mounted Blades	John Deere	115	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Mate. Hand Cut. and Shredders	Rear Mounted Blades	John Deere	155	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	1408	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	403	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	503	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	506	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	509	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	527	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	603	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	606	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	609	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	707	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	709	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	1008	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	1018	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	1418	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	1508	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	1517	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	1518	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	2018	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	HX10	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	HX14	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	MX10	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	MX8	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	54	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	350	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	450	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	455	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	550	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	570	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	660	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	680	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	780	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	N	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	John Deere	700	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Mate. Hand Cut. and Shredders	Wagons	John Deere	720	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	John Deere	740	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	John Deere	770	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	John Deere	965	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	John Deere	1065	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	John Deere	1075	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	John Deere	1275	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	John Deere	1065A	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	730	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	735	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	737	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	775	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	777	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	787	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	1060	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	1820	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	1850	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	1860	√	√	√	√	
Planting and Seeding	Drills	John Deere	450	√	√	√	√	
Planting and Seeding	Drills	John Deere	455	√	√	√	√	
Planting and Seeding	Drills	John Deere	515	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Planting and Seeding	Drills	John Deere	520	√	√	√	√	
Planting and Seeding	Drills	John Deere	750	√	√	√	√	
Planting and Seeding	Drills	John Deere	1520	√	√	√	√	
Planting and Seeding	Drills	John Deere	1530	√	√	√	√	
Planting and Seeding	Drills	John Deere	1560	√	√	√	√	
Planting and Seeding	Drills	John Deere	1570	√	√	√	√	
Planting and Seeding	Drills	John Deere	8000	√	√	√	√	
Planting and Seeding	Drills	John Deere	8500	√	√	√	√	
Planting and Seeding	Drills	John Deere	9000	√	√	√	√	
Planting and Seeding	Drills	John Deere	9400	√	√	√	√	
Planting and Seeding	Monitor	John Deere	100	√	√	√	√	
Planting and Seeding	Monitor	John Deere	150	√	√	√	√	
Planting and Seeding	Monitor	John Deere	200	√	√	√	√	
Planting and Seeding	Monitor	John Deere	250	√	√	√	√	
Planting and Seeding	Monitor	John Deere	300	√	√	√	√	
Planting and Seeding	Planters	John Deere	7000	√	√	√	√	
Planting and Seeding	Planters	John Deere	7100	√	√	√	√	
Planting and Seeding	Planters	John Deere	7240	√	√	√	√	
Planting and Seeding	Planters	John Deere	7300	√	√	√	√	
Planting and Seeding	Planters	John Deere	7340	√	√	√	√	
Planting and Seeding	Unit Planters	John Deere	71 FLEXI	√	√	√	√	
Sprayers	Hooded Sprayers	John Deere	320	√	√	√	√	
Sprayers	Self-Propelled Sprayers PIN Prefix N0 or 1N0	John Deere	6000	√	√	√	√	
Tillage	Chisel Plows	John Deere	610	√	√	√	√	
Tillage	Chisel Plows	John Deere	680	√	√	√	√	
Tillage	Chisel Plows	John Deere	1610	√	√	√	√	
Tillage	Chisel Plows	John Deere	1650	√	√	√	√	
Tillage	Disk Rippers	John Deere	512	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tillage	Disks	John Deere	215	√	√	√	√	
Tillage	Disks	John Deere	225	√	√	√	√	
Tillage	Disks	John Deere	235	√	√	√	√	
Tillage	Disks	John Deere	335	√	√	√	√	
Tillage	Disks	John Deere	355	√	√	√	√	
Tillage	Disks	John Deere	425	√	√	√	√	
Tillage	Disks	John Deere	600	√	√	√	√	
Tillage	Disks	John Deere	620	√	√	√	√	
Tillage	Disks	John Deere	627	√	√	√	√	
Tillage	Disks	John Deere	630	√	√	√	√	
Tillage	Disk Plows	John Deere	635	√	√	√	√	
Tillage	Disks	John Deere	637	√	√	√	√	
Tillage	Disks	John Deere	640	√	√	√	√	
Tillage	Disks	John Deere	650	√	√	√	√	
Tillage	Disks	John Deere	670	√	√	√	√	
Tillage	Field Cultivators	John Deere	960	√	√	√	√	
Tillage	Field Cultivators	John Deere	980	√	√	√	√	
Tillage	Field Cultivators	John Deere	985	√	√	√	√	
Tillage	Field Cultivators	John Deere	1010	√	√	√	√	
Tillage	Field Cultivators	John Deere	1060	√	√	√	√	
Tillage	Moldboard Plows	John Deere	965	√	√	√	√	
Tillage	Moldboard Plows	John Deere	975	√	√	√	√	
Tillage	Moldboard Plows	John Deere	2700	√	√	√	√	
Tillage	Moldboard Plows	John Deere	2810	√	√	√	√	
Tillage	Moldboard Plows	John Deere	3710	√	√	√	√	
Tillage	Moldboard Plows	John Deere	3835	√	√	√	√	
Tillage	Moldboard Plows	John Deere	3955	√	√	√	√	
Tillage	Moldboard Plows	John Deere	4600	√	√	√	√	
Tillage	Mulch Finishers	John Deere	722	√	√	√	√	
Tillage	Mulch Finishers	John Deere	724	√	√	√	√	
Tillage	Mulch Finishers	John Deere	726	√	√	√	√	
Tillage	Mulch Masters	John Deere	550	√	√	√	√	
Tillage	Mulch Tillers	John Deere	710	√	√	√	√	
Tillage	Mulch Tillers	John Deere	712	√	√	√	√	
Tillage	Mulch Tillers	John Deere	714	√	√	√	√	
Tillage	Rippers	John Deere	22B	√	√	√	√	
Tillage	Rippers	John Deere	510	√	√	√	√	
Tillage	Rippers	John Deere	900	√	√	√	√	
Tillage	Rippers	John Deere	913	√	√	√	√	
Tillage	Rippers	John Deere	915	√	√	√	√	
Tillage	Rotary Hoes	John Deere	400	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	825	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	856	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	875	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	885	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	886	√	√	√	√	
Tractors	4WD Articulated	John Deere	8010	√	√	√	√	
Tractors	4WD Articulated	John Deere	8430	√	√	√	√	
Tractors	4WD Articulated	John Deere	8440	√	√	√	√	
Tractors	4WD Articulated	John Deere	8450	√	√	√	√	
Tractors	4WD Articulated	John Deere	8560	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractors	4WD Articulated	John Deere	8630	√	√	√	√	
Tractors	4WD Articulated	John Deere	8640	√	√	√	√	
Tractors	4WD Articulated	John Deere	8650	√	√	√	√	
Tractors	4WD Articulated	John Deere	8760	√	√	√	√	
Tractors	4WD Articulated	John Deere	8850	√	√	√	√	
Tractors	4WD Articulated	John Deere	8960	√	√	√	√	
Tractors	2WD or MFWD	John Deere	510	√	√	√	√	
Tractors	2WD or MFWD	John Deere	710	√	√	√	√	
Tractors	2WD or MFWD	John Deere	820	√	√	√	√	
Tractors	2WD or MFWD	John Deere	830	√	√	√	√	
Tractors	2WD or MFWD	John Deere	840	√	√	√	√	
Tractors	2WD or MFWD	John Deere	920	√	√	√	√	
Tractors	2WD or MFWD	John Deere	930	√	√	√	√	
Tractors	2WD or MFWD	John Deere	940	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1010	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1020	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1030	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1040	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1120	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1130	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1140	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1250	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1350	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1450	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1520	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1530	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1550	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1630	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1640	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1650	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1830	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1850	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1950	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2020	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2030	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2040	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2120	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2130	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2140	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2150	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2155	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2240	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2250	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2255	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2350	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2355	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2440	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2450	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2510	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2520	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2550	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractors	2WD or MFWD	John Deere	2555	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2630	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2640	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2650	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2750	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2755	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2840	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2850	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2855	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2940	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2950	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2955	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3010	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3020	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3030	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3040	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3055	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3130	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3140	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3150	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3155	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3255	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3350	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3640	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3650	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4000	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4010	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4020	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4030	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4040	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4050	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4055	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4230	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4240	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4250	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4255	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4320	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4430	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4440	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4450	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4455	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4520	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4555	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4560	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4620	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4630	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4640	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4650	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4755	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4760	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4840	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractors	2WD or MFWD	John Deere	4850	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4955	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4960	√	√	√	√	
Tractors	2WD or MFWD	John Deere	5010	√	√	√	√	
Tractors	2WD or MFWD	John Deere	5020	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6030	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6600	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6800	√	√	√	√	
Tractors	4WD Articulated	John Deere	7020	√	√	√	√	
Tractors	2WD or MFWD	John Deere	7510	√	√	√	√	
Tractors	4WD Articulated	John Deere	7520	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2040S	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2355N	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2855N	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4040L	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4040S	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4240L	√	√	√	√	
Tractors	2WD or MFWD	John Deere	4240S	√	√	√	√	
Hay and Forage	Row-Crop Harvesting Units	John Deere	2RRC	√	√	√	√	
Hay and Forage	3 Meter Pickups	John Deere	630	√	√	√	√	
Hay and Forage	3 Meter Pickups	John Deere	630A	√	√	√	√	
Hay and Forage	4.5 Meter Pickups	John Deere	645	√	√	√	√	
Hay and Forage	4.5 Meter Pickups	John Deere	645A	√	√	√	√	
Hay and Forage	Row-Crop Harvesting Units	John Deere	664	√	√	√	√	
Hay and Forage	Row-Crop Harvesting Units	John Deere	665R	√	√	√	√	
Hay and Forage	Row-Crop Harvesting Units	John Deere	666R	√	√	√	√	
Hay and Forage	Auger Platforms	John Deere	230	√	√	√	√	
Hay and Forage	Auger Platforms	John Deere	300	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5105	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5205	√	√	√	√	
Hay and Forage	Rotary Harvesting Units	John Deere	684	√	√	√	√	
Hay and Forage	Rotary Harvesting Units	John Deere	686	√	√	√	√	
Hay and Forage	Rotary Harvesting Units	John Deere	676	√	√	√	√	
Hay and Forage	Rotary Harvesting Units	John Deere	688	√	√	√	√	
Hay and Forage	Rotary Platforms	John Deere	990	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Round Baler Accumulators	John Deere	20	√	√	√	√	
Mate. Hand Cut. and Shredders	Choppers	John Deere	972	√	√	√	√	
Hay and Forage	Auger Platforms	John Deere	300A	√	√	√	√	
Hay and Forage	Auger Platforms	John Deere	300GS	√	√	√	√	
Hay and Forage	Bale Mover Feeders	John Deere	84	√	√	√	√	
Hay and Forage	Conditioners	John Deere	30	√	√	√	√	
Hay and Forage	Conditioners	John Deere	31	√	√	√	√	
Hay and Forage	Conditioners	John Deere	35	√	√	√	√	
Hay and Forage	Conditioners	John Deere	36	√	√	√	√	
Hay and Forage	Conditioners	John Deere	60	√	√	√	√	
Hay and Forage	Conditioners	John Deere	61	√	√	√	√	
Hay and Forage	Conditioners	John Deere	65	√	√	√	√	
Hay and Forage	Conditioners	John Deere	66	√	√	√	√	
Hay and Forage	Auger Platforms	John Deere	140	√	√	√	√	
Hay and Forage	Draper Platforms	John Deere	160	√	√	√	√	
Hay and Forage	Stalker Heads	John Deere	483	√	√	√	√	
Hay and Forage	Stalker Heads	John Deere	484	√	√	√	√	
Mate. Hand Cut. and Shredders	Grain Carts	John Deere	500	√	√	√	√	
OEM Engines	Diesel	John Deere	6105	√	√	√	√	
OEM Engines	Diesel	John Deere	6125	√	√	√	√	
OEM Engines	Diesel	John Deere	4045	√	√	√	√	
OEM Engines	Diesel	John Deere	6068	√	√	√	√	
OEM Engines	Diesel	John Deere	6081	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	467	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	467S	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	567	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	916	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Mower Conditioners	John Deere	926	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	936	√	√	√	√	
Combines and Headers	Rigid Platforms	John Deere	918R	√	√	√	√	
Combines and Headers	Rigid Platforms	John Deere	920R	√	√	√	√	
Combines and Headers	Rigid Platforms	John Deere	922R	√	√	√	√	
Combines and Headers	Rigid Platforms	John Deere	925R	√	√	√	√	
Combines and Headers	Rigid Platforms	John Deere	930R	√	√	√	√	
Combines and Headers	Flex Platform	John Deere	915F	√	√	√	√	
Combines and Headers	Flex Platform	John Deere	918F	√	√	√	√	
Combines and Headers	Flex Platform	John Deere	920F	√	√	√	√	
Combines and Headers	Flex Platform	John Deere	922F	√	√	√	√	
Combines and Headers	Flex Platform	John Deere	925F	√	√	√	√	
Combines and Headers	Flex Platform	John Deere	930F	√	√	√	√	
Planting and Seeding	Drills	John Deere	1535	√	√	√	√	
Planting and Seeding	Drills	John Deere	1565	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	MX5	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	MX6	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	MX7	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	447	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	457	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	547	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	557	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	457S	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6100	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6200	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractors	2WD or MFWD - European	John Deere	6300	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6400	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6100SE	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6200SE	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6300SE	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6400SE	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6506	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6900	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6010	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6110	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6210	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6310	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6410	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6510	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6610	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6810	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6910	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6010SE	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6110SE	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6210SE	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6310SE	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6410SE	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6510SE	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6610SE	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6205	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6505	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	6103	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	6203	√	√	√	√	
Tractors	2WD or MFWD - North American	John Deere	6403	√	√	√	√	
Tractors	2WD or MFWD - North American	John Deere	6603	√	√	√	√	
Sprayers	Self-Propelled Sprayers XXXXXX - 004000	John Deere	4710	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6910S	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3100	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3300	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3400	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3200X	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3300X	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3400X	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3110	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3210	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3310	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3410	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3210X	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3310X	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3410X	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Combines and Headers	Combines	John Deere	2054	√	√	√	√	
Combines and Headers	Combines	John Deere	2056	√	√	√	√	
Combines and Headers	Combines	John Deere	2058	√	√	√	√	
Combines and Headers	Combines	John Deere	2064	√	√	√	√	
Combines and Headers	Combines	John Deere	2066	√	√	√	√	
Combines and Headers	Combines	John Deere	2254	√	√	√	√	
Combines and Headers	Combines	John Deere	2256	√	√	√	√	
Combines and Headers	Combines	John Deere	2258	√	√	√	√	
Combines and Headers	Combines	John Deere	2264	√	√	√	√	
Combines and Headers	Combines	John Deere	2266	√	√	√	√	
Combines and Headers	Combines	John Deere	2266EXTRA	√	√	√	√	
Combines and Headers	Combines	John Deere	CTS Region II	√	√	√	√	
Combines and Headers	Combines	John Deere	1170	√	√	√	√	
Combines and Headers	Platforms	John Deere	814	√	√	√	√	
Combines and Headers	Platforms	John Deere	816	√	√	√	√	
Combines and Headers	Platforms	John Deere	818	√	√	√	√	
Combines and Headers	Platforms	John Deere	820	√	√	√	√	
Combines and Headers	Platforms	John Deere	825	√	√	√	√	
Combines and Headers	Platforms	John Deere	822	√	√	√	√	
Combines and Headers	Header Equipment	John Deere	593	√	√	√	√	
Hay and Forage	Row-Crop Harvesting Units	John Deere	666	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	1470	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	1355	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	1365	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	1465	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Mower Conditioners	John Deere	324	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	328	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	228	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	228A	√	√	√	√	
Hay and Forage	Square Balers	John Deere	339	√	√	√	√	
Hay and Forage	Square Balers	John Deere	349	√	√	√	√	
Hay and Forage	Square Balers	John Deere	359	√	√	√	√	
Hay and Forage	Square Balers	John Deere	459	√	√	√	√	
Hay and Forage	Round Balers	John Deere	540	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix CC	John Deere	545	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix CC	John Deere	550	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix CC	John Deere	570	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix CC	John Deere	580	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix CC	John Deere	590	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix CC	John Deere	565	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix CC	John Deere	575	√	√	√	√	
Hay and Forage	Square Balers	John Deere	680	√	√	√	√	
Hay and Forage	Square Balers	John Deere	690	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	540A	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	640A	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	740A	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	551	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	631	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Mate. Hand Cut. and Shredders	Loaders	John Deere	651	√	√	√	√	
Planting and Seeding	Drills	John Deere	740A	√	√	√	√	
Planting and Seeding	Drills	John Deere	750A	√	√	√	√	
Tillage	Mulch Tillers	John Deere	410A	√	√	√	√	
Tillage	Mulch Finishers	John Deere	420A	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	624	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	632	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	638	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	632TF	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	638TF	√	√	√	√	
Sprayers	Orchard Sprayers	John Deere	310	√	√	√	√	
Sprayers	Orchard Sprayers	John Deere	315	√	√	√	√	
Sprayers	Mounted Sprayers	John Deere	408	√	√	√	√	
Sprayers	Mounted Sprayers	John Deere	410	√	√	√	√	
Sprayers	Mounted Sprayers	John Deere	412	√	√	√	√	
Mate. Hand Cut. and Shredders	Telehandlers	John Deere	3200	√	√	√	√	
Mate. Hand Cut. and Shredders	Telehandlers	John Deere	3400	√	√	√	√	
Mate. Hand Cut. and Shredders	Telehandlers	John Deere	4400	√	√	√	√	
Mate. Hand Cut. and Shredders	Telehandlers	John Deere	4500	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	5415	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	5615	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	5715	√	√	√	√	
Combines and Headers	Platforms PIN Prefix CQ	John Deere	314	√	√	√	√	
Combines and Headers	Platforms	John Deere	316	√	√	√	√	
Tillage	Moldboard Plows	John Deere	995	√	√	√	√	
Tractors	PIN prefix CQ - Brazil	John Deere	5600	√	√	√	√	
Tractors	PIN prefix CQ - Brazil	John Deere	5700	√	√	√	√	
Combines and Headers	Combines	John Deere	1165	√	√	√	√	
Combines and Headers	Combines	John Deere	1175	√	√	√	√	
Excavator	Compact	John Deere	17ZTS	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
AG Management Solutions	Field Documentation	John Deere	AMS	√	√	√	√	
AG Management Solutions	GreenStar Yield Systems	John Deere	AMS	√	√	√	√	
AG Management Solutions	Parallel Tracking	John Deere	AMS	√	√	√	√	
AG Management Solutions	StarFire Position Receiver	John Deere	AMS	√	√	√	√	
Tractors	2WD or MFWD - Brazilian	John Deere	7500	√	√	√	√	
Mate. Hand Cut. and Shredders	Scrapers	John Deere	1312C	√	√	√	√	
Combines and Headers	Combines	John Deere	6620	√	√	√	√	
Combines and Headers	Combines XXXXXX - 072799	John Deere	9780CTS	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5220	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5320	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5420	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5520	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5320N	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5420N	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5520N	√	√	√	√	
OEM Engines	Diesel	John Deere	3029	√	√	√	√	
OEM Engines	Diesel	John Deere	4039	√	√	√	√	
OEM Engines	Diesel	John Deere	6059	√	√	√	√	
Tillage	Mulch Rippers	John Deere	2700	√	√	√	√	
Hay and Forage	Square Balers	John Deere	466	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	824	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	832	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	840	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8120	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8220	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8320	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8420	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8520	√	√	√	√	
Tractors	Tracks	John Deere	8120T	√	√	√	√	
Tractors	Tracks	John Deere	8220T	√	√	√	√	
Tractors	Tracks	John Deere	8320T	√	√	√	√	
Tractors	Tracks	John Deere	8420T	√	√	√	√	
Tractors	Tracks	John Deere	8520T	√	√	√	√	
Tractors	4WD Articulated	John Deere	9120	√	√	√	√	
Tractors	4WD Articulated	John Deere	9220	√	√	√	√	
Tractors	4WD Articulated	John Deere	9320	√	√	√	√	
Tractors	4WD Articulated	John Deere	9420	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractors	4WD Articulated	John Deere	9520	√	√	√	√	
Tractors	Tracks	John Deere	9320T	√	√	√	√	
Tractors	Tracks	John Deere	9420T	√	√	√	√	
Tractors	Tracks	John Deere	9520T	√	√	√	√	
Combines and Headers	Combines PIN Prefix H0 - 695101 - XXXXXX	John Deere	9650STS	√	√	√	√	
Combines and Headers	Combines 695101 - XXXXXX	John Deere	9650CTS	√	√	√	√	
Combines and Headers	Combines 695101 - XXXXXX	John Deere	9550SH	√	√	√	√	
Combines and Headers	Combines 695101 - XXXXXX	John Deere	9450	√	√	√	√	
Combines and Headers	Rigid Platforms PIN Prefix Z0 - European	John Deere	615R	√	√	√	√	
Combines and Headers	Rigid Platforms	John Deere	618R	√	√	√	√	
Combines and Headers	Rigid Platforms	John Deere	620R	√	√	√	√	
Combines and Headers	Combines PIN Prefix H0 - 695101 - XXXXXX	John Deere	9750STS	√	√	√	√	
Combines and Headers	Combines 695101 - XXXXXX	John Deere	9650	√	√	√	√	
Combines and Headers	Combines 695101 - XXXXXX	John Deere	9550	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6020	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6120	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6220	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6320	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6420	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6420S	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6520	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6620	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6820	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6920	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6920S	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6020SE	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6120SE	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6220SE	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6320SE	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6420SE	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6520SE	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6215	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6515	√	√	√	√	
Tractors	2WD or MFWD - North American	John Deere	6120	√	√	√	√	
Tractors	2WD or MFWD - North American	John Deere	6220	√	√	√	√	
Tractors	2WD or MFWD - North American	John Deere	6320	√	√	√	√	
Tractors	2WD or MFWD - North American	John Deere	6420	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractors	2WD or MFWD	John Deere	6120L	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6220L	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6320L	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6420L	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6520L	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6415	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6615	√	√	√	√	
Tillage	Rippers	John Deere	2100	√	√	√	√	
Sugar Cane Harvesters	Sugar Cane Combines - PIN Prefix T8 - Thibodaux	John Deere	2500	√	√	√	√	
Tillage	Disk Plows	John Deere	3635	√	√	√	√	
Tillage	Disk Plows	John Deere	3645	√	√	√	√	
Tillage	Disk Plows	John Deere	3745	√	√	√	√	
Tillage	Disk Plows	John Deere	3755	√	√	√	√	
Mate. Hand Cut. and Shredders	Telehandlers	John Deere	3800	√	√	√	√	
Planting and Seeding	Planters	John Deere	1760NT	√	√	√	√	
Tillage	Field Cultivators	John Deere	2200	√	√	√	√	
Tillage	Chisel Plows	John Deere	2400	√	√	√	√	
Combines and Headers	Combines PIN Prefix CQ - Brazil - XXXXXX - 047353	John Deere	1450CWS	√	√	√	√	
Combines and Headers	Combines PIN Prefix CQ - Brazil - XXXXXX - 047353	John Deere	1550CWS	√	√	√	√	
Combines and Headers	Combines PIN Prefix CQ - Brazil - XXXXXX - 047353	John Deere	1550	√	√	√	√	
Combines and Headers	Platforms	John Deere	312	√	√	√	√	
Combines and Headers	Rigid Platforms PIN Prefix Z0 - European	John Deere	614R	√	√	√	√	
Planting and Seeding	Planters - Pin Prefix P0	John Deere	MP25	√	√	√	√	
Combines and Headers	Platforms	John Deere	319	√	√	√	√	
Combines and Headers	Platforms	John Deere	323	√	√	√	√	
Tillage	Disks	John Deere	MX425	√	√	√	√	
Tillage	Disks	John Deere	660	√	√	√	√	
Tillage	Cultivator	John Deere	812	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix CC	John Deere	572	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix CC	John Deere	582	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix CC	John Deere	592	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Combines and Headers	Rigid Platforms	John Deere	625R	√	√	√	√	
Combines and Headers	Rigid Platforms	John Deere	630R	√	√	√	√	
Tractor Attachments	Backhoe	John Deere	47	√	√	√	√	
Tractor Attachments	Backhoe	John Deere	48	√	√	√	√	
Tractor Attachments	Backhoe	John Deere	49	√	√	√	√	
Combines and Headers	Combines PIN Prefix ZO - European	John Deere	9540	√	√	√	√	
Combines and Headers	Combines	John Deere	9560	√	√	√	√	
Combines and Headers	Combines PIN Prefix ZO - European	John Deere	9640	√	√	√	√	
Combines and Headers	Combines	John Deere	9660	√	√	√	√	
Combines and Headers	Combines PIN Prefix ZO - European	John Deere	9580	√	√	√	√	
Combines and Headers	Combines PIN Prefix ZO - European	John Deere	9680	√	√	√	√	
Sprayers	Mounted Sprayers	John Deere	508	√	√	√	√	
Sprayers	Mounted Sprayers	John Deere	510	√	√	√	√	
Sprayers	Mounted Sprayers	John Deere	512	√	√	√	√	
Tractors	PIN prefix CQ - Brazil	John Deere	5403	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix CQ - Brazil	John Deere	7810	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5103	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5203	√	√	√	√	
Combines and Headers	Combines PIN Prefix CQ - Brazil - XXXXXX - 047353	John Deere	1450	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2000	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2100	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2200	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2300	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2400	√	√	√	√	
Hay and Forage	Pull-Type Forage Harvesters	John Deere	3955	√	√	√	√	
Hay and Forage	Pull-Type Forage Harvesters	John Deere	3975	√	√	√	√	
Hay and Forage	Self-Propelled Windrowers XXXXXX - 180000	John Deere	4895	√	√	√	√	
Hay and Forage	Auger Platforms	John Deere	895	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5300	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5400	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5500	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5300N	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractors	PIN prefix AT - Italy	John Deere	5400N	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5500N	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5310	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5510N	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5310N	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5410N	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5410	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5510	√	√	√	√	
Combines and Headers	Combines	John Deere	1185	√	√	√	√	
Mate. Hand Cut. and Shredders	Flail Shredders	John Deere	112	√	√	√	√	
Planting and Seeding	Planters XXXXXX - 740100	John Deere	1770NT 16ROW	√	√	√	√	
Hay and Forage	Rotary Harvesting Units	John Deere	710	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix CC	John Deere	568	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix CC	John Deere	578	√	√	√	√	
Hay and Forage	Mower Conditioner	John Deere	331	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6403	√	√	√	√	
Combines and Headers	Flex Platform	John Deere	615F	√	√	√	√	
Combines and Headers	Flex Platform	John Deere	618F	√	√	√	√	
Combines and Headers	Flex Platform	John Deere	620F	√	√	√	√	
Combines and Headers	Flex Platform	John Deere	622F	√	√	√	√	
Combines and Headers	Flex Platform	John Deere	625F	√	√	√	√	
Combines and Headers	Flex Platform	John Deere	630F	√	√	√	√	
Skid Steer	Loader	John Deere	280	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6603	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	531	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	661	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	751	√	√	√	√	
Mate. Hand Cut. and Shredders	Scrapers	John Deere	1412E	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Mate. Hand Cut. and Shredders	Scrapers	John Deere	1810E	√	√	√	√	
Mate. Hand Cut. and Shredders	Scrapers	John Deere	1814E	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	75	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	100	√	√	√	√	
Combines and Headers	Combines	John Deere	9880STS	√	√	√	√	
Mate. Hand Cut. and Shredders	Grinder Mixers	John Deere	700	√	√	√	√	
Tractors	2WD or MFWD - Brazilian	John Deere	7505	√	√	√	√	
Hay and Forage	4 Meter Pickups	John Deere	640A	√	√	√	√	
Utility Vehicles	Gator Diesel	John Deere	6X4D	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	1207	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	1209	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	HX20	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	CX20	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	131	√	√	√	√	
Tractors	Compact Utility	John Deere	4210	√	√	√	√	
Tractors	Compact Utility	John Deere	4310	√	√	√	√	
Tractors	Compact Utility	John Deere	4410	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	419	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	9986	√	√	√	√	
Tractors	2WD or MFWD - Brazilian	John Deere	6405	√	√	√	√	
Tractors	2WD or MFWD - Brazilian	John Deere	6605	√	√	√	√	
Combines and Headers	Combines 072800 - XXXXXX	John Deere	9780CTS	√	√	√	√	
Hay and Forage	Mower Conditioners PIN Prefix EX	John Deere	730	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Mower Conditioners PIN Prefix EX	John Deere	735	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6215	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6715	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	1890	√	√	√	√	
Planting and Seeding	Drills	John Deere	1590	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	LX4	√	√	√	√	
Tractors	PIN prefix CQ - Brazil	John Deere	5605	√	√	√	√	
Tractors	PIN prefix CQ - Brazil	John Deere	5705	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ - Brasil - XXXX - 000180	John Deere	9650STS	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ - Brasil - XXXX - 000180	John Deere	9750STS	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	1690	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	LX5	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	LX6	√	√	√	√	
Planting and Seeding	Planters XXXXXX - 740100	John Deere	DB44	√	√	√	√	
Planting and Seeding	Planters XXXXXX - 740100	John Deere	DB60	√	√	√	√	
Planting and Seeding	Planters XXXXXX - 740100	John Deere	DB66	√	√	√	√	
Planting and Seeding	Planters 740101-745000	John Deere	DB80	√	√	√	√	
Excavator	Compact	John Deere	27CZTS	√	√	√	√	
Excavator	Compact	John Deere	35CZTS	√	√	√	√	
Excavator	Compact	John Deere	50CZTS	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	1910	√	√	√	√	
Mate. Hand Cut. and Shredders	Stack Wagons	John Deere	100	√	√	√	√	
Mate. Hand Cut. and Shredders	Stack Wagons	John Deere	200	√	√	√	√	
Hay and Forage	Forage Blowers	John Deere	100	√	√	√	√	
Planting and Seeding	Planters	John Deere	913	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2700	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractors	2WD or MFWD	John Deere	2800	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2900	√	√	√	√	
Mate. Hand Cut. and Shredders	Grinder Mixers	John Deere	750	√	√	√	√	
Tractors	Tractor Loader Backhoe	John Deere	110	√	√	√	√	
Hay and Forage	Self-Propelled Windrowers XXXXXX - 180000	John Deere	4995	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix RW - USA	John Deere	7220	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix RW - USA	John Deere	7320	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix RW - USA	John Deere	7420	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix RW - USA	John Deere	7520	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	7300	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	726	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	721	√	√	√	√	
Hay and Forage	Tedders	John Deere	754	√	√	√	√	
Hay and Forage	Tedders	John Deere	756	√	√	√	√	
Hay and Forage	Self-Propelled Windrowers	John Deere	994	√	√	√	√	
OEM Engines	CNG_LNG	John Deere	6081	√	√	√	√	
OEM Engines	CNG_LNG	John Deere	6068	√	√	√	√	
Planting and Seeding	Planters XXXXXX - 705100	John Deere	1790	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	HX15	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	741	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5310	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	210	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5403	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5303	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	7220	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	7320	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	7420	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	7520	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	510	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	824SE	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	832SE	√	√	√	√	
Tractors	2WD or MFWD	John Deere	5620	√	√	√	√	
Tractors	2WD or MFWD	John Deere	5720	√	√	√	√	
Tractors	2WD or MFWD	John Deere	5820	√	√	√	√	
Skid Steer	Loader	John Deere	240 Series II	√	√	√	√	
Skid Steer	Loader	John Deere	250 Series II	√	√	√	√	
Skid Steer	Loader	John Deere	260 Series II	√	√	√	√	
Skid Steer	Loader	John Deere	270 Series II	√	√	√	√	
Skid Steer	Loader	John Deere	280 Series II	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	1895	√	√	√	√	
Mate. Hand Cut. and Shredders	Material Handler	John Deere	560C	√	√	√	√	
Sprayers	Self-Propelled Sprayers 004001 - XXXXXX	John Deere	4710	√	√	√	√	
Tractors	2WD or MFWD	John Deere	6620SE	√	√	√	√	
Tillage	Moldboard Plows	John Deere	945	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix RW - USA	John Deere	7720	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix RW - USA	John Deere	7820	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix RW - USA	John Deere	7920	√	√	√	√	
AG Management Solutions	Terrain Compensation Module	John Deere	AMS	√	√	√	√	
Planting and Seeding	Planters XXXXXX - 740100	John Deere	DB58	√	√	√	√	
Planting and Seeding	Planters XXXXXX - 740100	John Deere	DB90	√	√	√	√	
Tillage	Disk Plows	John Deere	645	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
OEM Engines	Diesel	John Deere	4024	√	√	√	√	
OEM Engines	Diesel	John Deere	5030	√	√	√	√	
Combines and Headers	Combines PIN Prefix ZO - European	John Deere	9560	√	√	√	√	
Combines and Headers	Combines PIN Prefix ZO - European	John Deere	9660	√	√	√	√	
Combines and Headers	Combines PIN Prefix HO - North American	John Deere	9560STS	√	√	√	√	
Combines and Headers	Combines PIN Prefix HO - North American	John Deere	9660STS	√	√	√	√	
Combines and Headers	Combines PIN Prefix HO - North American	John Deere	9760STS	√	√	√	√	
Combines and Headers	Combines PIN Prefix HO - North American	John Deere	9860STS	√	√	√	√	
Commercial	Utility Vehicle	John Deere	AMT600	√	√	√	√	
Commercial	Utility Vehicle	John Deere	AMT622	√	√	√	√	
Commercial	Utility Vehicle	John Deere	AMT626	√	√	√	√	
Sugar Cane Harvesters	Sugar Cane Combines - PIN Prefix T8 - Thibodaux	John Deere	3500	√	√	√	√	
Worksite Pro Attachment	Backhoe	John Deere	960	√	√	√	√	
Worksite Pro Attachment	Angle Broom	John Deere	BA72	√	√	√	√	
Worksite Pro Attachment	Angle Broom	John Deere	BA84	√	√	√	√	
Worksite Pro Attachment	Pick-Up Broom	John Deere	BP72	√	√	√	√	
Worksite Pro Attachment	Pick-Up Broom	John Deere	BP84	√	√	√	√	
Worksite Pro Attachment	Pick-Up Broom	John Deere	BP72F	√	√	√	√	
Worksite Pro Attachment	Pick-Up Broom	John Deere	BP84F	√	√	√	√	
Combines and Headers	Combines	John Deere	9660CTS	√	√	√	√	
Tractors	2WD - Mexico	John Deere	5303	√	√	√	√	
Skid Steer	Loader	John Deere	375	√	√	√	√	
Skid Steer	Loader	John Deere	570	√	√	√	√	
Skid Steer	Loader	John Deere	575	√	√	√	√	
Planting and Seeding	Monitor	John Deere	350	√	√	√	√	
Planting and Seeding	Monitor	John Deere	450	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Planting and Seeding	Seedstar Gen 2 Monitor	John Deere	Seedstar	√	√	√	√	
Planting and Seeding	Seedstar Monitor	John Deere	Seedstar	√	√	√	√	
Planting and Seeding	Variable Rate Drive	John Deere	Seedstar	√	√	√	√	
Planting and Seeding	Variable Rate Fertilizer	John Deere	Seedstar	√	√	√	√	
Planting and Seeding	Mapped Based Seeding	John Deere	Seedstar	√	√	√	√	
Planting and Seeding	Seedstar Frame Control	John Deere	Seedstar	√	√	√	√	
Combines and Headers	Flex Platform	John Deere	635F	√	√	√	√	
Hay and Forage	Rotary Platforms	John Deere	995	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	746	√	√	√	√	
Worksite Pro Attachment	Auger Chain	John Deere	CA15	√	√	√	√	
Worksite Pro Attachment	Auger Chain	John Deere	CA25	√	√	√	√	
Worksite Pro Attachment	Auger Planetary	John Deere	PA15	√	√	√	√	
Worksite Pro Attachment	Auger Planetary	John Deere	PA30	√	√	√	√	
Worksite Pro Attachment	Breaker	John Deere	HB100 Series II	√	√	√	√	
Worksite Pro Attachment	Breaker	John Deere	HB15 Series II	√	√	√	√	
Mate. Hand Cut. and Shredders	Telehandlers	John Deere	3215	√	√	√	√	
Mate. Hand Cut. and Shredders	Telehandlers	John Deere	3415	√	√	√	√	
Mate. Hand Cut. and Shredders	Telehandlers	John Deere	3220	√	√	√	√	
Mate. Hand Cut. and Shredders	Telehandlers	John Deere	3420	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5215	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5315	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractors	PIN prefix AT - Italy	John Deere	5415	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5515	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5215F	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5315F	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5515F	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5615F	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5215V	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5315V	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5515V	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5615V	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5515HC	√	√	√	√	
Tillage	Chisel Plows	John Deere	2410	√	√	√	√	
Hay and Forage	3 Meter Pickups	John Deere	630B	√	√	√	√	
Hay and Forage	3 Meter Pickups	John Deere	640B	√	√	√	√	
Hay and Forage	3 Meter Pickups	John Deere	645B	√	√	√	√	
Combines and Headers	Combines	John Deere	1133	√	√	√	√	
Combines and Headers	Combines	John Deere	1144	√	√	√	√	
Combines and Headers	Combines	John Deere	1155	√	√	√	√	
Combines and Headers	Combines	John Deere	1157	√	√	√	√	
Combines and Headers	Combines	John Deere	1158	√	√	√	√	
Combines and Headers	Combines	John Deere	1166	√	√	√	√	
Combines and Headers	Combines	John Deere	1169H	√	√	√	√	
Combines and Headers	Combines	John Deere	1174	√	√	√	√	
Combines and Headers	Combines	John Deere	1177	√	√	√	√	
Combines and Headers	Combines	John Deere	1188	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1750	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1850N	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1950N	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1445F	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1745F	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1845F	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2345F	√	√	√	√	
Combines and Headers	Combines	John Deere	360	√	√	√	√	
Combines and Headers	Combines	John Deere	330	√	√	√	√	
Combines and Headers	Combines	John Deere	430	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Combines and Headers	Combines	John Deere	530	√	√	√	√	
Combines and Headers	Combines	John Deere	630	√	√	√	√	
Combines and Headers	Combines	John Deere	730	√	√	√	√	
Combines and Headers	Combines	John Deere	925	√	√	√	√	
Tractors	2WD or MFWD	John Deere	2650N	√	√	√	√	
Combines and Headers	Combines	John Deere	935	√	√	√	√	
Combines and Headers	Combines	John Deere	945	√	√	√	√	
Combines and Headers	Combines	John Deere	955	√	√	√	√	
Combines and Headers	Combines	John Deere	975	√	√	√	√	
Combines and Headers	Combines	John Deere	1065	√	√	√	√	
Combines and Headers	Combines	John Deere	1075	√	√	√	√	
Combines and Headers	Combines	John Deere	1068H	√	√	√	√	
Combines and Headers	Combines	John Deere	1072	√	√	√	√	
Combines and Headers	Combines	John Deere	1085	√	√	√	√	
Tillage	Field Cultivators	John Deere	2210	√	√	√	√	
Combines and Headers	Combines PIN Prefix YC - China	John Deere	1042	√	√	√	√	
Combines and Headers	Combines	John Deere	1032	√	√	√	√	
Combines and Headers	Combines	John Deere	1052	√	√	√	√	
Combines and Headers	Combines	John Deere	1055	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1960N	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3120	√	√	√	√	
Combines and Headers	Platforms	John Deere	810	√	√	√	√	
Combines and Headers	Platforms	John Deere	812	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1840	√	√	√	√	
Combines and Headers	Platforms	John Deere	812SH	√	√	√	√	
Combines and Headers	Platforms	John Deere	816SH	√	√	√	√	
Skid Steer	Loader	John Deere	675	√	√	√	√	
Skid Steer	Loader	John Deere	675B	√	√	√	√	
Combines and Headers	Combines	John Deere	40	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Combines and Headers	Header Equipment	John Deere	40	√	√	√	√	
Combines and Headers	Combines	John Deere	42	√	√	√	√	
Combines and Headers	Combines	John Deere	44	√	√	√	√	
Combines and Headers	Combines	John Deere	45	√	√	√	√	
Combines and Headers	Combines	John Deere	55	√	√	√	√	
Combines and Headers	Combines	John Deere	65	√	√	√	√	
Combines and Headers	Combines	John Deere	95	√	√	√	√	
Combines and Headers	Combines	John Deere	105	√	√	√	√	
Combines and Headers	Combines	John Deere	932	√	√	√	√	
Combines and Headers	Combines	John Deere	952	√	√	√	√	
Combines and Headers	Combines	John Deere	968H	√	√	√	√	
Combines and Headers	Combines	John Deere	985	√	√	√	√	
Combines and Headers	Combines	John Deere	965H	√	√	√	√	
AG Management Solutions	StarFire RTK - Real Time Kinematic	John Deere	AMS	√	√	√	√	
Sprayers	Self-Propelled Sprayers PIN Prefix NO or 1NO	John Deere	4920	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	7400	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	7500	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	7700	√	√	√	√	
Planting and Seeding	Planters XXXXXX - 740100	John Deere	1770NT 12ROW	√	√	√	√	
Planting and Seeding	Planters XXXXXX - 740100	John Deere	1770NT 24ROW	√	√	√	√	
Planting and Seeding	Planters 705101 - 740100	John Deere	1790	√	√	√	√	
Tractors	Compact Utility	John Deere	850	√	√	√	√	
Tractors	Compact Utility	John Deere	950	√	√	√	√	
Tractors	Compact Utility	John Deere	1050	√	√	√	√	
OEM Engines	Diesel	John Deere	6076	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	A2	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	T2	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	T4	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tillage	Row-Crop Cultivators	John Deere	AT20	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	AT40	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	AT630	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	A4	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	499	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	699	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	244	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	343	√	√	√	√	
Hay and Forage	Forage Harvesters	John Deere	34	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	251	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	1550	√	√	√	√	
Hay and Forage	Windrowers	John Deere	2250	√	√	√	√	
Hay and Forage	Windrowers	John Deere	2270	√	√	√	√	
Tillage	Disks	John Deere	210	√	√	√	√	
Tillage	Disks	John Deere	220	√	√	√	√	
Hay and Forage	Round Balers	John Deere	224	√	√	√	√	
Hay and Forage	Balers	John Deere	24	√	√	√	√	
Hay and Forage	Balers	John Deere	24T	√	√	√	√	
Hay and Forage	Balers	John Deere	24WS	√	√	√	√	
Hay and Forage	Forage Harvesters	John Deere	25	√	√	√	√	
Hay and Forage	Mowers	John Deere	250	√	√	√	√	
Hay and Forage	Windrowers	John Deere	290	√	√	√	√	
Hay and Forage	Forage Harvesters	John Deere	3	√	√	√	√	
Hay and Forage	Mowers	John Deere	310H	√	√	√	√	
Hay and Forage	Mowers	John Deere	310M	√	√	√	√	
Hay and Forage	Balers	John Deere	323W	√	√	√	√	
Hay and Forage	Forage Harvesters	John Deere	35	√	√	√	√	
Hay and Forage	Forage Harvesters	John Deere	38	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Forage Harvesters	John Deere	3800	√	√	√	√	
Tillage	Harvester	John Deere	430	√	√	√	√	
Tillage	Beet Harvesters	John Deere	4300	√	√	√	√	
Tillage	Beet Harvesters	John Deere	4310	√	√	√	√	
Tillage	Beet Harvesters	John Deere	4310A	√	√	√	√	
Hay and Forage	Mowers	John Deere	47	√	√	√	√	
Hay and Forage	Mowers	John Deere	4	√	√	√	√	
Hay and Forage	Mower Conditioner	John Deere	37	√	√	√	√	
Hay and Forage	Mower Conditioner	John Deere	38	√	√	√	√	
Hay and Forage	Mower Conditioner	John Deere	39	√	√	√	√	
Combines and Headers	Combines	John Deere	96	√	√	√	√	
Hay and Forage	Mower Conditioner	John Deere	483	√	√	√	√	
Hay and Forage	Mower Conditioner	John Deere	485	√	√	√	√	
Hay and Forage	Mowers	John Deere	5	√	√	√	√	
Hay and Forage	Forage Blowers	John Deere	50	√	√	√	√	
Hay and Forage	Mowers	John Deere	50	√	√	√	√	
Hay and Forage	Round Balers	John Deere	500	√	√	√	√	
Hay and Forage	Forage Blowers	John Deere	55	√	√	√	√	
Tillage	Disks	John Deere	950	√	√	√	√	
Tillage	Disks	John Deere	970	√	√	√	√	
Tractor Attachments	Cultivator	John Deere	11	√	√	√	√	
Tractors	2WD or MFWD	John Deere	50	√	√	√	√	
Tractors	2WD or MFWD	John Deere	60	√	√	√	√	
Tractors	2WD or MFWD	John Deere	70	√	√	√	√	
Tractors	2WD or MFWD	John Deere	520	√	√	√	√	
Tractors	2WD or MFWD	John Deere	620	√	√	√	√	
Tractors	2WD or MFWD	John Deere	630	√	√	√	√	
Tractors	Compact Utility	John Deere	650	√	√	√	√	
Tractors	Compact Utility	John Deere	750	√	√	√	√	
Tractors	2WD or MFWD	John Deere	720	√	√	√	√	
Tractors	2WD or MFWD	John Deere	MI	√	√	√	√	
Tractors	2WD or MFWD	John Deere	A	√	√	√	√	
Tractors	2WD or MFWD	John Deere	AH	√	√	√	√	
Tractors	2WD or MFWD	John Deere	GH	√	√	√	√	
Tractors	2WD or MFWD	John Deere	AR	√	√	√	√	
Tractors	2WD or MFWD	John Deere	AO	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractors	2WD or MFWD	John Deere	B	√	√	√	√	
Tractors	2WD or MFWD	John Deere	BR	√	√	√	√	
Tractors	2WD or MFWD	John Deere	BO	√	√	√	√	
Tractors	2WD or MFWD	John Deere	G	√	√	√	√	
Tractors	2WD or MFWD	John Deere	GM	√	√	√	√	
Tractors	2WD or MFWD	John Deere	H	√	√	√	√	
Tractors	2WD or MFWD	John Deere	JD500	√	√	√	√	
Tractors	2WD or MFWD	John Deere	JD600	√	√	√	√	
Tractors	2WD or MFWD	John Deere	JD700	√	√	√	√	
Tractors	2WD or MFWD	John Deere	M	√	√	√	√	
Tractors	2WD or MFWD	John Deere	MC	√	√	√	√	
Tractors	2WD or MFWD	John Deere	MC-1000	√	√	√	√	
Tractors	2WD or MFWD	John Deere	MI7	√	√	√	√	
Tractors	2WD or MFWD	John Deere	MT	√	√	√	√	
Tractors	2WD or MFWD	John Deere	R	√	√	√	√	
Tractors	2WD or MFWD - North American	John Deere	730	√	√	√	√	
Tractors	2WD or MFWD	John Deere	80	√	√	√	√	
Hay and Forage	Mower Conditioner	John Deere	480	√	√	√	√	
Combines and Headers	Attachments	John Deere	10	√	√	√	√	
Combines and Headers	None	John Deere	100	√	√	√	√	
Combines and Headers	None	John Deere	101	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	12	√	√	√	√	
Combines and Headers	None	John Deere	120	√	√	√	√	
Combines and Headers	None	John Deere	127	√	√	√	√	
Combines and Headers	Combines	John Deere	25	√	√	√	√	
Combines and Headers	Combines	John Deere	30	√	√	√	√	
Combines and Headers	Combines	John Deere	12A	√	√	√	√	
Combines and Headers	None	John Deere	18	√	√	√	√	
Combines and Headers	Combines	John Deere	200	√	√	√	√	
Combines and Headers	Attachments	John Deere	205	√	√	√	√	
Combines and Headers	Attachments	John Deere	210	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	122	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	22	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Combines and Headers	None	John Deere	226	√	√	√	√	
Combines and Headers	None	John Deere	227	√	√	√	√	
Combines and Headers	Attachments	John Deere	235	√	√	√	√	
Combines and Headers	None	John Deere	237	√	√	√	√	
Combines and Headers	None	John Deere	277	√	√	√	√	
Combines and Headers	Attachments	John Deere	313	√	√	√	√	
Combines and Headers	Header Equipment	John Deere	50	√	√	√	√	
Combines and Headers	Header Equipment	John Deere	50A	√	√	√	√	
Combines and Headers	Attachments	John Deere	K	√	√	√	√	
Combines and Headers	Combines	John Deere	106	√	√	√	√	
Combines and Headers	Combines	John Deere	95H	√	√	√	√	
Combines and Headers	Attachments	John Deere	N	√	√	√	√	
Hay and Forage	Mowers	John Deere	10	√	√	√	√	
Hay and Forage	Balers	John Deere	10	√	√	√	√	
Tillage	Harvester	John Deere	100	√	√	√	√	
Hay and Forage	Balers	John Deere	116W	√	√	√	√	
Hay and Forage	Forage Harvesters	John Deere	12	√	√	√	√	
Combines and Headers	Combines	John Deere	111	√	√	√	√	
Combines and Headers	Attachments	John Deere	234	√	√	√	√	
Combines and Headers	Combines	John Deere	277	√	√	√	√	
Combines and Headers	None	John Deere	237A	√	√	√	√	
Combines and Headers	Attachments	John Deere	410	√	√	√	√	
Hay and Forage	Mowers	John Deere	11	√	√	√	√	
Combines and Headers	Pickup Platforms	John Deere	110	√	√	√	√	
Combines and Headers	Pickup Platforms	John Deere	132	√	√	√	√	
Combines and Headers	Pickup Platforms	John Deere	154	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Mower Conditioners	John Deere	1214	√	√	√	√	
Hay and Forage	Balers	John Deere	124W	√	√	√	√	
Hay and Forage	Draper Platforms	John Deere	130	√	√	√	√	
Planting and Seeding	Planters	John Deere	1300	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	1320	√	√	√	√	
Hay and Forage	Draper Platforms	John Deere	135	√	√	√	√	
Hay and Forage	Balers	John Deere	14T	√	√	√	√	
Hay and Forage	Balers	John Deere	214T	√	√	√	√	
Cotton Harvesting	Harvester	John Deere	15	√	√	√	√	
Hay and Forage	Windrowers	John Deere	190	√	√	√	√	
Hay and Forage	Bale Ejectors	John Deere	2	√	√	√	√	
Hay and Forage	Row-Crop Cultivators	John Deere	2	√	√	√	√	
Hay and Forage	Row-Crop Cultivators	John Deere	3	√	√	√	√	
Hay and Forage	Mowers	John Deere	20	√	√	√	√	
Hay and Forage	Harvester	John Deere	200	√	√	√	√	
Combines and Headers	Platforms	John Deere	200	√	√	√	√	
Combines and Headers	Harvester	John Deere	200A	√	√	√	√	
Hay and Forage	Conditioners	John Deere	21	√	√	√	√	
Hay and Forage	Balers	John Deere	214	√	√	√	√	
Hay and Forage	Balers	John Deere	214W	√	√	√	√	
Hay and Forage	Windrowers	John Deere	215	√	√	√	√	
Hay and Forage	Balers	John Deere	216	√	√	√	√	
Hay and Forage	Conditioners	John Deere	218	√	√	√	√	
Hay and Forage	Draper Platforms	John Deere	218	√	√	√	√	
Hay and Forage	Conditioners	John Deere	22	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Conditioners	John Deere	32	√	√	√	√	
Tillage	Harvester	John Deere	223	√	√	√	√	
Hay and Forage	Swath Fluffer	John Deere	3	√	√	√	√	
Hay and Forage	Self-Propelled Windrowers	John Deere	215A	√	√	√	√	
Hay and Forage	Mowers	John Deere	20A	√	√	√	√	
Hay and Forage	Windrowers	John Deere	580	√	√	√	√	
Hay and Forage	Forage Blowers	John Deere	60C	√	√	√	√	
Hay and Forage	Forage Blowers	John Deere	60H	√	√	√	√	
Hay and Forage	Choppers	John Deere	62	√	√	√	√	
Hay and Forage	Harvester	John Deere	64	√	√	√	√	
Hay and Forage	Harvester	John Deere	692	√	√	√	√	
Hay and Forage	Harvester	John Deere	694	√	√	√	√	
Hay and Forage	Harvester	John Deere	72	√	√	√	√	
Hay and Forage	Harvester	John Deere	74	√	√	√	√	
Hay and Forage	Self-Propelled Windrowers	John Deere	780	√	√	√	√	
Hay and Forage	Mowers	John Deere	8	√	√	√	√	
Hay and Forage	Mowers	John Deere	8W	√	√	√	√	
Hay and Forage	Self-Propelled Windrowers	John Deere	800	√	√	√	√	
Hay and Forage	Self-Propelled Windrowers	John Deere	830	√	√	√	√	
Hay and Forage	Balers	John Deere	840	√	√	√	√	
Combines and Headers	Pickup Platforms	John Deere	88	√	√	√	√	
Hay and Forage	Windrowers	John Deere	880	√	√	√	√	
Hay and Forage	Mowers	John Deere	9	√	√	√	√	
Hay and Forage	Mowers	John Deere	9W	√	√	√	√	
Hay and Forage	Harvester	John Deere	AT246	√	√	√	√	
Cotton Harvesting	Cotton Strippers	John Deere	282	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Cotton Harvesting	Cotton Pickers	John Deere	299	√	√	√	√	
Cotton Harvesting	Cotton Strippers	John Deere	482	√	√	√	√	
Planting and Seeding	Planters	John Deere	493A	√	√	√	√	
Planting and Seeding	Planters	John Deere	494A	√	√	√	√	
Planting and Seeding	Planters	John Deere	495	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	1	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	11	√	√	√	√	
Cotton Harvesting	Cotton Strippers	John Deere	277	√	√	√	√	
Cotton Harvesting	Cotton Strippers	John Deere	33	√	√	√	√	
Cotton Harvesting	Cotton Strippers	John Deere	280	√	√	√	√	
Planting and Seeding	Planters	John Deere	494	√	√	√	√	
Cotton Harvesting	Cotton Strippers	John Deere	77	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	8	√	√	√	√	
Hay and Forage	Row-Crop Cultivators	John Deere	1	√	√	√	√	
Hay and Forage	Row-Crop Cultivators	John Deere	4	√	√	√	√	
Tillage	Disks	John Deere	100	√	√	√	√	
Tillage	Chisel Plows	John Deere	100	√	√	√	√	
Tillage	Moldboard Plows	John Deere	1000	√	√	√	√	
Tillage	Chisel Plows	John Deere	1001	√	√	√	√	
Tillage	Chisel Plows	John Deere	100 I	√	√	√	√	
Tillage	Chisel Plows	John Deere	100 IFH	√	√	√	√	
Tillage	Chisel Plows	John Deere	100 IRC	√	√	√	√	
Tillage	Plows	John Deere	100K	√	√	√	√	
Tillage	Plows	John Deere	100C	√	√	√	√	
Tillage	Plows	John Deere	101A	√	√	√	√	
Hay and Forage	Rotary Cutters	John Deere	105	√	√	√	√	
Tillage	Disks	John Deere	105	√	√	√	√	
Tillage	Disks	John Deere	110	√	√	√	√	
Tillage	Disks	John Deere	111	√	√	√	√	
Planting and Seeding	Planters	John Deere	112	√	√	√	√	
Planting and Seeding	Planters	John Deere	212	√	√	√	√	
Planting and Seeding	Attachments	John Deere	112C	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Planting and Seeding	Attachments	John Deere	118C	√	√	√	√	
Planting and Seeding	Attachments	John Deere	123C	√	√	√	√	
Tillage	Plows	John Deere	AU4	√	√	√	√	
Tillage	Moldboard Plows	John Deere	1250	√	√	√	√	
Tillage	Rotary Hoes	John Deere	12	√	√	√	√	
Tillage	Rotary Hoes	John Deere	14	√	√	√	√	
Tillage	Tiller	John Deere	1200	√	√	√	√	
Planting and Seeding	Planters	John Deere	1240	√	√	√	√	
Planting and Seeding	Planters	John Deere	1250	√	√	√	√	
Planting and Seeding	Planters	John Deere	1260	√	√	√	√	
Planting and Seeding	Planters	John Deere	1280	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	127	√	√	√	√	
Planting and Seeding	Planters	John Deere	1290	√	√	√	√	
Tillage	Moldboard Plows	John Deere	1350	√	√	√	√	
Tillage	Moldboard Plows	John Deere	1450	√	√	√	√	
Tillage	Moldboard Plows	John Deere	2350	√	√	√	√	
Tillage	Moldboard Plows	John Deere	2450	√	√	√	√	
Tillage	Moldboard Plows	John Deere	135A	√	√	√	√	
Tillage	Moldboard Plows	John Deere	145A	√	√	√	√	
Tillage	Tiller	John Deere	1400	√	√	√	√	
Tillage	Tiller	John Deere	2400	√	√	√	√	
Planting and Seeding	Planters	John Deere	1400	√	√	√	√	
Attachment	Feed Mixers	John Deere	114A	√	√	√	√	
Attachment	Feed Mixers	John Deere	110A	√	√	√	√	
Attachment	Feed Mixers	John Deere	110	√	√	√	√	
Tillage	Moldboard Plows	John Deere	1150	√	√	√	√	
Tillage	Moldboard Plows	John Deere	15	√	√	√	√	
Tillage	Chisel Plows	John Deere	1600	√	√	√	√	
Tillage	Moldboard Plows	John Deere	1600	√	√	√	√	
Tillage	Chisel Plows	John Deere	1600M	√	√	√	√	
Tillage	Air Seeders	John Deere	1500	√	√	√	√	
Tillage	Disks	John Deere	1630	√	√	√	√	
Tillage	Disks	John Deere	1640	√	√	√	√	
Tillage	Tiller	John Deere	1900	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	20	√	√	√	√	
Tillage	Disks	John Deere	1635	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	200	√	√	√	√	
Mate. Hand Cut. and Shredders	Choppers	John Deere	15A	√	√	√	√	
Tillage	Attachment	John Deere	200B	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tillage	Tiller	John Deere	1700	√	√	√	√	
Planting and Seeding	Planters	John Deere	18	√	√	√	√	
Tillage	Tiller	John Deere	1800	√	√	√	√	
Planting and Seeding	Attachments	John Deere	200	√	√	√	√	
Planting and Seeding	Attachments	John Deere	300	√	√	√	√	
Tillage	Scrapers	John Deere	200	√	√	√	√	
Tillage	Plows	John Deere	200	√	√	√	√	
Tillage	Disks	John Deere	200A-H	√	√	√	√	
Tillage	Disks	John Deere	220A-H	√	√	√	√	
Tillage	Disks	John Deere	300B-H	√	√	√	√	
Tillage	Disks	John Deere	400B-H	√	√	√	√	
Tillage	Disks	John Deere	470B-H	√	√	√	√	
Tillage	Chisel Plows	John Deere	200F	√	√	√	√	
Attachment	Tool Carrier	John Deere	201	√	√	√	√	
Planting and Seeding	Plows	John Deere	202H	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	205	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	207	√	√	√	√	
Planting and Seeding	Attachments	John Deere	212B	√	√	√	√	
Planting and Seeding	Planters	John Deere	216	√	√	√	√	
Tillage	Harvester	John Deere	220	√	√	√	√	
Tillage	Disks	John Deere	2200A	√	√	√	√	
Tillage	Disk Plows	John Deere	225	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	227	√	√	√	√	
Attachment	Tool Carrier	John Deere	23A	√	√	√	√	
Attachment	Tool Carrier	John Deere	23B	√	√	√	√	
Planting and Seeding	Planters	John Deere	23B	√	√	√	√	
Planting and Seeding	Planters	John Deere	23C	√	√	√	√	
Planting and Seeding	Planters	John Deere	23F	√	√	√	√	
Planting and Seeding	Planters	John Deere	23R	√	√	√	√	
Attachment	None	John Deere	24	√	√	√	√	
Attachment	None	John Deere	26	√	√	√	√	
Hay and Forage	Auger Platforms	John Deere	240	√	√	√	√	
Planting and Seeding	Planters	John Deere	246	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Planting and Seeding	Planters	John Deere	446	√	√	√	√	
Planting and Seeding	Planters	John Deere	24B	√	√	√	√	
Planting and Seeding	Planters	John Deere	25B	√	√	√	√	
Planting and Seeding	Plows	John Deere	2500	√	√	√	√	
Tillage	Chisel Plows	John Deere	250F	√	√	√	√	
Hay and Forage	Flail Shredders	John Deere	26	√	√	√	√	
Planting and Seeding	Planters	John Deere	290	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	3	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	6	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	8	√	√	√	√	
Tillage	Plows	John Deere	30	√	√	√	√	
Tillage	Disks	John Deere	3000	√	√	√	√	
Tillage	Disks	John Deere	4000	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	301	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	307	√	√	√	√	
Planting and Seeding	Planters	John Deere	247	√	√	√	√	
Planting and Seeding	Planters	John Deere	447	√	√	√	√	
Tillage	Disks	John Deere	31	√	√	√	√	
Tillage	Moldboard Plows	John Deere	3100	√	√	√	√	
Tillage	Disks	John Deere	315	√	√	√	√	
Tillage	Moldboard Plows	John Deere	3200	√	√	√	√	
Tillage	Disks	John Deere	325	√	√	√	√	
Planting and Seeding	Planters	John Deere	33	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	34	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	40	√	√	√	√	
Tillage	Disks	John Deere	340	√	√	√	√	
Tillage	Moldboard Plows	John Deere	35	√	√	√	√	
Tillage	Moldboard Plows	John Deere	45	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tillage	Moldboard Plows	John Deere	350	√	√	√	√	
Tillage	Disks	John Deere	360	√	√	√	√	
Tillage	Disks	John Deere	370	√	√	√	√	
Tillage	Disks	John Deere	375	√	√	√	√	
Tillage	Plows	John Deere	40	√	√	√	√	
Tillage	Tiller	John Deere	40	√	√	√	√	
Tillage	Grinder Mixers	John Deere	400	√	√	√	√	
Tillage	Disk Plows	John Deere	400	√	√	√	√	
Tillage	Other	John Deere	410	√	√	√	√	
Tillage	Plows	John Deere	41	√	√	√	√	
Tillage	Disk Plows	John Deere	400H	√	√	√	√	
Planting and Seeding	Planters	John Deere	407	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	407	√	√	√	√	
Planting and Seeding	Planters	John Deere	406	√	√	√	√	
Tillage	Disks	John Deere	350	√	√	√	√	
Tillage	Moldboard Plows	John Deere	360	√	√	√	√	
Hay and Forage	Side-Delivery Rakes	John Deere	350	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	4100	√	√	√	√	
Tillage	Moldboard Plows	John Deere	411	√	√	√	√	
Tillage	Moldboard Plows	John Deere	412	√	√	√	√	
Planting and Seeding	Plows	John Deere	411	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	4110	√	√	√	√	
Tillage	Rotary Hoes	John Deere	414	√	√	√	√	
Tillage	Rotary Hoes	John Deere	614	√	√	√	√	
Tillage	Rotary Hoes	John Deere	814	√	√	√	√	
Tillage	Moldboard Plows	John Deere	415	√	√	√	√	
Tillage	Moldboard Plows	John Deere	416	√	√	√	√	
Tillage	Moldboard Plows	John Deere	415A	√	√	√	√	
Tillage	Moldboard Plows	John Deere	416A	√	√	√	√	
Tillage	Disks	John Deere	440	√	√	√	√	
Hay and Forage	Row-Crop Cultivators	John Deere	420	√	√	√	√	
Hay and Forage	Row-Crop Cultivators	John Deere	4200	√	√	√	√	
Tillage	Plows	John Deere	422A	√	√	√	√	
Hay and Forage	Plows	John Deere	4260	√	√	√	√	
Planting and Seeding	Planters	John Deere	631	√	√	√	√	
Planting and Seeding	Planters	John Deere	44	√	√	√	√	
Tillage	Plows	John Deere	44	√	√	√	√	
Tillage	Plows	John Deere	44A	√	√	√	√	
Tillage	Plows	John Deere	44AH	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Mate. Hand Cut. and Shredders	Flail Shredders	John Deere	445	√	√	√	√	
Tillage	Moldboard Plows	John Deere	444H	√	√	√	√	
Planting and Seeding	Planters	John Deere	4484	√	√	√	√	
Planting and Seeding	Planters	John Deere	4684	√	√	√	√	
Planting and Seeding	Planters	John Deere	4884	√	√	√	√	
Planting and Seeding	Planters	John Deere	4493	√	√	√	√	
Tillage	Plows	John Deere	422	√	√	√	√	
Planting and Seeding	Planters	John Deere	431	√	√	√	√	
Mate. Hand Cut. and Shredders	Flail Shredders	John Deere	465	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	4220	√	√	√	√	
Tillage	Plows	John Deere	44H	√	√	√	√	
Planting and Seeding	Planters	John Deere	44W	√	√	√	√	
Tillage	Disks	John Deere	455	√	√	√	√	
Tillage	Plows	John Deere	4600	√	√	√	√	
Mate. Hand Cut. and Shredders	Flail Shredders	John Deere	466	√	√	√	√	
Tillage	Disk Plows	John Deere	472	√	√	√	√	
Tillage	Disk Plows	John Deere	475	√	√	√	√	
Planting and Seeding	Planters	John Deere	484	√	√	√	√	
Tillage	Tiller	John Deere	488	√	√	√	√	
Tillage	Rotary Hoes	John Deere	49	√	√	√	√	
Planting and Seeding	Planters	John Deere	490	√	√	√	√	
Planting and Seeding	Planters	John Deere	494AN	√	√	√	√	
Planting and Seeding	Planters	John Deere	694AN	√	√	√	√	
Hay and Forage	Cutter	John Deere	5	√	√	√	√	
Hay and Forage	Pickup Platforms	John Deere	5	√	√	√	√	
Planting and Seeding	Planters	John Deere	50	√	√	√	√	
Tillage	Tiller	John Deere	500C-H	√	√	√	√	
Tillage	Tiller	John Deere	550C-H	√	√	√	√	
Tillage	Tiller	John Deere	700C-H	√	√	√	√	
Tillage	Tiller	John Deere	750C-H	√	√	√	√	
Planting and Seeding	Planters	John Deere	495A	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tillage	Tiller	John Deere	700C-7	√	√	√	√	
Tillage	Tiller	John Deere	800C-H	√	√	√	√	
Tillage	Tiller	John Deere	850C-H	√	√	√	√	
Planting and Seeding	Planters	John Deere	51	√	√	√	√	
Planting and Seeding	Planters	John Deere	5184	√	√	√	√	
Planting and Seeding	Planters	John Deere	5186	√	√	√	√	
Planting and Seeding	Planters	John Deere	5193	√	√	√	√	
Tillage	Rippers	John Deere	55	√	√	√	√	
Tillage	Moldboard Plows	John Deere	555	√	√	√	√	
Tillage	Moldboard Plows	John Deere	555H	√	√	√	√	
Tillage	Moldboard Plows	John Deere	55A	√	√	√	√	
Tillage	Moldboard Plows	John Deere	55B	√	√	√	√	
Tillage	Moldboard Plows	John Deere	55H	√	√	√	√	
Hay and Forage	Wheel Rakes	John Deere	567	√	√	√	√	
Hay and Forage	Side-Delivery Rakes	John Deere	594	√	√	√	√	
Hay and Forage	Side-Delivery Rakes	John Deere	594LW	√	√	√	√	
Planting and Seeding	Planters	John Deere	6	√	√	√	√	
Planting and Seeding	Planters	John Deere	7	√	√	√	√	
Planting and Seeding	Attachments	John Deere	60	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	600	√	√	√	√	
Tillage	Disk Plows	John Deere	600	√	√	√	√	
Tillage	Disk Plows	John Deere	600H	√	√	√	√	
Planting and Seeding	Attachments	John Deere	610	√	√	√	√	
Planting and Seeding	Attachments	John Deere	810	√	√	√	√	
Planting and Seeding	Planters	John Deere	6100	√	√	√	√	
Tillage	Plows	John Deere	64	√	√	√	√	
Tillage	Plows	John Deere	62	√	√	√	√	
Hay and Forage	Rakes	John Deere	640	√	√	√	√	
Tillage	Rotary Hoes	John Deere	642	√	√	√	√	
Hay and Forage	Side-Delivery Rakes	John Deere	650	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	655	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	665	√	√	√	√	
Tillage	Drills	John Deere	66	√	√	√	√	
Tillage	Drills	John Deere	66-4	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tillage	Moldboard Plows	John Deere	66	√	√	√	√	
Planting and Seeding	Planters	John Deere	694A	√	√	√	√	
Planting and Seeding	Planters	John Deere	695A	√	√	√	√	
Planting and Seeding	Planters	John Deere	894A	√	√	√	√	
Tillage	Plows	John Deere	740	√	√	√	√	
Tillage	Plows	John Deere	75	√	√	√	√	
Tillage	Drills	John Deere	750A	√	√	√	√	
Tillage	Moldboard Plows	John Deere	777	√	√	√	√	
Tillage	Drills	John Deere	780	√	√	√	√	
Tillage	Plows	John Deere	8	√	√	√	√	
Tillage	Plows	John Deere	80	√	√	√	√	
Planting and Seeding	Planters	John Deere	80	√	√	√	√	
Tillage	Drills	John Deere	800	√	√	√	√	
Tillage	Plows	John Deere	800	√	√	√	√	
Tillage	Plows	John Deere	805	√	√	√	√	
Tillage	Planters	John Deere	81	√	√	√	√	
Tillage	Plows	John Deere	810	√	√	√	√	
Tillage	Scrapers	John Deere	810	√	√	√	√	
Tillage	Plows	John Deere	810AM	√	√	√	√	
Tillage	Plows	John Deere	812	√	√	√	√	
Tillage	Plows	John Deere	813	√	√	√	√	
Tillage	Plows	John Deere	814	√	√	√	√	
Tillage	Plows	John Deere	820	√	√	√	√	
Tillage	Plows	John Deere	820A	√	√	√	√	
Tillage	Tiller	John Deere	820	√	√	√	√	
Tillage	Plows	John Deere	825	√	√	√	√	
Tillage	Plows	John Deere	825A	√	√	√	√	
Tillage	Plows	John Deere	825B	√	√	√	√	
Tillage	Plows	John Deere	825C	√	√	√	√	
Tillage	Plows	John Deere	8350	√	√	√	√	
Tillage	Plows	John Deere	8450	√	√	√	√	
Hay and Forage	Side-Delivery Rakes	John Deere	850	√	√	√	√	
Tillage	Tiller	John Deere	8500	√	√	√	√	
Hay and Forage	Side-Delivery Rakes	John Deere	851	√	√	√	√	
Hay and Forage	Side-Delivery Rakes	John Deere	858	√	√	√	√	
Tillage	Plows	John Deere	890	√	√	√	√	
Tillage	Plows	John Deere	890A	√	√	√	√	
Hay and Forage	Side-Delivery Rakes	John Deere	890	√	√	√	√	
Tillage	Chisel Plows	John Deere	900	√	√	√	√	
Planting and Seeding	Drills	John Deere	919L	√	√	√	√	
Planting and Seeding	Other	John Deere	930	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tillage	Attachments	John Deere	940	√	√	√	√	
Tillage	Attachments	John Deere	1010	√	√	√	√	
Tillage	Attachments	John Deere	1050	√	√	√	√	
Tillage	Attachments	John Deere	1650	√	√	√	√	
Tillage	Other	John Deere	9400	√	√	√	√	
Mate. Hand Cut. and Shredders	Flail Shredders	John Deere	870A	√	√	√	√	
Tillage	Plows	John Deere	A250	√	√	√	√	
Tillage	Plows	John Deere	G250	√	√	√	√	
Tillage	Plows	John Deere	AT4-6BB	√	√	√	√	
Tillage	Plows	John Deere	AT4-6BV	√	√	√	√	
Tillage	Plows	John Deere	AU2	√	√	√	√	
Tillage	Disks	John Deere	AW	√	√	√	√	
Tillage	Drills	John Deere	B	√	√	√	√	
Tillage	Drills	John Deere	DF-B	√	√	√	√	
Tillage	Drills	John Deere	FB-B	√	√	√	√	
Tillage	Drills	John Deere	B-B	√	√	√	√	
Tillage	Drills	John Deere	FB-C	√	√	√	√	
Tillage	Drills	John Deere	DF-C	√	√	√	√	
Tillage	Drills	John Deere	B-C	√	√	√	√	
Tillage	Drills	John Deere	D-C	√	√	√	√	
Tillage	Roller Harrows	John Deere	B	√	√	√	√	
Tillage	Roller Harrows	John Deere	BF	√	√	√	√	
Tillage	Roller Harrows	John Deere	BFT	√	√	√	√	
Tillage	Roller Harrows	John Deere	BFA	√	√	√	√	
Tillage	Roller Harrows	John Deere	BW	√	√	√	√	
Tillage	Roller Harrows	John Deere	BWN	√	√	√	√	
Tillage	Roller Harrows	John Deere	BWF	√	√	√	√	
Tillage	Roller Harrows	John Deere	BWS	√	√	√	√	
Tillage	Disks	John Deere	C	√	√	√	√	
Tillage	Disks	John Deere	C-10	√	√	√	√	
Planting and Seeding	Planters	John Deere	C-11	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	C380	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	C381	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	C392	√	√	√	√	
Tillage	Conditioners	John Deere	F100H	√	√	√	√	
Tillage	Plows	John Deere	F110	√	√	√	√	
Tillage	Plows	John Deere	F120	√	√	√	√	
Tillage	Plows	John Deere	F130	√	√	√	√	
Tillage	Plows	John Deere	F135H	√	√	√	√	
Tillage	Plows	John Deere	F145H	√	√	√	√	
Tillage	Other	John Deere	F1150	√	√	√	√	
Tillage	Plows	John Deere	F180	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tillage	Plows	John Deere	F225	√	√	√	√	
Tillage	Plows	John Deere	F230H	√	√	√	√	
Tillage	Plows	John Deere	F245H	√	√	√	√	
Tillage	Other	John Deere	F311	√	√	√	√	
Tillage	Plows	John Deere	F325	√	√	√	√	
Tillage	Plows	John Deere	F3350	√	√	√	√	
Tillage	Plows	John Deere	F345H	√	√	√	√	
Tillage	Plows	John Deere	F355H	√	√	√	√	
Tillage	Plows	John Deere	F350	√	√	√	√	
Tillage	Plows	John Deere	F360	√	√	√	√	
Tillage	Plows	John Deere	F365H	√	√	√	√	
Tillage	Plows	John Deere	F375H	√	√	√	√	
Tillage	Plows	John Deere	F370	√	√	√	√	
Tillage	Plows	John Deere	F380	√	√	√	√	
Tillage	Roller Harrows	John Deere	500F	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F610	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F610H	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F620	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F620H	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F630	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F630H	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F610A	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F610AH	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F620A	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F620AH	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F640	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F640H	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F650	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F650H	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F660	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F660H	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F640A	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F640AH	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F604AH	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F650A	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F650AH	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F670	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F670H	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F690	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F690H	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F670A	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F670AH	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F680A	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F680AH	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F835	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F835A	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F845	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F845A	√	√	√	√	
Tillage	Disks	John Deere	F850H	√	√	√	√	
Tillage	Roller Harrows	John Deere	F925	√	√	√	√	
Tillage	Roller Harrows	John Deere	F925H	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tillage	Moldboard Plows	John Deere	F935H	√	√	√	√	
Tillage	Moldboard Plows	John Deere	F945H	√	√	√	√	
Tillage	Cutter	John Deere	FM468	√	√	√	√	
Tillage	Roller Harrows	John Deere	FWA	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	H	√	√	√	√	
Tillage	Plows	John Deere	H2-1	√	√	√	√	
Tillage	Plows	John Deere	H5	√	√	√	√	
Tillage	Plows	John Deere	H10	√	√	√	√	
Planting and Seeding	Drills	John Deere	HZ	√	√	√	√	
Tillage	Roller Harrows	John Deere	JA	√	√	√	√	
Tillage	Roller Harrows	John Deere	JBA	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	K	√	√	√	√	
Tillage	Roller Harrows	John Deere	KBA	√	√	√	√	
Tillage	Roller Harrows	John Deere	KBY	√	√	√	√	
Tillage	Roller Harrows	John Deere	KCA	√	√	√	√	
Tillage	Roller Harrows	John Deere	KHZ	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	L	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	M	√	√	√	√	
Planting and Seeding	Drills	John Deere	LL	√	√	√	√	
Planting and Seeding	Drills	John Deere	LZ-B	√	√	√	√	
Planting and Seeding	Drills	John Deere	PD-A	√	√	√	√	
Tillage	Roller Harrows	John Deere	LW	√	√	√	√	
Tillage	Plows	John Deere	M10A	√	√	√	√	
Tillage	Plows	John Deere	M1A	√	√	√	√	
Tillage	Plows	John Deere	M2A	√	√	√	√	
Tillage	Plows	John Deere	MT1A	√	√	√	√	
Tillage	Plows	John Deere	MT2A	√	√	√	√	
Tillage	Plows	John Deere	M3B	√	√	√	√	
Tillage	Plows	John Deere	M6	√	√	√	√	
Tillage	Plows	John Deere	MT6	√	√	√	√	
Tillage	Plows	John Deere	MT200	√	√	√	√	
Tillage	Plows	John Deere	MT3	√	√	√	√	
Tillage	Plows	John Deere	MT-88	√	√	√	√	
Tillage	Other	John Deere	MT-100	√	√	√	√	
Tillage	Other	John Deere	MT-120	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	P-107	√	√	√	√	
Tillage	Roller Harrows	John Deere	P-98	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Planting and Seeding	Attachments	John Deere	PA300	√	√	√	√	
Planting and Seeding	Attachments	John Deere	PA600	√	√	√	√	
Planting and Seeding	Attachments	John Deere	PA700	√	√	√	√	
Planting and Seeding	Attachments	John Deere	PA800	√	√	√	√	
Planting and Seeding	Attachments	John Deere	PA824	√	√	√	√	
Planting and Seeding	Attachments	John Deere	PA840	√	√	√	√	
Planting and Seeding	Attachments	John Deere	PA860	√	√	√	√	
Planting and Seeding	Attachments	John Deere	PA884	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	R	√	√	√	√	
Tillage	Plows	John Deere	R4-6BB	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	RB1	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	RG2	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	RG4	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	RG6	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	RG430	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	RG630	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	RG20	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	RG40	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	RG830F	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	RG1230	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	RG1620	√	√	√	√	
Tillage	Plows	John Deere	RL4	√	√	√	√	
Tillage	Plows	John Deere	RL6	√	√	√	√	
Tillage	Plows	John Deere	RL630	√	√	√	√	
Tillage	Plows	John Deere	RO516	√	√	√	√	
Tillage	Disks	John Deere	RW	√	√	√	√	
Tillage	Disks	John Deere	RWA	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	S1	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	T21	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	T41	√	√	√	√	
Tillage	Roller Harrows	John Deere	TH224	√	√	√	√	
Tillage	Roller Harrows	John Deere	TH224H	√	√	√	√	
Tillage	Roller Harrows	John Deere	THC328	√	√	√	√	
Tillage	Roller Harrows	John Deere	THC328H	√	√	√	√	
Tillage	Roller Harrows	John Deere	TH336	√	√	√	√	
Tillage	Roller Harrows	John Deere	TH336H	√	√	√	√	
Tillage	Roller Harrows	John Deere	TH436	√	√	√	√	
Tillage	Roller Harrows	John Deere	TH436H	√	√	√	√	
Tillage	Disks	John Deere	TW	√	√	√	√	
Tillage	Disks	John Deere	TWA	√	√	√	√	
Tillage	Plows	John Deere	U2	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tillage	Plows	John Deere	U4	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreaders	John Deere	W	√	√	√	√	
Tillage	Disks	John Deere	WHA	√	√	√	√	
Tillage	Disks	John Deere	Y	√	√	√	√	
Sprayers	Sprayers	John Deere	10A	√	√	√	√	
Sprayers	Sprayers	John Deere	20A	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	John Deere	112	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	John Deere	115	√	√	√	√	
Tillage	Tiller	John Deere	500H	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	507	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	RG8	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	RB2	√	√	√	√	
Tillage	Disks	John Deere	C-21	√	√	√	√	
Tillage	Plows	John Deere	F115	√	√	√	√	
Tillage	Plows	John Deere	F125	√	√	√	√	
Tillage	Plows	John Deere	F3450	√	√	√	√	
Tillage	Disks	John Deere	M100	√	√	√	√	
Planting and Seeding	Drills	John Deere	LL-Z	√	√	√	√	
Planting and Seeding	Drills	John Deere	LZ	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	John Deere	1074	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	John Deere	1065W	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	John Deere	1064	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	John Deere	122	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	John Deere	125	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	125	√	√	√	√	
Skid Steer	Loader	John Deere	170	√	√	√	√	
Hay and Forage	Wagons	John Deere	214	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Wagons	John Deere	216	√	√	√	√	
Sprayers	Sprayers	John Deere	23	√	√	√	√	
Skid Steer	Loader	John Deere	24	√	√	√	√	
Mate. Hand Cut. and Shredders	Blade	John Deere	240	√	√	√	√	
Mate. Hand Cut. and Shredders	Blade	John Deere	245	√	√	√	√	
Skid Steer	Loader	John Deere	24A	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	25	√	√	√	√	
Sprayers	Sprayers	John Deere	25A	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	30	√	√	√	√	
Sprayers	Sprayers	John Deere	31	√	√	√	√	
Sprayers	Sprayers	John Deere	32	√	√	√	√	
Sprayers	Sprayers	John Deere	320	√	√	√	√	
Sprayers	Sprayers	John Deere	335	√	√	√	√	
Sprayers	Sprayers	John Deere	32A	√	√	√	√	
Sprayers	Sprayers	John Deere	32B	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	36	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	36A	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	37	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	3805	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	3807	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	40	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	45	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	45W	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	46	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Mate. Hand Cut. and Shredders	Loaders	John Deere	47	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	46A	√	√	√	√	
Sprayers	Sprayers	John Deere	5	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	50	√	√	√	√	
Sprayers	Sprayers	John Deere	50A	√	√	√	√	
LG Attachments	Sprayer	John Deere	5A	√	√	√	√	
LG Attachments	Sprayer	John Deere	5B	√	√	√	√	
Skid Steer	Loader	John Deere	60	√	√	√	√	
Sprayers	Attachments	John Deere	60	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	John Deere	68	√	√	√	√	
LG Attachments	Sprayer	John Deere	7	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	John Deere	714A	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	John Deere	716A	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	John Deere	76	√	√	√	√	
Mate. Hand Cut. and Shredders	Loader	John Deere	7610	√	√	√	√	
Mate. Hand Cut. and Shredders	Loader	John Deere	7620	√	√	√	√	
Mate. Hand Cut. and Shredders	Loader	John Deere	7630	√	√	√	√	
Mate. Hand Cut. and Shredders	Loader	John Deere	7640	√	√	√	√	
Skid Steer	Loader	John Deere	90	√	√	√	√	
Tillage	Plows	John Deere	90	√	√	√	√	
Sprayers	Sprayers	John Deere	90	√	√	√	√	
Sprayers	Sprayers	John Deere	100	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	John Deere	943	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Mate. Hand Cut. and Shredders	Wagons	John Deere	953	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	John Deere	963	√	√	√	√	
Tillage	Tool Carrier	John Deere	100	√	√	√	√	
Tillage	Other	John Deere	100	√	√	√	√	
Tillage	Attachments	John Deere	1000	√	√	√	√	
Tractor Attachments	Backhoe	John Deere	1550	√	√	√	√	
Tractor Attachments	Backhoe	John Deere	1650	√	√	√	√	
Tractor Attachments	Backhoe	John Deere	165	√	√	√	√	
Combines and Headers	Other	John Deere	1-B	√	√	√	√	
Mate. Hand Cut. and Shredders	Other	John Deere	10A	√	√	√	√	
Mate. Hand Cut. and Shredders	Other	John Deere	14	√	√	√	√	
Tillage	Other	John Deere	15	√	√	√	√	
Tillage	Other	John Deere	16	√	√	√	√	
Mate. Hand Cut. and Shredders	Other	John Deere	150	√	√	√	√	
JD Miscellaneous Equipment	Genset	John Deere	15K	√	√	√	√	
JD Miscellaneous Equipment	Genset	John Deere	25K	√	√	√	√	
Tillage	Attachments	John Deere	180	√	√	√	√	
Tillage	Attachments	John Deere	1600	√	√	√	√	
Planting and Seeding	Attachments	John Deere	184	√	√	√	√	
Planting and Seeding	Attachments	John Deere	186	√	√	√	√	
Planting and Seeding	Attachments	John Deere	186W	√	√	√	√	
Planting and Seeding	Attachments	John Deere	186WL	√	√	√	√	
Tillage	Attachments	John Deere	1900	√	√	√	√	
Planting and Seeding	Other	John Deere	12	√	√	√	√	
Planting and Seeding	Other	John Deere	16	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
JD Miscellaneous Equipment	Other	John Deere	16	√	√	√	√	
Planting and Seeding	Other	John Deere	18	√	√	√	√	
Sprayers	Attachment	John Deere	2	√	√	√	√	
Hay and Forage	Swath Fluffer	John Deere	2	√	√	√	√	
Tillage	Plows	John Deere	202	√	√	√	√	
Tillage	Plows	John Deere	202H	√	√	√	√	
Planting and Seeding	Attachments	John Deere	206	√	√	√	√	
Planting and Seeding	Attachments	John Deere	208	√	√	√	√	
Planting and Seeding	Attachments	John Deere	211B	√	√	√	√	
Planting and Seeding	Attachments	John Deere	411	√	√	√	√	
Planting and Seeding	Attachments	John Deere	411B	√	√	√	√	
Planting and Seeding	Attachments	John Deere	611	√	√	√	√	
Mate. Hand Cut. and Shredders	Other	John Deere	22	√	√	√	√	
Tillage	Other	John Deere	22A	√	√	√	√	
Sprayers	Mounted Sprayers	John Deere	25A	√	√	√	√	
Forklift	None	John Deere	26	√	√	√	√	
Forklift	None	John Deere	27	√	√	√	√	
Tractor Attachments	Blower	John Deere	270	√	√	√	√	
Tractor Attachments	Blower	John Deere	275	√	√	√	√	
Tillage	Harvester	John Deere	30	√	√	√	√	
Tillage	Attachments	John Deere	3000	√	√	√	√	
Hay and Forage	Grain Carts	John Deere	400	√	√	√	√	
Hay and Forage	Attachments	John Deere	400	√	√	√	√	
Hay and Forage	Attachments	John Deere	425	√	√	√	√	
Tillage	Attachments	John Deere	400	√	√	√	√	
Planting and Seeding	Attachments	John Deere	421B	√	√	√	√	
Planting and Seeding	Attachments	John Deere	445	√	√	√	√	
Tillage	Attachments	John Deere	500	√	√	√	√	
Planting and Seeding	Attachments	John Deere	74	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Planting and Seeding	Attachments	John Deere	76	√	√	√	√	
Tractor Attachments	Blade	John Deere	80A	√	√	√	√	
Planting and Seeding	Attachments	John Deere	87	√	√	√	√	
Planting and Seeding	Attachments	John Deere	88	√	√	√	√	
Tractor Attachments	Blade	John Deere	88	√	√	√	√	
Tillage	Other	John Deere	984	√	√	√	√	
Tillage	Other	John Deere	986	√	√	√	√	
Tillage	Other	John Deere	988	√	√	√	√	
Tillage	Other	John Deere	990	√	√	√	√	
JD Miscellaneous Equipment	Other	John Deere	M8	√	√	√	√	
Tillage	Plows	John Deere	MC-1	√	√	√	√	
Tillage	Plows	John Deere	MC-2	√	√	√	√	
Tillage	Plows	John Deere	MC-2A	√	√	√	√	
JD Miscellaneous Equipment	Genset	John Deere	1100	√	√	√	√	
Tillage	Other	John Deere	S16	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	888	√	√	√	√	
Backhoe	Loader	John Deere	JD300-A	√	√	√	√	
Backhoe	Loader	John Deere	JD400-A	√	√	√	√	
Backhoe	Loader	John Deere	JD310	√	√	√	√	
Backhoe	Loader	John Deere	JD410	√	√	√	√	
Planting and Seeding	Planters	John Deere	TZ100	√	√	√	√	
Planting and Seeding	Planters	John Deere	TZ200	√	√	√	√	
Forklift	None	John Deere	59	√	√	√	√	
Tractor Attachments	None	John Deere	F930H	√	√	√	√	
Tractor Attachments	None	John Deere	F931H	√	√	√	√	
Tractor Attachments	Tool Carrier	John Deere	M5A	√	√	√	√	
Tractor Attachments	Tool Carrier	John Deere	MT5A	√	√	√	√	
Tillage	Other	John Deere	F912	√	√	√	√	
Backhoe	None	John Deere	9505A	√	√	√	√	
Backhoe	None	John Deere	9605	√	√	√	√	
Backhoe	None	John Deere	9510A	√	√	√	√	
Backhoe	None	John Deere	9511	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	AT12BB	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	AT4	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tillage	Row-Crop Cultivators	John Deere	AT6	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	AT43	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	AT63	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	AT83	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	AT400	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	AT600	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	AT800	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	AT400A	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	AT600A	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	AT800A	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	AT830A	√	√	√	√	
Tillage	Row-Crop Cultivators	John Deere	AT1230A	√	√	√	√	
Tractor Attachments	Tool Carrier	John Deere	ABG-2000	√	√	√	√	
Other	Bulldozer	John Deere	864	√	√	√	√	
Other	Bulldozer	John Deere	865	√	√	√	√	
Other	Bulldozer	John Deere	866	√	√	√	√	
Sprayers	Sprayers	John Deere	600	√	√	√	√	
Sprayers	Sprayers	John Deere	700	√	√	√	√	
Harvester	Other	John Deere	300	√	√	√	√	
Mate. Hand Cut. and Shredders	Blade	John Deere	78	√	√	√	√	
Mate. Hand Cut. and Shredders	Blade	John Deere	80	√	√	√	√	
Other	Bulldozer	John Deere	534	√	√	√	√	
Other	Bulldozer	John Deere	544	√	√	√	√	
Tractor Attachments	Plows	John Deere	42	√	√	√	√	
Tractor Attachments	Blade	John Deere	423	√	√	√	√	
Tractor Attachments	Attachments	John Deere	500 D	√	√	√	√	
Tractor Attachments	Attachments	John Deere	500E	√	√	√	√	
Tractor Attachments	Attachments	John Deere	500A	√	√	√	√	
Tractor Attachments	Attachments	John Deere	50	√	√	√	√	
Tractor Attachments	Attachments	John Deere	500	√	√	√	√	
Tractor Attachments	Attachments	John Deere	80	√	√	√	√	
Tractor Attachments	Attachments	John Deere	800	√	√	√	√	
Tractor Attachments	Attachments	John Deere	70	√	√	√	√	
Tractor Attachments	Attachments	John Deere	700	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractor Attachments	Attachments	John Deere	82	√	√	√	√	
Tractor Attachments	Attachments	John Deere	84	√	√	√	√	
Backhoe	None	John Deere	50	√	√	√	√	
Backhoe	None	John Deere	51	√	√	√	√	
Planting and Seeding	Attachments	John Deere	451	√	√	√	√	
Planting and Seeding	Attachments	John Deere	651	√	√	√	√	
Planting and Seeding	Attachments	John Deere	41	√	√	√	√	
Planting and Seeding	Attachments	John Deere	41A	√	√	√	√	
Planting and Seeding	Attachments	John Deere	41B	√	√	√	√	
Tillage	Attachments	John Deere	400B	√	√	√	√	
Tillage	Attachments	John Deere	9B	√	√	√	√	
Sprayers	Sprayer Attachment	John Deere	300	√	√	√	√	
Sprayers	Sprayers	John Deere	734	√	√	√	√	
Combines and Headers	Attachments	John Deere	334	√	√	√	√	
Combines and Headers	Attachments	John Deere	434	√	√	√	√	
Combines and Headers	Attachments	John Deere	634	√	√	√	√	
Combines and Headers	Attachments	John Deere	335	√	√	√	√	
Combines and Headers	Attachments	John Deere	435	√	√	√	√	
Combines and Headers	Platforms	John Deere	635	√	√	√	√	
Tillage	Moldboard Plows	John Deere	666	√	√	√	√	
Tillage	Disks	John Deere	1100	√	√	√	√	
Combines and Headers	Combines	John Deere	9560SH	√	√	√	√	
Hay and Forage	Square Balers	John Deere	446	√	√	√	√	
Tractors	2WD or MFWD	John Deere	7715	√	√	√	√	
Tractors	2WD or MFWD	John Deere	7815	√	√	√	√	
Hay and Forage	Balers	John Deere	678	√	√	√	√	
Cotton Harvesting	Cotton Strippers	John Deere	7460	√	√	√	√	
Tillage	Field Cultivators - Level Lift	John Deere	2210	√	√	√	√	
Tractors	Compact Utility	John Deere	900HC	√	√	√	√	
Tractors	4WD Articulated	John Deere	9620	√	√	√	√	
Tractors	Tracks	John Deere	9620T	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Worksite Pro Attachment	Power Rake	John Deere	PR72	√	√	√	√	
Worksite Pro Attachment	Power Rake	John Deere	PR72S	√	√	√	√	
Worksite Pro Attachment	Power Rake	John Deere	PR96	√	√	√	√	
Mate. Hand Cut. and Shredders	Scrapers	John Deere	284	√	√	√	√	
AG Management Solutions	GreenStar Display 2100	John Deere	AMS	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	400X	√	√	√	√	
Information	Information	John Deere	Service ADVISOR AG	√	√	√	√	
Worksite Pro Attachment	Power Rake	John Deere	PR72B	√	√	√	√	
Worksite Pro Attachment	Power Rake	John Deere	PR84B	√	√	√	√	
Worksite Pro Attachment	Power Rake	John Deere	PR96B	√	√	√	√	
Worksite Pro Attachment	Breaker	John Deere	HB100	√	√	√	√	
Worksite Pro Attachment	Breaker	John Deere	HB15	√	√	√	√	
Skid Steer	Loader	John Deere	317	√	√	√	√	
Skid Steer	Loader	John Deere	320	√	√	√	√	
Skid Steer	Loader	John Deere	325	√	√	√	√	
Skid Steer	Loader	John Deere	328	√	√	√	√	
Skid Steer	Loader	John Deere	332	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5300SN	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5310SN	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5400SN	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5410SN	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5500SN	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5510HC	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5510SN	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	381	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Mower Conditioners	John Deere	388	√	√	√	√	
OEM Engines	Diesel	John Deere	3013	√	√	√	√	
OEM Engines	Diesel	John Deere	3016	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	190	√	√	√	√	
Sprayers	Self-Propelled Sprayers PIN Prefix NO or 1NO	John Deere	4720	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5225	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5325	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5425	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5525	√	√	√	√	
Worksite Pro Attachment	Vibratory Roller	John Deere	VR66	√	√	√	√	
Worksite Pro Attachment	Vibratory Roller	John Deere	VR73	√	√	√	√	
Worksite Pro Attachment	Vibratory Roller	John Deere	VR84	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	7200	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	7800	√	√	√	√	
4WD Loader	None	John Deere	244J	√	√	√	√	
4WD Loader	None	John Deere	304J	√	√	√	√	
Excavator	Compact	John Deere	35D	√	√	√	√	
Worksite Pro Attachment	Cold Planer	John Deere	CP12B	√	√	√	√	
Worksite Pro Attachment	Trencher	John Deere	TR36B	√	√	√	√	
Worksite Pro Attachment	Trencher	John Deere	TR48B	√	√	√	√	
Worksite Pro Attachment	Trencher	John Deere	TR60B	√	√	√	√	
Excavator	Compact	John Deere	50D	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5325N	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5425N	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5525N	√	√	√	√	
Tractors	Compact Utility	John Deere	4120	√	√	√	√	
Tractors	Compact Utility	John Deere	4320	√	√	√	√	
Tractors	Compact Utility	John Deere	4520	√	√	√	√	
Tractors	Compact Utility	John Deere	4720	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Mate. Hand Cut. and Shredders	Loader	John Deere	542	√	√	√	√	
Mate. Hand Cut. and Shredders	Loader	John Deere	522	√	√	√	√	
Mate. Hand Cut. and Shredders	Loader	John Deere	512	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ - Brasil - 048751 - XXXXXX	John Deere	1450	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ - Brasil - 048751 - XXXXXX	John Deere	1550	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ - Brasil - 048751 - XXXXXX	John Deere	1450CWS	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ - Brasil - 048751 - XXXXXX	John Deere	1550CWS	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ - Brasil - 048751 - XXXXXX	John Deere	1450WTS	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ - Brasil - 048751 - XXXXXX	John Deere	1550WTS	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ - Brasil - 000181 - XXXXXX	John Deere	9650STS	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ - Brasil - 000181 - XXXXXX	John Deere	9750STS	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	9996	√	√	√	√	
Planting and Seeding	Planters	John Deere	2109	√	√	√	√	
Planting and Seeding	Planters	John Deere	2111	√	√	√	√	
Planting and Seeding	Planters	John Deere	2113	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix CQ - Brazil	John Deere	7515	√	√	√	√	
Planting and Seeding	Planters	John Deere	2115	√	√	√	√	
Planting and Seeding	Planters	John Deere	2117	√	√	√	√	
Planting and Seeding	Planters	John Deere	2122	√	√	√	√	
Planting and Seeding	Planters	John Deere	2126	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Worksite Pro Attachment	Vibratory Roller	John Deere	VR66B	√	√	√	√	
Worksite Pro Attachment	Vibratory Roller	John Deere	VR73B	√	√	√	√	
Worksite Pro Attachment	Vibratory Roller	John Deere	VR84B	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8130	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8230	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8330	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8430	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8530	√	√	√	√	
Tractors	Tracks	John Deere	8230T	√	√	√	√	
Tractors	Tracks	John Deere	8330T	√	√	√	√	
Tractors	Tracks	John Deere	8430T	√	√	√	√	
OEM Engines	Diesel	John Deere	6090	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8000	√	√	√	√	
Tractors	2WD or MFWD	John Deere	5000	√	√	√	√	
Tractors	2WD or MFWD	John Deere	1000	√	√	√	√	
Tractors	2WD or MFWD	John Deere	3000	√	√	√	√	
Combines and Headers	Pickup Platforms	John Deere	615P	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ Brasil - 054551B - XXXXXX	John Deere	1450	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ Brasil - 054551B - XXXXXX	John Deere	1450CWS	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ Brasil - 054551B - XXXXXX	John Deere	1450WTS	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ Brasil - 054551B - XXXXXX	John Deere	1550	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ Brasil - 054551B - XXXXXX	John Deere	1550CWS	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ Brasil - 054551B - XXXXXX	John Deere	1550WTS	√	√	√	√	
Worksite Pro Attachment	Cold Planer	John Deere	CP12	√	√	√	√	
Worksite Pro Attachment	Cold Planer	John Deere	CP16	√	√	√	√	
Worksite Pro Attachment	Cold Planer	John Deere	CP18	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Worksite Pro Attachment	Cold Planer	John Deere	CP24	√	√	√	√	
Skid Steer	Loader	John Deere	CT322	√	√	√	√	
Skid Steer	Loader	John Deere	CT332	√	√	√	√	
Sugar Cane Harvesters	Sugar Cane Combines - PIN Prefix T8 - Thibodaux	John Deere	3510	√	√	√	√	
Hay and Forage	Mower Conditioners PIN Prefix EX	John Deere	525	√	√	√	√	
Hay and Forage	Mower Conditioners PIN Prefix EX	John Deere	530	√	√	√	√	
Hay and Forage	Mower Conditioner	John Deere	535	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix PO	John Deere	5425	√	√	√	√	
Tractors	Pin Prefix PX - Monterrey	John Deere	5425OR	√	√	√	√	
Tractors	Pin Prefix PX - Monterrey	John Deere	5425HC	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix PO	John Deere	5625	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix PO	John Deere	5625HC	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix PO	John Deere	5725	√	√	√	√	
Tractors	Pin Prefix PX - Monterrey	John Deere	5725OR	√	√	√	√	
Tractors	Pin Prefix PX - Monterrey	John Deere	5725HC	√	√	√	√	
Worksite Pro Attachment	Backhoe	John Deere	BH8	√	√	√	√	
Worksite Pro Attachment	Backhoe	John Deere	BH9	√	√	√	√	
Worksite Pro Attachment	Backhoe	John Deere	BH11	√	√	√	√	
Planting and Seeding	Planters	John Deere	1107	√	√	√	√	
Planting and Seeding	Planters	John Deere	1109	√	√	√	√	
Planting and Seeding	Planters	John Deere	1111	√	√	√	√	
Planting and Seeding	Monitor	John Deere	SM500	√	√	√	√	
Mate. Hand Cut. and Shredders	Scrapers	John Deere	1512E	√	√	√	√	
Scraper	Ejector Scraper	John Deere	1810E	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Scraper	Ejector Scraper	John Deere	1814E	√	√	√	√	
Scraper	Ejector Scraper	John Deere	2112E	√	√	√	√	
Combines and Headers	Combines PIN Prefix CQ - Brazil	John Deere	1650CTS	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	5725N	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	5415N	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	724	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	732	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	740	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	1990	√	√	√	√	
Worksite Pro Attachment	Pick-Up Broom	John Deere	BR72	√	√	√	√	
Worksite Pro Attachment	Pick-Up Broom	John Deere	BR84	√	√	√	√	
AG Management Solutions	GreenStar Display	John Deere	AMS	√	√	√	√	
Excavator	Compact	John Deere	27D	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	1840	√	√	√	√	
Tractors	Compact Utility	John Deere	3120	√	√	√	√	
Tractors	Compact Utility	John Deere	3320	√	√	√	√	
Tractors	Compact Utility	John Deere	3520	√	√	√	√	
Sugar Cane Harvesters	None	John Deere	1800B	√	√	√	√	
Mate. Hand Cut. and Shredders	Sugar Cane Loaders	John Deere	SP1850	√	√	√	√	
Mate. Hand Cut. and Shredders	Sugar Cane Loaders	John Deere	SP2254	√	√	√	√	
Tractors	Compact Utility	John Deere	3720	√	√	√	√	
OEM Engines	Diesel	John Deere	6135	√	√	√	√	
Readings	Vehicle	John Deere	Service ADVISOR AG	√	√	√	√	
Readings	Implement	John Deere	Service ADVISOR AG	√	√	√	√	
Boom	Harvester	John Deere	CH8	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvester 508100-XXXXXX	John Deere	7200	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvester 508100-XXXXXX	John Deere	7300	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Self-Propelled Forage Harvester 508100-XXXXXX	John Deere	7400	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvester 508100-XXXXXX	John Deere	7500	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvester 508100-XXXXXX	John Deere	7700	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvester 508100-XXXXXX	John Deere	7800	√	√	√	√	
Combines and Headers	Combines PIN Prefix Z0 - European	John Deere	9540i	√	√	√	√	
Combines and Headers	Combines PIN Prefix Z0 - European	John Deere	9560i	√	√	√	√	
Combines and Headers	Combines PIN Prefix Z0 - European	John Deere	9580i	√	√	√	√	
Combines and Headers	Combines PIN Prefix Z0 - European	John Deere	9640i	√	√	√	√	
Combines and Headers	Combines PIN Prefix Z0 - European	John Deere	9660i	√	√	√	√	
Combines and Headers	Combines	John Deere	9780iCTS	√	√	√	√	
Combines and Headers	Combines	John Deere	9880iSTS	√	√	√	√	
Skid Steer	Loader	John Deere	125	√	√	√	√	
Tractors	Compact Utility	John Deere	2520	√	√	√	√	
Tractors	2WD or MFWD	John Deere	7630	√	√	√	√	
Tractors	2WD or MFWD	John Deere	7730	√	√	√	√	
Tractors	2WD or MFWD	John Deere	7830	√	√	√	√	
Tractors	2WD or MFWD	John Deere	7930	√	√	√	√	
Tractors	2WD or MFWD - North American	John Deere	6230 Premium	√	√	√	√	
Tractors	2WD or MFWD - North American	John Deere	6330 Premium	√	√	√	√	
Tractors	2WD or MFWD - North American	John Deere	6430 Premium	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6230 Premium	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6330 Premium	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6430 Premium	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6530 Premium	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6630 Premium	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6830 Premium	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractors	2WD or MFWD - European	John Deere	6930 Premium	√	√	√	√	
Sprayers	Self-Propelled Sprayers PIN Prefix NO or 1NO	John Deere	4930	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix CQ - Brazil	John Deere	6415	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix CQ - Brazil	John Deere	6615	√	√	√	√	
Worksite Pro Attachment	Dozer	John Deere	DB84	√	√	√	√	
Worksite Pro Attachment	Dozer	John Deere	DB96	√	√	√	√	
Worksite Pro Attachment	Breaker	John Deere	HB60	√	√	√	√	
Worksite Pro Attachment	Breaker	John Deere	HB85	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ Brasil - 070001 - XXXXXX	John Deere	1450	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ Brasil - 070001 - XXXXXX	John Deere	1450CWS	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ Brasil - 070001 - XXXXXX	John Deere	1450WTS	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ Brasil - 070001 - XXXXXX	John Deere	1550	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ Brasil - 070001 - XXXXXX	John Deere	1550CWS	√	√	√	√	
Combines and Headers	Combines Pin Prefix CQ Brasil - 070001 - XXXXXX	John Deere	1550WTS	√	√	√	√	
Worksite Pro Attachment	Backhoe	John Deere	850	√	√	√	√	
Worksite Pro Attachment	Backhoe	John Deere	900	√	√	√	√	
Worksite Pro Attachment	Backhoe	John Deere	911	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	458	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5625	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Planting and Seeding	Planters - Pin Prefix P0	John Deere	1750	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	1830	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	1835	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	673	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	563	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	448	√	√	√	√	
Combines and Headers	Combines	John Deere	9660WTS	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	7430 Premium	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	7530 Premium	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5603	√	√	√	√	
Excavator	Compact	John Deere	17D	√	√	√	√	
Worksite Pro Attachment	Breaker	John Deere	HB50	√	√	√	√	
Worksite Pro Attachment	Breaker	John Deere	HB50 Series II	√	√	√	√	
Worksite Pro Attachment	Breaker	John Deere	HB30	√	√	√	√	
Worksite Pro Attachment	Breaker	John Deere	HB30 Series II	√	√	√	√	
Worksite Pro Attachment	Breaker	John Deere	HB75	√	√	√	√	
Worksite Pro Attachment	Breaker	John Deere	HB75 Series II	√	√	√	√	
Sprayers	Self-Propelled Sprayers PIN Prefix N0 or 1N0	John Deere	4830	√	√	√	√	
Planting and Seeding	Planters	John Deere	1113	√	√	√	√	
Utility Vehicles	Gator X Series	John Deere	XUV 4x4 Diesel	√	√	√	√	
Utility Vehicles	Gator X Series	John Deere	XUV 4x4 Gas	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Utility Vehicles	Gator X Series	John Deere	XUV Trail 4x4 Gas	√	√	√	√	
Worksite Pro Attachment	Cold Planer	John Deere	CP12C	√	√	√	√	
Worksite Pro Attachment	Cold Planer	John Deere	CP18C	√	√	√	√	
Worksite Pro Attachment	Cold Planer	John Deere	CP24C	√	√	√	√	
Worksite Pro Attachment	Cold Planer	John Deere	CP30C	√	√	√	√	
Worksite Pro Attachment	Rotary Tiller	John Deere	RT52	√	√	√	√	
Worksite Pro Attachment	Rotary Tiller	John Deere	RT66	√	√	√	√	
Worksite Pro Attachment	Vibratory Roller	John Deere	VR66C	√	√	√	√	
Worksite Pro Attachment	Vibratory Roller	John Deere	VR73C	√	√	√	√	
Worksite Pro Attachment	Vibratory Roller	John Deere	VR84C	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	533	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	583	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	633	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	653	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	663	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	683	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	753	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractors	Compact Utility	John Deere	2320	√	√	√	√	
Tractors	4WD Articulated	John Deere	9230	√	√	√	√	
Tractors	4WD Articulated	John Deere	9330	√	√	√	√	
Tractors	4WD Articulated	John Deere	9430	√	√	√	√	
Tractors	4WD Articulated	John Deere	9530	√	√	√	√	
Tractors	4WD Articulated	John Deere	9630	√	√	√	√	
Tractors	Tracks	John Deere	9430T	√	√	√	√	
Tractors	Tracks	John Deere	9530T	√	√	√	√	
Tractors	Tracks	John Deere	9630T	√	√	√	√	
Combines and Headers	Combines PIN Prefix H0 - North American	John Deere	9570STS	√	√	√	√	
Combines and Headers	Combines PIN Prefix H0 - North American	John Deere	9670STS	√	√	√	√	
Combines and Headers	Combines PIN Prefix H0 - North American	John Deere	9770STS	√	√	√	√	
Combines and Headers	Combines PIN Prefix H0 - North American	John Deere	9870STS	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	7660	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	7760	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix RW - USA	John Deere	7130 Premium	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix RW - USA	John Deere	7230 Premium	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix RW - USA	John Deere	7330 Premium	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix RW - USA	John Deere	7430 Premium	√	√	√	√	
Worksite Pro Attachment	Snow Utility Blade	John Deere	BL10	√	√	√	√	
Worksite Pro Attachment	Snow Utility Blade	John Deere	BL6	√	√	√	√	
Worksite Pro Attachment	Snow Utility Blade	John Deere	BL7	√	√	√	√	
Worksite Pro Attachment	Snow Utility Blade	John Deere	BL8	√	√	√	√	
Worksite Pro Attachment	Snow Utility Blade	John Deere	BL9	√	√	√	√	
Worksite Pro Attachment	Pick-Up Broom	John Deere	BR60	√	√	√	√	
Worksite Pro Attachment	Scrap Grapple	John Deere	GS60	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Worksite Pro Attachment	Scrap Grapple	John Deere	GS66	√	√	√	√	
Worksite Pro Attachment	Scrap Grapple	John Deere	GS72	√	√	√	√	
Worksite Pro Attachment	Scrap Grapple	John Deere	GS78	√	√	√	√	
Worksite Pro Attachment	Scrap Grapple	John Deere	GS84	√	√	√	√	
Worksite Pro Attachment	Brush Tined Grapple	John Deere	GT72	√	√	√	√	
Worksite Pro Attachment	Brush Tined Grapple	John Deere	GT80	√	√	√	√	
Worksite Pro Attachment	Ag Utility Grapple	John Deere	GU60	√	√	√	√	
Worksite Pro Attachment	Ag Utility Grapple	John Deere	GU66	√	√	√	√	
Worksite Pro Attachment	Ag Utility Grapple	John Deere	GU78	√	√	√	√	
Worksite Pro Attachment	Breaker	John Deere	HH15	√	√	√	√	
Worksite Pro Attachment	Breaker	John Deere	HH30	√	√	√	√	
Worksite Pro Attachment	Breaker	John Deere	HH50	√	√	√	√	
Worksite Pro Attachment	Breaker	John Deere	HH75	√	√	√	√	
Worksite Pro Attachment	Land Plane	John Deere	LP72	√	√	√	√	
Worksite Pro Attachment	Land Plane	John Deere	LP78	√	√	√	√	
Worksite Pro Attachment	Land Plane	John Deere	LP84	√	√	√	√	
Worksite Pro Attachment	Multi-Purpose Bucket	John Deere	MP66	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Worksite Pro Attachment	Multi-Purpose Bucket	John Deere	MP72	√	√	√	√	
Worksite Pro Attachment	Multi-Purpose Bucket	John Deere	MP78	√	√	√	√	
Worksite Pro Attachment	Multi-Purpose Bucket	John Deere	MP84	√	√	√	√	
Worksite Pro Attachment	Power Rake	John Deere	PR60	√	√	√	√	
Worksite Pro Attachment	Roller Level	John Deere	RL66	√	√	√	√	
Worksite Pro Attachment	Rotary Tiller	John Deere	RT55	√	√	√	√	
Worksite Pro Attachment	Trencher	John Deere	TR36	√	√	√	√	
Worksite Pro Attachment	Ag Utility Grapple	John Deere	GU72	√	√	√	√	
Sprayers	Self-Propelled Sprayers PIN Prefix NO or 1NO	John Deere	4730	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	606C	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	608C	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	612C	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	468	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	468S	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	568	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	300	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	300CX	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	300X	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	200CX	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Mate. Hand Cut. and Shredders	Loaders	John Deere	200X	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	843	√	√	√	√	
Hay and Forage	Auger Platforms	John Deere	896	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6130	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6230	√	√	√	√	
Tractors	2WD or MFWD - North American	John Deere	6230	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6330	√	√	√	√	
Tractors	2WD or MFWD - North American	John Deere	6330	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6430	√	√	√	√	
Tractors	2WD or MFWD - North American	John Deere	6430	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6530	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6630	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6830	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6930	√	√	√	√	
Tractors	2WD or MFWD - North American	John Deere	7130	√	√	√	√	
Tractors	2WD or MFWD - North American	John Deere	7230	√	√	√	√	
Skid Steer	Loader	John Deere	313	√	√	√	√	
Skid Steer	Loader	John Deere	315	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix RW - USA	John Deere	7530 Premium	√	√	√	√	
Hay and Forage	Mower Conditioners PIN Prefix EX	John Deere	625	√	√	√	√	
Hay and Forage	Mower Conditioners PIN Prefix EX	John Deere	630	√	√	√	√	
Hay and Forage	Mower Conditioners PIN Prefix EX	John Deere	635	√	√	√	√	
Hay and Forage	Mower Conditioners PIN Prefix EX	John Deere	830	√	√	√	√	
Hay and Forage	Mower Conditioners PIN Prefix EX	John Deere	835	√	√	√	√	
Tractors	Compact Utility	John Deere	4105	√	√	√	√	
Tillage	Mulch Finishers	John Deere	2310	√	√	√	√	
Tillage	Strip Till Residue Master Applicator	John Deere	2510S	√	√	√	√	
Cotton Harvesting	Cotton Pickers	John Deere	7260	√	√	√	√	
Tillage	Conventional Applicator	John Deere	2510C	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5204	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6225	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6325	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractors	2WD or MFWD - European	John Deere	6425	√	√	√	√	
Hay and Forage	Mower Conditioner	John Deere	488	√	√	√	√	
Combines and Headers	Combines 1HO XXXXXX-745099	John Deere	S690	√	√	√	√	
Combines and Headers	Combines	John Deere	S560	√	√	√	√	
Planting and Seeding	Air Seeders	John Deere	1870	√	√	√	√	
Telematics	JDLink	John Deere	JDLink	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	7250	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	7350	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	7450	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	7550	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	7750	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	7850	√	√	√	√	
Utility Vehicles	Gator Electric	John Deere	4X2E	√	√	√	√	
Utility Vehicles	Gator T Series	John Deere	TE 4x2	√	√	√	√	
Combines and Headers	Combines	John Deere	W540	√	√	√	√	
Combines and Headers	Combines	John Deere	W550	√	√	√	√	
Combines and Headers	Combines	John Deere	W650	√	√	√	√	
Combines and Headers	Combines	John Deere	W660	√	√	√	√	
Combines and Headers	Combines	John Deere	T550	√	√	√	√	
Combines and Headers	Combines	John Deere	T560	√	√	√	√	
Combines and Headers	Combines	John Deere	T660	√	√	√	√	
Combines and Headers	Combines	John Deere	T670	√	√	√	√	
Combines and Headers	Combines	John Deere	C670	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6525	√	√	√	√	
Tractors	Specialty Tractor	John Deere	100F	√	√	√	√	
Tractors	Specialty Tractor	John Deere	85F	√	√	√	√	
Tractors	Specialty Tractor	John Deere	76F	√	√	√	√	
Tractors	2WD or MFWD Pin Prefix RW or LO	John Deere	7330	√	√	√	√	
Tractors	Compact Utility	John Deere	3005	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractors	Compact Utility	John Deere	4005	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5503	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5610	√	√	√	√	
Tractors	2WD or MFWD - North American	John Deere	6630	√	√	√	√	
Tractors	2WD or MFWD - North American	John Deere	6530	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	7425	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	7525	√	√	√	√	
Mate. Hand Cut. and Shredders	Scrapers	John Deere	1512C	√	√	√	√	
Mate. Hand Cut. and Shredders	Scrapers	John Deere	1810C	√	√	√	√	
Mate. Hand Cut. and Shredders	Scrapers	John Deere	2112c	√	√	√	√	
Worksite Pro Attachment	Backhoe	John Deere	BH7	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	324A	√	√	√	√	
Hay and Forage	Mower Conditioners	John Deere	328A	√	√	√	√	
Hay and Forage	Rotary Harvesting Units	John Deere	330	√	√	√	√	
Hay and Forage	Rotary Harvesting Units	John Deere	345	√	√	√	√	
Hay and Forage	Rotary Harvesting Units	John Deere	360	√	√	√	√	
Hay and Forage	Rotary Harvesting Units	John Deere	375	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	6100D	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	6110D	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	6115D	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	6125D	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	6130D	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	6140D	√	√	√	√	
Excavator	Compact	John Deere	60D	√	√	√	√	
Combines and Headers	Combines PIN Prefix CQ - Brazil	John Deere	9570STS	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	840i	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Sprayers	Trailed Sprayers	John Deere	832i	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	724i	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	732i	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	740i	√	√	√	√	
Tractors	Compact Utility	John Deere	2720	√	√	√	√	
Transmission	Series	John Deere	1000	√	√	√	√	
Transmission	Series	John Deere	2000	√	√	√	√	
Transmission	Series	John Deere	4000	√	√	√	√	
PTO	Series	John Deere	F20	√	√	√	√	
Transmission	DF Series	John Deere	DF180	√	√	√	√	
Transmission	DF Series	John Deere	DF230	√	√	√	√	
Transmission	Series	John Deere	RC	√	√	√	√	
Transmission	Series	John Deere	50000	√	√	√	√	
Transmission	Series	John Deere	12000	√	√	√	√	
Planetary Drive	P Series	John Deere	P5	√	√	√	√	
Planetary Drive	P Series	John Deere	P25	√	√	√	√	
Planetary Drive	P Series	John Deere	P40	√	√	√	√	
Planetary Drive	P Series	John Deere	P65	√	√	√	√	
Planetary Drive	P Series	John Deere	P120	√	√	√	√	
Planetary Drive	P Series	John Deere	P200	√	√	√	√	
Transmission	Series	John Deere	30000 or 31000	√	√	√	√	
Transmission	HMD	John Deere	23000	√	√	√	√	
Transmission	HMD	John Deere	12700	√	√	√	√	
Transmission	HS	John Deere	17000	√	√	√	√	
Transmission	HMD	John Deere	18000	√	√	√	√	
Axles	TM 2 And 4	John Deere	1600	√	√	√	√	
Axles	TM 2 And 4	John Deere	1400	√	√	√	√	
Axles	TM 2 And 4	John Deere	1200	√	√	√	√	
Sugar Cane Harvesters	PIN T83520XXXXXXX - T83520X100000	John Deere	3520	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Round Balers PIN Prefix EX	John Deere	558	√	√	√	√	
Combines and Headers	Draper Platforms	John Deere	625D	√	√	√	√	
Combines and Headers	Draper Platforms	John Deere	630D	√	√	√	√	
Combines and Headers	Draper Platforms	John Deere	635D	√	√	√	√	
Tractors	Compact Utility	John Deere	3032E	√	√	√	√	
Tractors	Compact Utility	John Deere	3036E	√	√	√	√	
Tractors	Compact Utility	John Deere	3038E	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5083E	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5093E	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5101E	√	√	√	√	
Worksite Pro Attachment	Snow Blower	John Deere	SB60	√	√	√	√	
Worksite Pro Attachment	Snow Blower	John Deere	SB72	√	√	√	√	
Worksite Pro Attachment	Snow Blower	John Deere	SB72H	√	√	√	√	
Worksite Pro Attachment	Snow Blower	John Deere	SB78	√	√	√	√	
Worksite Pro Attachment	Snow Blower	John Deere	SB78H	√	√	√	√	
Worksite Pro Attachment	Snow Blower	John Deere	SB84	√	√	√	√	
Worksite Pro Attachment	Snow Blower	John Deere	SB84H	√	√	√	√	
Worksite Pro Attachment	Snow Push	John Deere	SP8	√	√	√	√	
Worksite Pro Attachment	Snow Push	John Deere	SP10	√	√	√	√	
Worksite Pro Attachment	Snow Push	John Deere	SP10B	√	√	√	√	
Worksite Pro Attachment	Snow Push	John Deere	SP12B	√	√	√	√	
Worksite Pro Attachment	Snow Utility Blade	John Deere	BL6B	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Worksite Pro Attachment	Snow Utility Blade	John Deere	BL7B	√	√	√	√	
Worksite Pro Attachment	Snow Utility Blade	John Deere	BL8B	√	√	√	√	
Worksite Pro Attachment	Snow Utility Blade	John Deere	BL9B	√	√	√	√	
Worksite Pro Attachment	Snow Utility Blade	John Deere	BL10B	√	√	√	√	
Worksite Pro Attachment	Rotary Cutters	John Deere	RC60L	√	√	√	√	
Worksite Pro Attachment	Rotary Cutters	John Deere	RC72L	√	√	√	√	
Worksite Pro Attachment	Rotary Cutters	John Deere	RC72	√	√	√	√	
Worksite Pro Attachment	Rotary Cutters	John Deere	RC78	√	√	√	√	
Transmission	DF Series	John Deere	DF500	√	√	√	√	
Tillage	Nutrient Applicator	John Deere	2510C	√	√	√	√	
Tillage	Nutrient Applicator	John Deere	2510H	√	√	√	√	
Tillage	Nutrient Applicator	John Deere	2510S	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	5080R	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	5090R	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	5100R	√	√	√	√	
Mate. Hand Cut. and Shredders	Fertilizer Spreader	John Deere	DN 345	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	553	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5045D	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5045E	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5055D	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5065E	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5055E	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5075E	√	√	√	√	
Worksite Pro Attachment	Mulching Head	John Deere	MH60	√	√	√	√	
Worksite Pro Attachment	Side Discharge Bucket	John Deere	SA60	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Worksite Pro Attachment	Side Discharge Bucket	John Deere	SA72	√	√	√	√	
Worksite Pro Attachment	Side Discharge Bucket	John Deere	SD84	√	√	√	√	
Worksite Pro Attachment	Side Discharge Bucket	John Deere	SD72	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	5100RN	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	5080RN	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	5090RN	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5065M	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5075M	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5085M	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5095M	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5095MH	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5105M	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5083EN	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5093EN	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5101EN	√	√	√	√	
Combines and Headers	Combines With Command Center	John Deere	T550	√	√	√	√	
Combines and Headers	Combines With Command Center	John Deere	T560	√	√	√	√	
Combines and Headers	Combines With Command Center	John Deere	T660	√	√	√	√	
Combines and Headers	Combines With Command Center	John Deere	T670	√	√	√	√	
Combines and Headers	Combines With Command Center	John Deere	W540	√	√	√	√	
Combines and Headers	Combines With Command Center	John Deere	W550	√	√	√	√	
Combines and Headers	Combines With Command Center	John Deere	W650	√	√	√	√	
Combines and Headers	Combines With Command Center	John Deere	W660	√	√	√	√	
Hay and Forage	Rotary Harvesting Units	John Deere	678	√	√	√	√	
Combines and Headers	Combines With Command Center	John Deere	C670	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	6100B	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	6110B	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	400CX	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	MX15	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix CC	John Deere	854	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Round Balers PIN Prefix CC	John Deere	864	√	√	√	√	
Skid Steer	Loader	John Deere	CT315	√	√	√	√	
Sugar Cane Harvesters	Sugar Cane Combines - PIN Prefix NW - Catalao	John Deere	3522	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix CC	John Deere	744	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix CC	John Deere	644	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	7430 E Premium	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	7530 E Premium	√	√	√	√	
Tractors	PIN prefix CQ - Brazil	John Deere	5603	√	√	√	√	
Planting and Seeding	Planters	John Deere	1740	√	√	√	√	
Tractor Attachments	Backhoe	John Deere	595	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix ZO	John Deere	7950	√	√	√	√	
Sugar Cane Harvesters	Sugar Cane Combines - PIN Prefix NW - Catalao	John Deere	3520	√	√	√	√	
Planting and Seeding	Planters XXXXXX - 740100	John Deere	DB88	√	√	√	√	
Hay and Forage	3 Meter Pickups	John Deere	630C	√	√	√	√	
Hay and Forage	4 Meter Pickups	John Deere	640C	√	√	√	√	
Hay and Forage	4.5 Meter Pickups	John Deere	645C	√	√	√	√	
Utility Vehicles	Gator T Series	John Deere	TS4X2	√	√	√	√	
Utility Vehicles	Gator T Series	John Deere	TH6X4	√	√	√	√	
Utility Vehicles	Gator T Series	John Deere	TH6X4D	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix PO	John Deere	5425N	√	√	√	√	
Worksite Pro Attachment	Breaker	John Deere	HH100	√	√	√	√	
Hay and Forage	Rotary Harvesting Units	John Deere	475	√	√	√	√	
Hay and Forage	Rotary Harvesting Units	John Deere	770	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5080G	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5090G	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5090GH	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractors	PIN prefix AT - Italy	John Deere	5080GF	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5090GF	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5100GF	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5080GV	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5090GV	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5100GV	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	6425	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8225R	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8245R	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8270R	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8320R	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8345R	√	√	√	√	
Tractors	Tracks	John Deere	8295RT	√	√	√	√	
Tractors	Tracks	John Deere	8320RT	√	√	√	√	
Tractors	Tracks	John Deere	8345RT	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8295R	√	√	√	√	
Sprayers	Self-Propelled Sprayers PIN Prefix N0 or 1N0	John Deere	4630	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	6403	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	6603	√	√	√	√	
Tillage	Toolbars	John Deere	MX10	√	√	√	√	
Mate. Hand Cut. and Shredders	Flail Shredders	John Deere	520	√	√	√	√	
Planting and Seeding	Planters - Pin Prefix P0	John Deere	1010	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	5070M	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	5080M	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	5090M	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	5100M	√	√	√	√	
Combines and Headers	Combines PIN Prefix CQ - Brazil	John Deere	1470	√	√	√	√	
Combines and Headers	Combines PIN Prefix CQ - Brazil	John Deere	1570	√	√	√	√	
Planting and Seeding	Planters XXXXXX - 740100	John Deere	DB120	√	√	√	√	
Combines and Headers	Corn Heads PIN prefix CQ - Brazil	John Deere	604C	√	√	√	√	
Combines and Headers	Corn Heads PIN prefix CQ - Brazil	John Deere	606C	√	√	√	√	
Combines and Headers	Corn Heads PIN prefix CQ - Brazil	John Deere	607C	√	√	√	√	
Combines and Headers	Corn Heads PIN prefix CQ - Brazil	John Deere	608C	√	√	√	√	
Combines and Headers	Corn Heads PIN prefix CQ - Brazil	John Deere	609C	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Combines and Headers	Corn Heads PIN prefix CQ - Brazil	John Deere	610C	√	√	√	√	
Combines and Headers	Corn Heads PIN prefix CQ - Brazil	John Deere	611C	√	√	√	√	
Combines and Headers	Corn Heads PIN prefix CQ - Brazil	John Deere	612C	√	√	√	√	
Combines and Headers	Corn Heads PIN prefix CQ - Brazil	John Deere	613C	√	√	√	√	
Combines and Headers	Corn Heads PIN prefix CQ - Brazil	John Deere	614C	√	√	√	√	
Combines and Headers	Corn Heads PIN prefix CQ - Brazil	John Deere	615C	√	√	√	√	
Combines and Headers	Corn Heads PIN prefix CQ - Brazil	John Deere	616C	√	√	√	√	
Combines and Headers	Corn Heads PIN prefix CQ - Brazil	John Deere	617C	√	√	√	√	
Planting and Seeding	Planters	John Deere	DR16	√	√	√	√	
Planting and Seeding	Planters	John Deere	DR18	√	√	√	√	
Worksite Pro Attachment	Auger Planetary	John Deere	PA40	√	√	√	√	
AG Management Solutions	AutoTrac Controller MX 215-305	CASE	AMS	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5105ML	√	√	√	√	
Skid Steer	Manual Controls	John Deere	318D	√	√	√	√	
Skid Steer	Manual Controls	John Deere	319D	√	√	√	√	
Skid Steer	Manual Controls	John Deere	320D	√	√	√	√	
Skid Steer	Manual Controls	John Deere	323D	√	√	√	√	
Skid Steer	Manual Controls	John Deere	326D	√	√	√	√	
Skid Steer	Manual Controls	John Deere	328D	√	√	√	√	
Skid Steer	Manual Controls	John Deere	329D	√	√	√	√	
Skid Steer	Manual Controls	John Deere	332D	√	√	√	√	
Skid Steer	Manual Controls	John Deere	333D	√	√	√	√	
Hay and Forage	Self-Propelled Windrowers 180001 - XXXXXX	John Deere	A400	√	√	√	√	
Hay and Forage	Self-Propelled Windrowers 180001 - XXXXXX	John Deere	R450	√	√	√	√	
Hay and Forage	Self-Propelled Windrowers 180001 - XXXXXX	John Deere	D400	√	√	√	√	
Tractor	2WD or MFWD - PIN Prefix BM - Brazil	John Deere	6165J	√	√	√	√	
Skid Steer	Electrohydraulic Controls - EH	John Deere	318D	√	√	√	√	
Skid Steer	Electrohydraulic Controls - EH	John Deere	319D	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Skid Steer	Electrohydraulic Controls - EH	John Deere	320D	√	√	√	√	
Skid Steer	Electrohydraulic Controls - EH	John Deere	323D	√	√	√	√	
Skid Steer	Electrohydraulic Controls - EH	John Deere	326D	√	√	√	√	
Skid Steer	Electrohydraulic Controls - EH	John Deere	328D	√	√	√	√	
Skid Steer	Electrohydraulic Controls - EH	John Deere	329D	√	√	√	√	
Skid Steer	Electrohydraulic Controls - EH	John Deere	332D	√	√	√	√	
Skid Steer	Electrohydraulic Controls - EH	John Deere	333D	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix CC	John Deere	623	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix CC	John Deere	842	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix CC	John Deere	852	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix CC	John Deere	862	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6534 PREMIUM	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6534	√	√	√	√	
Combines and Headers	Rigid Platforms PIN Prefix ZO - European	John Deere	616R	√	√	√	√	
Combines and Headers	Rigid Platform PIN prefix CQ - Brazil	John Deere	616R	√	√	√	√	
Hay and Forage	Rotary Harvesting Units	John Deere	M4500 or 445	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	824TF	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	832TF	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	832i TF	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	840TF	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	840i TF	√	√	√	√	
Sugar Cane Harvesters	Wheeled PIN T83520W100001 - T83520WXXXXXX	John Deere	3520	√	√	√	√	
Sugar Cane Harvesters	Track PIN T83520T100001 - T83520TXXXXXX	John Deere	3520	√	√	√	√	
Sugar Cane Harvesters	Wheel PIN 1NW3520WTA0090564 - 1NW3520WXXXXXXXX	John Deere	3520	√	√	√	√	
Sugar Cane Harvesters	Track PIN 1NW3520THA0090565 - 1NW3520TXXXXXXXX	John Deere	3520	√	√	√	√	
Sugar Cane Harvesters	Track PIN 1NW3522TPA0090021 - 1NW3522TXXXXXXXX	John Deere	3522	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractor	2WD or MFWD - PIN Prefix BM - Brazil	John Deere	5075E	√	√	√	√	
Hay and Forage	Mower Conditioners PIN Prefix CC	John Deere	730	√	√	√	√	
Hay and Forage	Mower Conditioners PIN Prefix CC	John Deere	735	√	√	√	√	
Combines and Headers	Combines PIN Prefix CQ - Brazil	John Deere	9470STS	√	√	√	√	
Combines and Headers	Combines PIN Prefix CQ - Brazil	John Deere	9670STS	√	√	√	√	
Combines and Headers	Combines PIN Prefix CQ - Brazil	John Deere	9770STS	√	√	√	√	
Combines and Headers	Draper Platforms	John Deere	640D	√	√	√	√	
Utility Vehicles	Gator X Series	John Deere	825i	√	√	√	√	
Crop Care	Nutrient Applicator	John Deere	PitStop Pro	√	√	√	√	
Combines and Headers	Combines PIN Prefix CQ - Brazil	John Deere	S540	√	√	√	√	
Tractor	2WD or MFWD - PIN Prefix BM - Brazil	John Deere	6125J	√	√	√	√	
Tractor	2WD or MFWD - PIN Prefix BM - Brazil	John Deere	6125E	√	√	√	√	
Tractor	2WD or MFWD - PIN Prefix BM - Brazil	John Deere	6110J	√	√	√	√	
Tractor	2WD or MFWD - PIN Prefix BM - Brazil	John Deere	6145J	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	H420	√	√	√	√	
Planting and Seeding	Planters - Pin Prefix P0	John Deere	1030	√	√	√	√	
Tractor	2WD or MFWD - PIN Prefix BM - Brazil	John Deere	6110E	√	√	√	√	
Planting and Seeding	Planters XXXXXX - 740100	John Deere	DB74	√	√	√	√	
AG Management Solutions	ISOBUS	John Deere	AMS	√	√	√	√	
AG Management Solutions	Fleet Management	John Deere	AMS	√	√	√	√	
Tractors	PIN Prefix 1BM - Brazil	John Deere	7515	√	√	√	√	
Tractors	PIN Prefix BM - Brazil	John Deere	7515	√	√	√	√	
Hay and Forage	Mower Conditioners PIN Prefix CC	John Deere	530	√	√	√	√	
Hay and Forage	Mower Conditioners PIN Prefix CC	John Deere	535	√	√	√	√	
Tractors	4WD PIN Prefix JZ	John Deere	9430	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractors	2WD or MFWD - PIN Prefix JZ	John Deere	8345R	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix JZ	John Deere	8320R	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix JZ	John Deere	8295R	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix JZ	John Deere	8270R	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix JZ	John Deere	8245R	√	√	√	√	
Tractors	PIN Prefix BM - Brazil	John Deere	6415	√	√	√	√	
Tractors	PIN Prefix 1BM - Brazil	John Deere	6415	√	√	√	√	
Planting and Seeding	Planters	John Deere	2130	√	√	√	√	
Utility Vehicles	Gator X Series	John Deere	625i	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6170R	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	John Deere	7225J	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	John Deere	7185J	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	John Deere	7205J	√	√	√	√	
Hay and Forage	Rotary Harvesting Units	John Deere	390plus	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	John Deere	7715	√	√	√	√	
Tractors	2WD or MFWD - Brazilian	John Deere	7815	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	John Deere	7815	√	√	√	√	
Tractors	PIN Prefix BM - Brazil	John Deere	5603	√	√	√	√	
Tractors	PIN Prefix 1BM - Brazil	John Deere	5603	√	√	√	√	
Tractors	PIN Prefix 1BM - Brazil	John Deere	5303	√	√	√	√	
Tractors	PIN Prefix BM - Brazil	John Deere	6615	√	√	√	√	
Tractors	PIN Prefix 1BM - Brazil	John Deere	6615	√	√	√	√	
Combines and Headers	Combines PIN Prefix YC - China	John Deere	Y215	√	√	√	√	
Tractors	PIN Prefix 1BM - Brazil	John Deere	5705	√	√	√	√	
Tractors	PIN Prefix BM - Brazil	John Deere	5605	√	√	√	√	
Tractors	PIN Prefix 1BM - Brazil	John Deere	5605	√	√	√	√	
Planting and Seeding	Planters XXXXXX - 740100	John Deere	DB50	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Sprayers	Self-Propelled Sprayers PIN Prefix N0 or 1N0	John Deere	4940	√	√	√	√	
Hay and Forage	Self-Propelled Windrowers 180001 - XXXXXX	John Deere	D450	√	√	√	√	
Sprayers	(-642664) Engine 6068HDW74 (T3)	John Deere	724	√	√	√	√	
Sprayers	(-642664) Engine 6068HDW74 (T3)	John Deere	724i	√	√	√	√	
Sprayers	(-642664) Engine 6068HDW74 (T3)	John Deere	732	√	√	√	√	
Sprayers	(-642664) Engine 6068HDW74 (T3)	John Deere	732i	√	√	√	√	
Sprayers	(-642664) Engine 6068HDW74 (T3)	John Deere	740i	√	√	√	√	
Sprayers	(-642664) Engine 6068HDW74 (T3)	John Deere	832	√	√	√	√	
Sprayers	(-642664) Engine 6068HDW74 (T3)	John Deere	832i	√	√	√	√	
Sprayers	(-642664) Engine 6068HDW74 (T3)	John Deere	840	√	√	√	√	
Sprayers	(-642664) Engine 6068HDW74 (T3)	John Deere	840i	√	√	√	√	
AG	ISOBUS	John Deere	ISOBUS Implement	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5036C	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5041C	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	5-750	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	5-754	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	5-800	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	5-804	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	5-850	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	5-854	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	5-900	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	6155J	√	√	√	√	
Combines and Headers	Draper Platforms	John Deere	640FD	√	√	√	√	
Combines and Headers	Draper Platforms	John Deere	635FD	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	John Deere	5078E	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	John Deere	5085E	√	√	√	√	
Mate. Hand Cut. and Shredders	Loader	John Deere	D120	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Mate. Hand Cut. and Shredders	Loader	John Deere	H120	√	√	√	√	
Mate. Hand Cut. and Shredders	Loader	John Deere	H480	√	√	√	√	
Tractors	Tracks	John Deere	8310RT	√	√	√	√	
Tractors	Tracks	John Deere	8335RT	√	√	√	√	
Tractors	Tracks	John Deere	8360RT	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1RW - USA	John Deere	7200R	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1RW - USA	John Deere	7215R	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1RW - USA	John Deere	7230R	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1RW - USA	John Deere	7260R	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1RW - USA	John Deere	7280R	√	√	√	√	
Combines and Headers	Flex Platforms PIN Prefix 1CQ - Brazil	John Deere	635F	√	√	√	√	
Planting and Seeding	Planters PIN Prefix 1CQ	John Deere	1107	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8235R	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8260R	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8285R	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8310R	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8335R	√	√	√	√	
Tractors	2WD or MFWD	John Deere	8360R	√	√	√	√	
Planting and Seeding	Planters PIN Prefix 1CQ	John Deere	2113	√	√	√	√	
Planting and Seeding	Planters PIN Prefix 1CQ	John Deere	2122	√	√	√	√	
Planting and Seeding	Planters PIN Prefix 1CQ	John Deere	2130	√	√	√	√	
Planting and Seeding	Planters PIN Prefix 1CQ	John Deere	2115	√	√	√	√	
Planting and Seeding	Planters PIN Prefix 1CQ	John Deere	2109	√	√	√	√	
Planting and Seeding	Planters PIN Prefix 1CQ	John Deere	1113	√	√	√	√	
Planting and Seeding	Planters PIN Prefix 1CQ	John Deere	1111	√	√	√	√	
Planting and Seeding	Planters PIN Prefix 1CQ	John Deere	1109	√	√	√	√	
Information Management	AgLogic	John Deere	AMS Ag Logic	√	√	√	√	
Information Management	APEX Desktop Software	John Deere	AMS APEX	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Information Management	HarvestLab	John Deere	AMS Harvest Lab	√	√	√	√	
Information Management	Documentation Printer	John Deere	AMS Printer	√	√	√	√	
Guidance	iGuide	John Deere	AMS iGuide	√	√	√	√	
Guidance	iSteer	John Deere	AMS iSteer	√	√	√	√	
Guidance	iTEC Pro	John Deere	AMS iTEC Pro	√	√	√	√	
GPS Receiver	StarFire 300 Receiver	John Deere	AMS StarFire 300	√	√	√	√	
GPS Receiver	StarFire 3000 Receiver	John Deere	AMS StarFire 3000	√	√	√	√	
GPS Receiver	StarFire iTC Receiver	John Deere	AMS StarFire iTC	√	√	√	√	
GPS Receiver	RTK	John Deere	AMS StarFire RTK	√	√	√	√	
Field and Crop Solutions	iGrade	John Deere	AMS iGrade	√	√	√	√	
Display	GS2 1800 Display	John Deere	AMS 1800	√	√	√	√	
Display	GS2 2100 Display	John Deere	AMS 2100	√	√	√	√	
Display	GS2 2600 Display	John Deere	AMS 2600	√	√	√	√	
Display	GS3 2630 Display	John Deere	AMS 2630	√	√	√	√	
Display	GreenStar Lightbar	John Deere	AMS Lightbar	√	√	√	√	
GPS Receiver	StarFire Gen2 Receiver	John Deere	AMS StarFire Orig.	√	√	√	√	
Guidance	AutoTrac Controller (Case, NH)	John Deere	AMS AT Controller	√	√	√	√	
Guidance	Integrated AutoTrac	John Deere	AMS AT Integrated	√	√	√	√	
Guidance	RowSense & RS Universal	John Deere	AMS AT RowSense	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Guidance	AutoTrac Universal	John Deere	AMS AT Universal	√	√	√	√	
Field and Crop Solutions	Spreader, Seeder Pro (ISO)	John Deere	AMS ApplicationPro	√	√	√	√	
Field and Crop Solutions	Greenstar Rate Controller	John Deere	AMS RateController	√	√	√	√	
Field and Crop Solutions	Raven SmartBoom	John Deere	AMS RavenSmartBoom	√	√	√	√	
Field and Crop Solutions	Surface Water Pro & SWP Plus	John Deere	AMS Surface Water	√	√	√	√	
Field and Crop Solutions	Swath Control Pro, Sprayer Pro	John Deere	AMS Swath Control	√	√	√	√	
Display	Original Display & Mobile Processor	John Deere	AMS Orig. Display	√	√	√	√	
Field and Crop Solutions	Raven Accuflow	John Deere	AMS Raven Accuflow	√	√	√	√	
Field and Crop Solutions	Raven AutoBoom	John Deere	AMS Raven AutoBoom	√	√	√	√	
Field and Crop Solutions	Raven SCS 450	John Deere	AMS Raven SCS 450	√	√	√	√	
Field and Crop Solutions	Raven SCS 660M	John Deere	AMS Raven SCS 660M	√	√	√	√	
Field and Crop Solutions	Raven Sidekick	John Deere	AMS Raven Sidekick	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	John Deere	6180J	√	√	√	√	
Combines and Headers	Corn Heads PIN prefix 1CQ - Brazil	John Deere	613C	√	√	√	√	
Tractors	PIN Prefix 1BM - Brazil	John Deere	5403	√	√	√	√	
Planting and Seeding	Planters 740101-745000	John Deere	1790	√	√	√	√	
Planting and Seeding	Planters 740101-745000	John Deere	1770NT 12ROW	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Planting and Seeding	Planters 740101-745000	John Deere	1770NT 16ROW	√	√	√	√	
Planting and Seeding	Planters 740101-745000	John Deere	1770NT 24ROW	√	√	√	√	
Planting and Seeding	Planters 740101-745000	John Deere	DB120	√	√	√	√	
Planting and Seeding	Planters 740101-745000	John Deere	DB44	√	√	√	√	
Planting and Seeding	Planters 740101-745000	John Deere	DB58	√	√	√	√	
Planting and Seeding	Planters 740101-745000	John Deere	DB60 36ROW	√	√	√	√	
Planting and Seeding	Planters 740101-745000	John Deere	DB60 47ROW	√	√	√	√	
Planting and Seeding	Planters XXXXXX - 740100	John Deere	DB60 47ROW	√	√	√	√	
Planting and Seeding	Planters 740101-745000	John Deere	DB66	√	√	√	√	
Planting and Seeding	Planters XXXXXX - 740100	John Deere	DB80 32 Row	√	√	√	√	
Planting and Seeding	Planters 740101-745000	John Deere	DB80 48 Row	√	√	√	√	
Planting and Seeding	Planters XXXXXX - 740100	John Deere	DB80 48 Row	√	√	√	√	
Planting and Seeding	Planters 740101-745000	John Deere	DB88	√	√	√	√	
Planting and Seeding	Planters 740101-745000	John Deere	DB90	√	√	√	√	
Planting and Seeding	Twin Row Planter	John Deere	1720	√	√	√	√	
Other	Other	John Deere	oCONN1	√	√	√	√	
Tractors	PIN Prefix PY or 1PY	John Deere	5038D	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5103E	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5103S	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5203S	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5104	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5410	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix 1CC	John Deere	960	√	√	√	√	
Hay and Forage	Round Balers PIN Prefix 1CC	John Deere	990	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	1654	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	1854	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	John Deere	5075E	√	√	√	√	
Tractor	General Purpose Construction	John Deere	2350	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5115M	√	√	√	√	
Combines and Headers	Combines	John Deere	1450	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Combines and Headers	Combines 1HO XXXXXX-745099	John Deere	S690 Hillmaster	√	√	√	√	
Combines and Headers	Combines 1HO 745100-XXXXXX	John Deere	S550	√	√	√	√	
Combines and Headers	Combines 1HO 745100-XXXXXX	John Deere	S660	√	√	√	√	
Combines and Headers	Combines 1HO 745100-XXXXXX	John Deere	S670	√	√	√	√	
Combines and Headers	Combines 1HO 745100-XXXXXX	John Deere	S680	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	606C STALKMASTER	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	608C STALKMASTER	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	612C STALKMASTER	√	√	√	√	
Combines and Headers	Flex Platform	John Deere	213F	√	√	√	√	
Combines and Headers	Combines PIN Prefix CQ - Brazil	John Deere	1175	√	√	√	√	
Combines and Headers	Corn Heads PIN prefix CQ - Brazil	John Deere	204	√	√	√	√	
Combines and Headers	Combines PIN Prefix YC - China	John Deere	3316	√	√	√	√	
Combines and Headers	Rigid Platform 13 digit PIN	John Deere	630R	√	√	√	√	
Combines and Headers	Rigid Platform PIN prefix CQ - Brazil	John Deere	618R	√	√	√	√	
Combines and Headers	Rigid Platform PIN prefix CQ - Brazil	John Deere	620R	√	√	√	√	
Combines and Headers	Flex Platforms PIN Prefix 1CQ - Brazil	John Deere	618F	√	√	√	√	
Combines and Headers	Flex Platforms PIN Prefix 1CQ - Brazil	John Deere	620F	√	√	√	√	
Combines and Headers	Flex Platforms PIN Prefix 1CQ - Brazil	John Deere	622F	√	√	√	√	
Combines and Headers	Flex Platforms PIN Prefix 1CQ - Brazil	John Deere	625F	√	√	√	√	
Combines and Headers	Flex Platforms PIN Prefix 1CQ - Brazil	John Deere	630F	√	√	√	√	
Combines and Headers	Corn Heads PIN prefix 1CQ - Brazil	John Deere	616C	√	√	√	√	
Combines and Headers	Rigid Platform	John Deere	618R	√	√	√	√	
Combines and Headers	Rigid Platform	John Deere	620R	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Combines and Headers	Rigid Platform	John Deere	622R	√	√	√	√	
Combines and Headers	Rigid Platform	John Deere	625R	√	√	√	√	
Combines and Headers	Flex Platforms PIN Prefix CQ - Brazil	John Deere	618F	√	√	√	√	
Combines and Headers	Flex Platforms PIN Prefix CQ - Brazil	John Deere	620F	√	√	√	√	
Combines and Headers	Flex Platforms PIN Prefix CQ - Brazil	John Deere	622F	√	√	√	√	
Combines and Headers	Flex Platforms PIN Prefix CQ - Brazil	John Deere	625F	√	√	√	√	
Combines and Headers	Flex Platforms PIN Prefix CQ - Brazil	John Deere	630F	√	√	√	√	
Combines and Headers	Flex Platforms PIN Prefix CQ - Brazil	John Deere	616F	√	√	√	√	
Combines and Headers	Combines w/Command Center Pin-Prefix Z0	John Deere	W540	√	√	√	√	
Combines and Headers	Combines w/Command Center Pin-Prefix Z0	John Deere	W550	√	√	√	√	
Combines and Headers	Combines w/Command Center Pin-Prefix Z0	John Deere	W650	√	√	√	√	
Combines and Headers	Combines w/Command Center Pin-Prefix Z0	John Deere	W660	√	√	√	√	
Combines and Headers	Combines w/Command Center Pin-Prefix Z0	John Deere	T550	√	√	√	√	
Combines and Headers	Combines w/Command Center Pin-Prefix Z0	John Deere	T560	√	√	√	√	
Combines and Headers	Combines w/Command Center Pin-Prefix Z0	John Deere	T660	√	√	√	√	
Combines and Headers	Combines w/Command Center Pin-Prefix Z0	John Deere	T670	√	√	√	√	
Combines and Headers	Corn Heads PIN prefix KM	John Deere	608C STALKMASTER	√	√	√	√	
Combines and Headers	Combines PIN Prefix 1CQ - Brazil	John Deere	1175	√	√	√	√	
Combines and Headers	Combines w/Command Center Pin-prefix 1Z0	John Deere	W540	√	√	√	√	
Combines and Headers	Combines w/Command Center Pin-prefix 1Z0	John Deere	W550	√	√	√	√	
Combines and Headers	Combines w/Command Center Pin-prefix 1Z0	John Deere	W660	√	√	√	√	
Combines and Headers	Combines w/Command Center Pin-prefix 1Z0	John Deere	T550	√	√	√	√	
Combines and Headers	Combines w/Command Center Pin-prefix 1Z0	John Deere	T560	√	√	√	√	
Combines and Headers	Combines w/Command Center Pin-prefix 1Z0	John Deere	T660	√	√	√	√	
Combines and Headers	Combines w/Command Center Pin-prefix 1Z0	John Deere	T670	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Combines and Headers	Combines Pin Prefix 1ZO	John Deere	W540	√	√	√	√	
Combines and Headers	Combines Pin Prefix 1ZO	John Deere	W550	√	√	√	√	
Combines and Headers	Combines Pin Prefix 1ZO	John Deere	W650	√	√	√	√	
Combines and Headers	Combines Pin Prefix 1ZO	John Deere	W660	√	√	√	√	
Combines and Headers	Combines Pin Prefix 1ZO	John Deere	T550	√	√	√	√	
Combines and Headers	Combines Pin Prefix 1ZO	John Deere	T560	√	√	√	√	
Combines and Headers	Combines Pin Prefix 1ZO	John Deere	T660	√	√	√	√	
Combines and Headers	Combines Pin Prefix 1ZO	John Deere	T670	√	√	√	√	
Combines and Headers	Rigid Platforms PIN Prefix 1ZO - European	John Deere	614R	√	√	√	√	
Combines and Headers	Rigid Platforms PIN Prefix 1ZO - European	John Deere	618R	√	√	√	√	
Combines and Headers	Rigid Platforms PIN Prefix 1ZO - European	John Deere	622R	√	√	√	√	
Combines and Headers	Rigid Platforms PIN Prefix 1ZO - European	John Deere	625R	√	√	√	√	
Combines and Headers	Rigid Platform 17 Digit PIN	John Deere	630R	√	√	√	√	
Combines and Headers	Rigid Platforms PIN Prefix 1ZO - European	John Deere	616R	√	√	√	√	
Combines and Headers	Rigid Platforms PIN Prefix 1ZO - European	John Deere	635R	√	√	√	√	
Combines and Headers	Combines PIN Prefix 1HO - North American	John Deere	S690	√	√	√	√	
Combines and Headers	Combines PIN Prefix 1HO - North American	John Deere	S690 Hillmaster	√	√	√	√	
Combines and Headers	Rigid Platforms Pin Prefix 1HO	John Deere	630R	√	√	√	√	
Combines and Headers	Corn Heads PIN Prefix 1HO	John Deere	618C	√	√	√	√	
Combines and Headers	Wide-Row Cornhead PIN Prefix XF	Frontier	CH2112	√	√	√	√	
Combines and Headers	Wide-Row Cornhead PIN Prefix XF	Frontier	CH2208	√	√	√	√	
Hay and Forage	Mower Conditioners PIN Prefix EX	John Deere	535	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix ZO	John Deere	7450	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix ZO	John Deere	7250	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix Z0	John Deere	7350	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix Z0	John Deere	7550	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix Z0	John Deere	7750	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix 1Z0	John Deere	7450	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix 1Z0	John Deere	7250	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix 1Z0	John Deere	7350	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix 1Z0	John Deere	7550	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters PIN-Prefix 1Z0	John Deere	7750	√	√	√	√	
Tillage	Disk Plows	John Deere	624	√	√	√	√	
Tillage	Nutrient Applicator	John Deere	PitStop Pro	√	√	√	√	
Planting and Seeding	Planters PIN Prefix 1CQ	John Deere	2111	√	√	√	√	
Planting and Seeding	Planters PIN Prefix 1CQ	John Deere	2117	√	√	√	√	
Planting and Seeding	Planters PIN Prefix 1CQ	John Deere	2126	√	√	√	√	
Planting and Seeding	Planters XXXXXX - 740100	John Deere	DB60 36 Row	√	√	√	√	
Planting and Seeding	Planters XXXXXX - 740100	John Deere	DB60 47 Row	√	√	√	√	
Sugar Cane Harvesters	Sugar Cane Loaders	John Deere	2254	√	√	√	√	
Sprayers	Mounted Sprayers	John Deere	410A	√	√	√	√	
Sprayers	Mounted Sprayers	John Deere	412A	√	√	√	√	
Sprayers	Mounted Sprayers	John Deere	408A	√	√	√	√	
Sprayers	Self-Propelled Sprayers PIN Prefix WZ or1WZ	John Deere	5430i	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB1010	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB1015	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB1020	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB1110	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB1115	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB1120	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB1130	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB1210	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB1215	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB1220	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB1230	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB2220	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB2230	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB2020	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB2030	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB2120	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB2130	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	MB3110	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	MB3115	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	MB3120	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	MB3210	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	MB3215	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	MB3220	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	CN4106	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	CN4108	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	CN4110	√	√	√	√	
Tractors	4WD Articulated	John Deere	9360R	√	√	√	√	
Tractors	4WD - PIN Prefix RW	John Deere	9410R	√	√	√	√	
Tractors	4WD Articulated	John Deere	9460R	√	√	√	√	
Tractors	4WD Articulated	John Deere	9510R	√	√	√	√	
Tractors	4WD Articulated	John Deere	9560R	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractors	Tracks	John Deere	9460RT	√	√	√	√	
Tractors	Tracks	John Deere	9510RT	√	√	√	√	
Tractors	Tracks	John Deere	9560RT	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	6415	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	6603	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	John Deere	6165J	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	John Deere	6125J	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	John Deere	6110J	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	John Deere	6145J	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	John Deere	6110E	√	√	√	√	
Tractors	PIN prefix 1PY - India	John Deere	5055E	√	√	√	√	
Tractors	PIN prefix 1PY - India	John Deere	5065E	√	√	√	√	
Tractors	PIN prefix 1PY - India	John Deere	5075E	√	√	√	√	
Utility Vehicles	Gator X Series	John Deere	855D	√	√	√	√	
Utility Vehicles	ProGator Attachment	John Deere	HD300 Sprayer	√	√	√	√	
Utility Vehicles	Gator Turf	John Deere	TXTurf	√	√	√	√	
Utility Vehicles	Gator Robotic	John Deere	R-Gator	√	√	√	√	
Utility Vehicles	Gator H Series	John Deere	HPX4X4	√	√	√	√	
Utility Vehicles	Gator H Series	John Deere	HPX4X4 Trail	√	√	√	√	
Utility Vehicles	Gator H Series	John Deere	HPX4X2	√	√	√	√	
Utility Vehicles	Gator H Series	John Deere	HPX4X2D	√	√	√	√	
Utility Vehicles	Gator H Series	John Deere	HPX4X4D	√	√	√	√	
Commercial Mowing	Front Mowers and Equipment	John Deere	F912	√	√	√	√	
Worksite Pro Attachment	Breaker	John Deere	HH20	√	√	√	√	
Worksite Pro Attachment	Breaker	John Deere	HH40	√	√	√	√	
Worksite Pro Attachment	Breaker	John Deere	HH60	√	√	√	√	
Worksite Pro Attachment	Breaker	John Deere	HH80	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
LG Attachments	Sprayer	John Deere	15	√	√	√	√	
Sugar Cane Harvesters	Wheel PIN Prefix 1NW - Catal?o	John Deere	3520	√	√	√	√	
Sugar Cane Harvesters	Track PIN Prefix 1NW - Catal?o	John Deere	3520	√	√	√	√	
Combines and Headers	Combines PIN Prefix YC - China	John Deere	C230	√	√	√	√	
Combines and Headers	Combines PIN Prefix YC - China	John Deere	W210	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix PO	John Deere	5093E	√	√	√	√	
Sprayers	Trailed Sprayers	John Deere	R962i	√	√	√	√	
Sprayers	Self-Propelled Sprayers PIN Prefix 1NW Brazil	John Deere	4730	√	√	√	√	
Snow Products	Snowblowers Rear Mounted	Frontier	SB1148	√	√	√	√	
Snow Products	Snowblowers Rear Mounted	Frontier	SB1154	√	√	√	√	
Snow Products	Snowblowers Rear Mounted	Frontier	SB1164	√	√	√	√	
Snow Products	Snowblowers Rear Mounted	Frontier	SB1174	√	√	√	√	
Snow Products	Snowblowers Rear Mounted	Frontier	SB1184	√	√	√	√	
Snow Products	Snowblowers Rear Mounted	Frontier	SB1194	√	√	√	√	
Snow Products	Snowblowers Rear Mounted	Frontier	SB1388	√	√	√	√	
Snow Products	Snowblowers Rear Mounted	Frontier	SB1392	√	√	√	√	
Snow Products	Snowblowers Rear Mounted	Frontier	SB1308	√	√	√	√	
Snow Products	Snowblowers Rear Mounted	Frontier	SB1392R	√	√	√	√	
Snow Products	Snowblowers Rear Mounted	Frontier	SB1308R	√	√	√	√	
Snow Products	Snowblowers Rear Mounted	Frontier	SB1309R	√	√	√	√	
Snow Products	Snowblowers Rear Mounted	Frontier	SB1274	√	√	√	√	
Snow Products	Snowblowers Rear Mounted	Frontier	SB1280	√	√	√	√	
Snow Products	Snowblowers Loader Mounted	Frontier	SB2176	√	√	√	√	
Snow Products	Snowblowers Loader Mounted	Frontier	SB2164	√	√	√	√	
Hydraulic Power Pack	Hydraulic Power Pack	Frontier	HP2025	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hydraulic Power Pack	Hydraulic Power Pack	Frontier	HP2134	√	√	√	√	
Hay and Forage	Tedders	Frontier	TD2427	√	√	√	√	
Hay and Forage	Rotary Rake	Frontier	RR2109	√	√	√	√	
Hay and Forage	Rotary Rake	Frontier	RR2211	√	√	√	√	
Hay and Forage	Disc Mower Caddy	Frontier	DC1000	√	√	√	√	
Planting and Seeding	Drills	John Deere	BD1108	√	√	√	√	
Planting and Seeding	Drills	John Deere	BD1110	√	√	√	√	
Planting and Seeding	Drills	John Deere	BD1113	√	√	√	√	
Hay and Forage	Rotary Harvesting Units	John Deere	692	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6105R	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6115R	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6125R	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6130R	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6140R	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6150R	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6210RE	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6190R	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6210R	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	X550	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	X554	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6105M	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6115M	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6125M	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6130M	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6140M	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6150M	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6170M	√	√	√	√	
Tractors	PIN prefix 1PY - India	John Deere	5060E	√	√	√	√	
Tillage	Disks - PIN prefix P0 - Mexico	John Deere	655	√	√	√	√	
Planting and Seeding	Planters	GreenSystem	PP1102	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix RW - USA	John Deere	6170R	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix RW - USA	John Deere	6140R	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix RW - USA	John Deere	6150R	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix RW - USA	John Deere	6190R	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix RW - USA	John Deere	6210R	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	John Deere	6130J	√	√	√	√	
Apollo Series	None	John Deere	Transaxle	√	√	√	√	
Combines and Headers	Combines 1HO 745100-XXXXXX	John Deere	S690	√	√	√	√	
Combines and Headers	Combines 1HO 745100-XXXXXX	John Deere	S690 Hillmaster	√	√	√	√	
Cutting and Mowing	Flex-Wing Grooming Mower	Frontier	FM2015	√	√	√	√	
Cutting and Mowing	Flex-Wing Grooming Mower	Frontier	FM2017	√	√	√	√	
Cutting and Mowing	Flex-Wing Grooming Mower	Frontier	FM2112	√	√	√	√	
Cutting and Mowing	Flex-Wing Grooming Mower	Frontier	FM2115	√	√	√	√	
Cutting and Mowing	Flex-Wing Grooming Mower	Frontier	FM2117	√	√	√	√	
Cutting and Mowing	Flex-Wing Grooming Mower	Frontier	FM1012	√	√	√	√	
Cutting and Mowing	Flex-Wing Grooming Mower	Frontier	FM1015	√	√	√	√	
Cutting and Mowing	Flex-Wing Grooming Mower	Frontier	FM1017	√	√	√	√	
Cutting and Mowing	Flex-Wing Grooming Mower	Frontier	FM3012	√	√	√	√	
Cutting and Mowing	Flex-Wing Grooming Mower	Frontier	FM2120	√	√	√	√	
Cutting and Mowing	Flex-Wing Grooming Mower	Frontier	FM2012	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix P0	John Deere	5083E	√	√	√	√	
Cutting and Mowing	Rotary Cutters	Frontier	RC1048	√	√	√	√	
Cutting and Mowing	Rotary Cutters	Frontier	RC1060	√	√	√	√	
Cutting and Mowing	Rotary Cutters	Frontier	RC1072	√	√	√	√	
Cutting and Mowing	Rotary Cutters	Frontier	RC2048	√	√	√	√	
Cutting and Mowing	Rotary Cutters	Frontier	RC2060	√	√	√	√	
Cutting and Mowing	Rotary Cutters	Frontier	RC2072	√	√	√	√	
Cutting and Mowing	Rotary Cutters	Frontier	RC2084	√	√	√	√	
Cutting and Mowing	Rear Discharge Rotary Mower	Frontier	GM1048E	√	√	√	√	
Cutting and Mowing	Rear Discharge Rotary Mower	Frontier	GM1060E	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Cutting and Mowing	Rear Discharge Rotary Mower	Frontier	GM1072E	√	√	√	√	
Cutting and Mowing	Rear Discharge Rotary Mower	Frontier	GM2060	√	√	√	√	
Cutting and Mowing	Rear Discharge Rotary Mower	Frontier	GM2072	√	√	√	√	
Cutting and Mowing	Rear Discharge Rotary Mower	Frontier	GM2084	√	√	√	√	
Cutting and Mowing	Rear Discharge Rotary Mower	Frontier	GM2190	√	√	√	√	
Cutting and Mowing	Rear Discharge Rotary Mower	Frontier	GM2109	√	√	√	√	
Cutting and Mowing	Rear Discharge Rotary Mower	Frontier	GM1060	√	√	√	√	
Cutting and Mowing	Rear Discharge Rotary Mower	Frontier	GM1072	√	√	√	√	
Cutting and Mowing	Rear Discharge Rotary Mower	Frontier	GM1084	√	√	√	√	
Cutting and Mowing	Rear Discharge Rotary Mower	Frontier	GM1190	√	√	√	√	
Cutting and Mowing	Rear Discharge Rotary Mower	Frontier	GM3054	√	√	√	√	
Cutting and Mowing	Rear Discharge Rotary Mower	Frontier	GM3060	√	√	√	√	
Cutting and Mowing	Rear Discharge Rotary Mower	Frontier	GM3072	√	√	√	√	
Cutting and Mowing	Side Discharge Rotary Mower	Frontier	GM1060S	√	√	√	√	
Cutting and Mowing	Side Discharge Rotary Mower	Frontier	GM1072S	√	√	√	√	
Mate. Hand Cut. and Shredders	Attachment	Frontier	MJ4084	√	√	√	√	
Mate. Hand Cut. and Shredders	Attachment	Frontier	MJ4058	√	√	√	√	
Mate. Hand Cut. and Shredders	Attachment	Frontier	MJ4091	√	√	√	√	
Mate. Hand Cut. and Shredders	Attachment	Frontier	MJ4090	√	√	√	√	
Mate. Hand Cut. and Shredders	Attachment	Frontier	MJ4085	√	√	√	√	
Mate. Hand Cut. and Shredders	Attachment	Frontier	QC1072	√	√	√	√	
Mate. Hand Cut. and Shredders	Bale Spear	Frontier	AB12A	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Mate. Hand Cut. and Shredders	Bale Spear	Frontier	AB12D	√	√	√	√	
Mate. Hand Cut. and Shredders	Bale Spear	Frontier	AB12E	√	√	√	√	
Mate. Hand Cut. and Shredders	Bale Spear	Frontier	AB12G	√	√	√	√	
Mate. Hand Cut. and Shredders	Bale Spear	Frontier	AB13D	√	√	√	√	
Mate. Hand Cut. and Shredders	Bale Spear	Frontier	AB13E	√	√	√	√	
Mate. Hand Cut. and Shredders	Bale Spear	Frontier	AB13G	√	√	√	√	
Mate. Hand Cut. and Shredders	Bale Spear	Frontier	AB14A	√	√	√	√	
Mate. Hand Cut. and Shredders	Bale Spear	Frontier	AB14D	√	√	√	√	
Mate. Hand Cut. and Shredders	Bale Spear	Frontier	AB14G	√	√	√	√	
Mate. Hand Cut. and Shredders	Bale Spear	Frontier	AB15A	√	√	√	√	
Mate. Hand Cut. and Shredders	Bale Spear	Frontier	AB16A	√	√	√	√	
Mate. Hand Cut. and Shredders	Bale Spear	Frontier	AB16D	√	√	√	√	
Mate. Hand Cut. and Shredders	Bale Spear	Frontier	AB16G	√	√	√	√	
Mate. Hand Cut. and Shredders	Bale Spear	Frontier	MJ4081	√	√	√	√	
Mate. Hand Cut. and Shredders	Bale Spear	Frontier	MJ4074	√	√	√	√	
Mate. Hand Cut. and Shredders	Bale Spear	Frontier	MJ4060A	√	√	√	√	
Mate. Hand Cut. and Shredders	Bale Spear	Frontier	MJ4037	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Mate. Hand Cut. and Shredders	Bale Spear	Frontier	BF1102S	√	√	√	√	
Mate. Hand Cut. and Shredders	Bale Hugger	Frontier	AH11A	√	√	√	√	
Mate. Hand Cut. and Shredders	Bale Hugger	Frontier	AH11D	√	√	√	√	
Mate. Hand Cut. and Shredders	Bale Hugger	Frontier	MJ4099	√	√	√	√	
Mate. Hand Cut. and Shredders	Grapple	Frontier	AV20D	√	√	√	√	
Mate. Hand Cut. and Shredders	Grapple	Frontier	AV20E	√	√	√	√	
Mate. Hand Cut. and Shredders	Grapple	Frontier	AV20G	√	√	√	√	
Mate. Hand Cut. and Shredders	Grapple	Frontier	AV20H	√	√	√	√	
Mate. Hand Cut. and Shredders	Grapple	Frontier	BG1096	√	√	√	√	
Mate. Hand Cut. and Shredders	Grapple	Frontier	AT1096G	√	√	√	√	
Mate. Hand Cut. and Shredders	Scrapers	Frontier	LL1410	√	√	√	√	
Mate. Hand Cut. and Shredders	Scrapers	Frontier	LL1412	√	√	√	√	
Mate. Hand Cut. and Shredders	Scrapers	Frontier	LL1414	√	√	√	√	
Mate. Hand Cut. and Shredders	Scrapers	Frontier	LL1416	√	√	√	√	
Hay and Forage	Bale Mover Feeders	Frontier	BU1060	√	√	√	√	
Mate. Hand Cut. and Shredders	Snow Push	Frontier	AS10H	√	√	√	√	
Mate. Hand Cut. and Shredders	Snow Push	Frontier	AS11E	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Bale Spear	Frontier	HS1001	√	√	√	√	
Hay and Forage	Bale Spear	Frontier	HS1002	√	√	√	√	
Hay and Forage	Bale Spear	Frontier	HS2001	√	√	√	√	
Hay and Forage	Bale Spear	Frontier	HS2003	√	√	√	√	
Hay and Forage	Bale Spear	Frontier	HS2004	√	√	√	√	
Hay and Forage	Bale Spear	Frontier	HS2002	√	√	√	√	
Mate. Hand Cut. and Shredders	Bucket	Frontier	AD11E	√	√	√	√	
Mate. Hand Cut. and Shredders	Bucket	Frontier	AD11H	√	√	√	√	
Mate. Hand Cut. and Shredders	Bucket	Frontier	AD12D	√	√	√	√	
Mate. Hand Cut. and Shredders	Bucket	Frontier	AD12G	√	√	√	√	
Mate. Hand Cut. and Shredders	Bucket	Frontier	AY11E	√	√	√	√	
Mate. Hand Cut. and Shredders	Bucket	Frontier	AY11H	√	√	√	√	
Mate. Hand Cut. and Shredders	Bucket	Frontier	MJ4079A	√	√	√	√	
Mate. Hand Cut. and Shredders	Bucket	Frontier	MJ4063A	√	√	√	√	
Mate. Hand Cut. and Shredders	Bucket	Frontier	MJ4062	√	√	√	√	
Mate. Hand Cut. and Shredders	Bucket	Frontier	MJ4061A	√	√	√	√	
Mate. Hand Cut. and Shredders	Bucket	Frontier	MJ4059A	√	√	√	√	
Mate. Hand Cut. and Shredders	Bucket	Frontier	AT2016U	√	√	√	√	
Mate. Hand Cut. and Shredders	Bucket	Frontier	AT2016G	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Mate. Hand Cut. and Shredders	Bucket	Frontier	MJ4118	√	√	√	√	
Mate. Hand Cut. and Shredders	Roller	Frontier	CR1448	√	√	√	√	
Mate. Hand Cut. and Shredders	Roller	Frontier	CR1460	√	√	√	√	
Mate. Hand Cut. and Shredders	Pallet Fork	Frontier	AP12A	√	√	√	√	
Mate. Hand Cut. and Shredders	Pallet Fork	Frontier	AP12D	√	√	√	√	
Mate. Hand Cut. and Shredders	Pallet Fork	Frontier	AP12F	√	√	√	√	
Mate. Hand Cut. and Shredders	Pallet Fork	Frontier	AP12G	√	√	√	√	
Mate. Hand Cut. and Shredders	Pallet Fork	Frontier	AP12K	√	√	√	√	
Mate. Hand Cut. and Shredders	Pallet Fork	Frontier	AP13D	√	√	√	√	
Mate. Hand Cut. and Shredders	Pallet Fork	Frontier	AP13F	√	√	√	√	
Mate. Hand Cut. and Shredders	Pallet Fork	Frontier	AP13G	√	√	√	√	
Mate. Hand Cut. and Shredders	Pallet Fork	Frontier	AP13K	√	√	√	√	
Mate. Hand Cut. and Shredders	Front Blade	Frontier	AF11D	√	√	√	√	
Mate. Hand Cut. and Shredders	Front Blade	Frontier	AF11E	√	√	√	√	
Mate. Hand Cut. and Shredders	Front Blade	Frontier	AF11G	√	√	√	√	
Mate. Hand Cut. and Shredders	Front Blade	Frontier	AF12D	√	√	√	√	
Mate. Hand Cut. and Shredders	Front Blade	Frontier	AF12G	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Mate. Hand Cut. and Shredders	Rock Bucket	Frontier	AR10D	√	√	√	√	
Mate. Hand Cut. and Shredders	Rock Bucket	Frontier	AR10E	√	√	√	√	
Mate. Hand Cut. and Shredders	Rock Bucket	Frontier	AR10G	√	√	√	√	
Mate. Hand Cut. and Shredders	Rock Bucket	Frontier	AR10H	√	√	√	√	
Mate. Hand Cut. and Shredders	Rock Bucket	Frontier	AR12A	√	√	√	√	
Mate. Hand Cut. and Shredders	Rock Bucket	Frontier	AR12D	√	√	√	√	
Mate. Hand Cut. and Shredders	Rock Bucket	Frontier	AR12G	√	√	√	√	
Mate. Hand Cut. and Shredders	Free Stall Scraper	Frontier	AE11E	√	√	√	√	
Mate. Hand Cut. and Shredders	Manure Fork & Grapple	Frontier	AM11D	√	√	√	√	
Mate. Hand Cut. and Shredders	Manure Fork & Grapple	Frontier	AM11E	√	√	√	√	
Mate. Hand Cut. and Shredders	Manure Fork & Grapple	Frontier	AM11G	√	√	√	√	
Mate. Hand Cut. and Shredders	Manure Fork & Grapple	Frontier	AM11H	√	√	√	√	
Mate. Hand Cut. and Shredders	Manure Fork & Grapple	Frontier	MJ4077	√	√	√	√	
Mate. Hand Cut. and Shredders	Manure Fork & Grapple	Frontier	MJ4076	√	√	√	√	
Mate. Hand Cut. and Shredders	Silage Defacer	Frontier	AG10A	√	√	√	√	
Mate. Hand Cut. and Shredders	Silage Defacer	Frontier	AG10D	√	√	√	√	
Mate. Hand Cut. and Shredders	Silage Defacer	Frontier	AG11S	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Mate. Hand Cut. and Shredders	Silage Defacer	Frontier	AG12S	√	√	√	√	
Mate. Hand Cut. and Shredders	Silage Defacer	Frontier	SD1096	√	√	√	√	
Hay and Forage	Bale Carrier	Frontier	BC1104	√	√	√	√	
Hay and Forage	Bale Carrier	Frontier	BC1108	√	√	√	√	
Hay and Forage	Bale Carrier	Frontier	BC1110	√	√	√	√	
Hay and Forage	Bale Wrapper	Frontier	LW1166	√	√	√	√	
Hay and Forage	Bale Wrapper	Frontier	LW1266	√	√	√	√	
Combines and Headers	Header Transports	Frontier	HT1124	√	√	√	√	
Combines and Headers	Header Transports	Frontier	HT1128	√	√	√	√	
Combines and Headers	Header Transports	Frontier	HT1132	√	√	√	√	
Combines and Headers	Header Transports	Frontier	HT1138	√	√	√	√	
Combines and Headers	Header Transports	Frontier	HT1142	√	√	√	√	
Combines and Headers	Header Transports	Frontier	HT1224	√	√	√	√	
Combines and Headers	Header Transports	Frontier	HT1228	√	√	√	√	
Combines and Headers	Header Transports	Frontier	HT1232	√	√	√	√	
Combines and Headers	Header Transports	Frontier	HT1238	√	√	√	√	
Combines and Headers	Header Transports	Frontier	HT1242	√	√	√	√	
Cotton Harvesting	Module Handler	Frontier	CM1100	√	√	√	√	
Hay and Forage	Mowers	Frontier	DM1140	√	√	√	√	
Hay and Forage	Mowers	Frontier	DM1150	√	√	√	√	
Hay and Forage	Mowers	Frontier	DM1160	√	√	√	√	
Hay and Forage	Mowers	Frontier	DM1270	√	√	√	√	
Hay and Forage	Mowers	Frontier	SB1106	√	√	√	√	
Hay and Forage	Mowers	Frontier	SB1107	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Mowers	Frontier	SB3106	√	√	√	√	
Hay and Forage	Mowers	Frontier	SB3107	√	√	√	√	
Hay and Forage	Mowers	Frontier	SB3108	√	√	√	√	
Hay and Forage	Tedders	Frontier	TD1010E	√	√	√	√	
Hay and Forage	Tedders	Frontier	TD1123	√	√	√	√	
Hay and Forage	Tedders	Frontier	TD1316	√	√	√	√	
Hay and Forage	Carted Wheel Rakes	Frontier	WR1008	√	√	√	√	
Hay and Forage	Carted Wheel Rakes	Frontier	WR1010	√	√	√	√	
Hay and Forage	Carted Wheel Rakes	Frontier	WR1012	√	√	√	√	
Hay and Forage	Carted Wheel Rakes	Frontier	WR1108	√	√	√	√	
Hay and Forage	Carted Wheel Rakes	Frontier	WR1112	√	√	√	√	
Hay and Forage	Carted Wheel Rakes	Frontier	WR1116	√	√	√	√	
Hay and Forage	Carted Wheel Rakes	Frontier	WR3008	√	√	√	√	
Hay and Forage	Carted Wheel Rakes	Frontier	WR3010	√	√	√	√	
Hay and Forage	Carted Wheel Rakes	Frontier	WR3012	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR1212	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR1214	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR1216	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR1218	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR1417	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR2010E	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR2012E	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR2014E	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR2110	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR2112	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR2114	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR2212	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR2214	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR2316	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR2318	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR3310	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR3312	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR3313	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR3414	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR3416	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR3417	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR3419	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR5417	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR4106	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR4109	√	√	√	√	
Hay and Forage	Pull-Type Wheel Rakes	Frontier	WR4313	√	√	√	√	
Hay and Forage	Rotary Rake	Frontier	RR1012E	√	√	√	√	
Hay and Forage	Rotary Rake	Frontier	RR2313	√	√	√	√	
Hay and Forage	Rotary Rake	Frontier	RR2324	√	√	√	√	
Hay and Forage	Hay Merger	Frontier	HM1109	√	√	√	√	
Hay and Forage	Hay Merger	Frontier	HM1209	√	√	√	√	
Hay and Forage	Hay Merger	Frontier	HM1212	√	√	√	√	
Mate. Hand Cut. and Shredders	Scrapers	Frontier	LL1410C	√	√	√	√	
Mate. Hand Cut. and Shredders	Scrapers	Frontier	LL1412C	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Mate. Hand Cut. and Shredders	Scrapers	Frontier	LL1414C	√	√	√	√	
Mate. Hand Cut. and Shredders	Scrapers	Frontier	LL1416C	√	√	√	√	
Mate. Hand Cut. and Shredders	Roller	Frontier	CR1448C	√	√	√	√	
Mate. Hand Cut. and Shredders	Roller	Frontier	CR1460C	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT2283	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	5-950	√	√	√	√	
Tillage	Disk	John Deere	2620	√	√	√	√	
Tillage	Disk	John Deere	2623	√	√	√	√	
Tillage	Disk	John Deere	2625	√	√	√	√	
Vertical Tillage	Disk	John Deere	2623VT	√	√	√	√	
Tillage	Disks - PIN prefix P0 - Mexico	John Deere	660	√	√	√	√	
Combines and Headers	Combines PIN Prefix N4	John Deere	R40-STC	√	√	√	√	
Planting and Seeding	Twin Row Planter	John Deere	1700	√	√	√	√	
Utility Vehicles	Gator Military	John Deere	M-Gator A2	√	√	√	√	
Landscaping	Trencher	Frontier	DT1136	√	√	√	√	
Field and Crop Solutions	Rate Controller Dry	John Deere	AMS RateControlDry	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	616C	√	√	√	√	
Landscaping	Scrapers	Frontier	LL1160	√	√	√	√	
Landscaping	Scrapers	Frontier	LL1172	√	√	√	√	
Landscaping	Scrapers	Frontier	LL1208	√	√	√	√	
Landscaping	Scrapers	Frontier	LL1210	√	√	√	√	
Landscaping	Scrapers	Frontier	LL1212	√	√	√	√	
Landscaping	Scrapers	Frontier	LL1372	√	√	√	√	
Landscaping	Scrapers	Frontier	LL1384	√	√	√	√	
Landscaping	Scrapers	Frontier	LL1396	√	√	√	√	
Landscaping	Blade	Frontier	BB4184	√	√	√	√	
Landscaping	Blade	Frontier	BB1048	√	√	√	√	
Landscaping	Blade	Frontier	BB1048L	√	√	√	√	
Landscaping	Blade	Frontier	BB1060	√	√	√	√	
Landscaping	Blade	Frontier	BB1065	√	√	√	√	
Landscaping	Blade	Frontier	BB1072	√	√	√	√	
Landscaping	Blade	Frontier	BB1172	√	√	√	√	
Landscaping	Blade	Frontier	BB1184	√	√	√	√	
Landscaping	Blade	Frontier	BB1284	√	√	√	√	
Landscaping	Blade	Frontier	BB1354	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Landscaping	Blade	Frontier	BB1360	√	√	√	√	
Landscaping	Blade	Frontier	BB1365	√	√	√	√	
Landscaping	Blade	Frontier	BB1372	√	√	√	√	
Landscaping	Blade	Frontier	BB1472	√	√	√	√	
Landscaping	Blade	Frontier	BB1484	√	√	√	√	
Landscaping	Blade	Frontier	BB2048	√	√	√	√	
Landscaping	Blade	Frontier	BB2048L	√	√	√	√	
Landscaping	Blade	Frontier	BB2060	√	√	√	√	
Landscaping	Blade	Frontier	BB2065	√	√	√	√	
Landscaping	Blade	Frontier	BB2072	√	√	√	√	
Landscaping	Blade	Frontier	BB2172	√	√	√	√	
Landscaping	Blade	Frontier	BB2184	√	√	√	√	
Landscaping	Blade	Frontier	BB2272	√	√	√	√	
Landscaping	Blade	Frontier	BB3272	√	√	√	√	
Landscaping	Blade	Frontier	BB3284	√	√	√	√	
Landscaping	Blade	Frontier	BB3296	√	√	√	√	
Landscaping	Blade	Frontier	BB3384	√	√	√	√	
Landscaping	Blade	Frontier	BB4160	√	√	√	√	
Landscaping	Blade	Frontier	BB4166	√	√	√	√	
Landscaping	Blade	Frontier	BB4172	√	√	√	√	
Landscaping	Blade	Frontier	BB4178	√	√	√	√	
Landscaping	Blade	Frontier	BB4196	√	√	√	√	
Landscaping	Blade	Frontier	BB4278	√	√	√	√	
Landscaping	Blade	Frontier	BB4284	√	√	√	√	
Landscaping	Blade	Frontier	BB4296	√	√	√	√	
Landscaping	Aerator	Frontier	CA1048	√	√	√	√	
Landscaping	Aerator	Frontier	CA1060	√	√	√	√	
Landscaping	Aerator	Frontier	CA1072	√	√	√	√	
Landscaping	Aerator	Frontier	CA2048E	√	√	√	√	
Landscaping	Aerator	Frontier	CA2060	√	√	√	√	
Landscaping	Aerator	Frontier	CA2060E	√	√	√	√	
Landscaping	Aerator	Frontier	CA2072	√	√	√	√	
Landscaping	Aerator	Frontier	CA2072E	√	√	√	√	
Landscaping	Land Plane	Frontier	LP1048	√	√	√	√	
Landscaping	Land Plane	Frontier	LP1060	√	√	√	√	
Landscaping	Land Plane	Frontier	LP1160	√	√	√	√	
Landscaping	Land Plane	Frontier	LP1172	√	√	√	√	
Landscaping	Land Plane	Frontier	LP1184	√	√	√	√	
Landscaping	Land Plane	Frontier	LP1196	√	√	√	√	
Landscaping	Land Plane	Frontier	LP1207	√	√	√	√	
Landscaping	Land Plane	Frontier	LP1208	√	√	√	√	
Landscaping	Land Plane	Frontier	LP1210	√	√	√	√	
Landscaping	Landscape Rake	Frontier	LR1072	√	√	√	√	
Landscaping	Landscape Rake	Frontier	LR1060L	√	√	√	√	
Landscaping	Landscape Rake	Frontier	LR1172	√	√	√	√	
Landscaping	Landscape Rake	Frontier	LR1184	√	√	√	√	
Landscaping	Landscape Rake	Frontier	LR1196	√	√	√	√	
Landscaping	Landscape Rake	Frontier	LR2060L	√	√	√	√	
Landscaping	Landscape Rake	Frontier	LR2072	√	√	√	√	
Landscaping	Landscape Rake	Frontier	LR2084	√	√	√	√	
Landscaping	Landscape Rake	Frontier	LR2196	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Landscaping	Post Hole Auger	Frontier	PHA006	√	√	√	√	
Landscaping	Post Hole Auger	Frontier	PHA009	√	√	√	√	
Landscaping	Post Hole Auger	Frontier	PHA012	√	√	√	√	
Landscaping	Post Hole Auger	Frontier	PHA106	√	√	√	√	
Landscaping	Post Hole Auger	Frontier	PHA109	√	√	√	√	
Landscaping	Post Hole Auger	Frontier	PHA112	√	√	√	√	
Landscaping	Post Hole Auger	Frontier	PHA118	√	√	√	√	
Landscaping	Post Hole Auger	Frontier	PHA124	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB1060	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB1060L	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB1072	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB1084	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB1172	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB1184	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB1196	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2060	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2060L	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2072	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2084	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2160	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2172	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2172H	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2184	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2184H	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2196	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2196H	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2272	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2284	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2296	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2307	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2308	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2309	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2310	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2408	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2409	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2410	√	√	√	√	
Landscaping	Post Hole Digger	Frontier	PHD100	√	√	√	√	
Landscaping	Post Hole Digger	Frontier	PHD200	√	√	√	√	
Landscaping	Post Hole Digger	Frontier	PHD300	√	√	√	√	
Landscaping	Post Hole Digger	Frontier	PHD400	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1060E	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1070E	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1080E	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1140	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1142	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1149	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1150	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1157	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1160	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1165	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1170	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Landscaping	Rotary Tiller	Frontier	RT1173	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1180	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1181	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1207	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1208	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1240	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1250	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1260	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1270	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1280	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1307	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1307R	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1308	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1308R	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1310	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1310R	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1360	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1380	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1380R	√	√	√	√	
Landscaping	Power Rake	Frontier	PR1148	√	√	√	√	
Landscaping	Power Rake	Frontier	PR1160	√	√	√	√	
Landscaping	Power Rake	Frontier	PR1172	√	√	√	√	
Landscaping	Power Rake	Frontier	PR1184	√	√	√	√	
Landscaping	Power Rake	Frontier	PR1184F	√	√	√	√	
Mate. Hand Cut. and Shredders	Bale Hugger	Frontier	AH11G	√	√	√	√	
Golf and Turf Products	Grinders	Frontier	BG1000	√	√	√	√	
Golf and Turf Products	Grinders	Frontier	BG1500	√	√	√	√	
Golf and Turf Products	Grinders	Frontier	RG5000	√	√	√	√	
Golf and Turf Products	Grinders	Frontier	RG5500	√	√	√	√	
Snow Products	Snowblowers Rear Mounted	Frontier	SB1388R	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2160H	√	√	√	√	
Landscaping	Landscape Rake	Frontier	LR2172	√	√	√	√	
Landscaping	Landscape Rake	Frontier	LR2184	√	√	√	√	
Landscaping	Soil Pulverizor	Frontier	SP1060	√	√	√	√	
Landscaping	Soil Pulverizor	Frontier	SP1272	√	√	√	√	
Landscaping	Soil Pulverizor	Frontier	SP1272B	√	√	√	√	
Landscaping	Soil Pulverizor	Frontier	SP1284	√	√	√	√	
Landscaping	Soil Pulverizor	Frontier	SP1284B	√	√	√	√	
Landscaping	Soil Pulverizor	Frontier	SP2048B	√	√	√	√	
Landscaping	Soil Pulverizor	Frontier	SP2060B	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Landscaping	Soil Pulverizor	Frontier	SP2072B	√	√	√	√	
Landscaping	Soil Pulverizor	Frontier	SP2272B	√	√	√	√	
Landscaping	Soil Pulverizor	Frontier	SP2284B	√	√	√	√	
Landscaping	Soil Pulverizor	Frontier	SP1048	√	√	√	√	
Combines and Headers	Combines MY12 Wide Cab PIN Prefix 1ZO	John Deere	T670	√	√	√	√	
Combines and Headers	Draper Platforms PIN Prefix 1CQ	John Deere	640D	√	√	√	√	
Combines and Headers	Draper Platforms PIN Prefix 1CQ	John Deere	635D	√	√	√	√	
Combines and Headers	Combines PIN Prefix YC - China	John Deere	C110	√	√	√	√	
Combines and Headers	Corn Heads PIN prefix KM	John Deere	606C STALKMASTER	√	√	√	√	
Combines and Headers	Combines MY12 Wide Cab PIN Prefix 1ZO	John Deere	W540	√	√	√	√	
Combines and Headers	Combines MY12 Wide Cab PIN Prefix 1ZO	John Deere	W550	√	√	√	√	
Combines and Headers	Combines MY12 Wide Cab PIN Prefix 1ZO	John Deere	W650	√	√	√	√	
Combines and Headers	Combines MY12 Wide Cab PIN Prefix 1ZO	John Deere	W660	√	√	√	√	
Combines and Headers	Combines MY12 Wide Cab PIN Prefix 1ZO	John Deere	T550	√	√	√	√	
Combines and Headers	Combines MY12 Wide Cab PIN Prefix 1ZO	John Deere	T560	√	√	√	√	
Combines and Headers	Combines MY12 Wide Cab PIN Prefix 1ZO	John Deere	T660	√	√	√	√	
Utility Vehicles	Gator X Series	John Deere	XUV 550 S4	√	√	√	√	
Utility Vehicles	Gator X Series	John Deere	XUV 550	√	√	√	√	
Utility Vehicles	Gator R Series	John Deere	RSX850i	√	√	√	√	
Worksite Pro Attachment	Snow Blower	John Deere	SB60B	√	√	√	√	
Worksite Pro Attachment	Snow Blower	John Deere	SB72B	√	√	√	√	
Worksite Pro Attachment	Snow Blower	John Deere	SB78B	√	√	√	√	
Worksite Pro Attachment	Snow Blower	John Deere	SB84B	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	John Deere	5055E	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	John Deere	5065E	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	7280	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	7380	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	7480	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	7580	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	7780	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	7180	√	√	√	√	
Hay and Forage	Self-Propelled Forage Harvesters	John Deere	7980	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix JZ	John Deere	6130D	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	John Deere	7195J	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	John Deere	7210J	√	√	√	√	
Planting and Seeding	Drills	Frontier	BD1307	√	√	√	√	
Planting and Seeding	seeders	Frontier	CS1360	√	√	√	√	
Planting and Seeding	seeders	Frontier	CS1384	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	616C STALKMASTER	√	√	√	√	
Combines and Headers	Corn Heads	John Deere	618C STALKMASTER	√	√	√	√	
Hay and Forage	Processor	Frontier	BP1166	√	√	√	√	
Tillage	Disks	Frontier	DH3409C	√	√	√	√	
Tillage	Disks	Frontier	DH3474C	√	√	√	√	
Tillage	Disks	Frontier	DH3480C	√	√	√	√	
Tillage	Disks	Frontier	DH3490C	√	√	√	√	
Tillage	Disks	Frontier	DH3499C	√	√	√	√	
Tillage	Disks	Frontier	DH4413C	√	√	√	√	
Tillage	Disks	Frontier	DH4414C	√	√	√	√	
Tillage	Disks	Frontier	DH4415C	√	√	√	√	
Tillage	Disks	Frontier	DH4420C	√	√	√	√	
Tillage	Disks	Frontier	DH5410C	√	√	√	√	
Tillage	Disks	Frontier	DH5411C	√	√	√	√	
Tillage	Disks	Frontier	DH5412C	√	√	√	√	
Tillage	Disks	Frontier	DH5413C	√	√	√	√	
Tillage	Disks	Frontier	DH5414C	√	√	√	√	
Tillage	Disks	Frontier	DH5510C	√	√	√	√	
Tillage	Disks	Frontier	DH5511C	√	√	√	√	
Tillage	Disks	Frontier	DH5513C	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tillage	Disks	Frontier	DH5514C	√	√	√	√	
Tillage	Disks	Frontier	DH5610C	√	√	√	√	
Tillage	Disks	Frontier	DH5612C	√	√	√	√	
Tillage	Disks	Frontier	DH5613C	√	√	√	√	
Tillage	Disks	Frontier	DH5615C	√	√	√	√	
Tillage	Disks	Frontier	DH1048	√	√	√	√	
Tillage	Disks	Frontier	DH1066	√	√	√	√	
Tillage	Disks	Frontier	DH1166	√	√	√	√	
Tillage	Disks	Frontier	DH1176	√	√	√	√	
Tillage	Disks	Frontier	DH1180	√	√	√	√	
Tillage	Disks	Frontier	DH1276	√	√	√	√	
Tillage	Disks	Frontier	DH1280	√	√	√	√	
Tillage	Disks	Frontier	DH1296	√	√	√	√	
Tillage	Disks	Frontier	DH1376	√	√	√	√	
Tillage	Disks	Frontier	DH1380	√	√	√	√	
Tillage	Disks	Frontier	DH1396	√	√	√	√	
Tillage	Disks	Frontier	DH1508	√	√	√	√	
Tillage	Disks	Frontier	DH1509	√	√	√	√	
Tillage	Disks	Frontier	DH1510	√	√	√	√	
Tillage	Disks	Frontier	DH1512	√	√	√	√	
Tillage	Disks	Frontier	DH1610	√	√	√	√	
Tillage	Disks	Frontier	DH1612	√	√	√	√	
Tillage	Disks	Frontier	DH1613	√	√	√	√	
Tillage	Disks	Frontier	DH1615	√	√	√	√	
Tillage	Disks	Frontier	DH3263	√	√	√	√	
Tillage	Disks	Frontier	DH3272	√	√	√	√	
Tillage	Disks	Frontier	DH3280	√	√	√	√	
Tillage	Disks	Frontier	DH3290	√	√	√	√	
Tillage	Disks	Frontier	DH3299	√	√	√	√	
Tillage	Disks	Frontier	DH3409	√	√	√	√	
Tillage	Disks	Frontier	DH3474	√	√	√	√	
Tillage	Disks	Frontier	DH3480	√	√	√	√	
Tillage	Disks	Frontier	DH3490	√	√	√	√	
Tillage	Disks	Frontier	DH3499	√	√	√	√	
Tillage	Disks	Frontier	DH4108	√	√	√	√	
Tillage	Disks	Frontier	DH4110	√	√	√	√	
Tillage	Disks	Frontier	DH4112	√	√	√	√	
Tillage	Disks	Frontier	DH4114	√	√	√	√	
Tillage	Disks	Frontier	DH4115	√	√	√	√	
Tillage	Disks	Frontier	DH4116	√	√	√	√	
Tillage	Disks	Frontier	DH4117	√	√	√	√	
Tillage	Disks	Frontier	DH4119	√	√	√	√	
Tillage	Disks	Frontier	DH4119R	√	√	√	√	
Tillage	Disks	Frontier	DH4121	√	√	√	√	
Tillage	Disks	Frontier	DH4122	√	√	√	√	
Tillage	Disks	Frontier	DH4125	√	√	√	√	
Tillage	Disks	Frontier	DH4218	√	√	√	√	
Tillage	Disks	Frontier	DH4221	√	√	√	√	
Tillage	Disks	Frontier	DH4307	√	√	√	√	
Tillage	Disks	Frontier	DH4309	√	√	√	√	
Tillage	Disks	Frontier	DH4311	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tillage	Disks	Frontier	DH4315	√	√	√	√	
Tillage	Disks	Frontier	DH4317	√	√	√	√	
Tillage	Disks	Frontier	DH4320	√	√	√	√	
Tillage	Disks	Frontier	DH4411	√	√	√	√	
Tillage	Disks	Frontier	DH4413	√	√	√	√	
Tillage	Disks	Frontier	DH4414	√	√	√	√	
Tillage	Disks	Frontier	DH4415	√	√	√	√	
Tillage	Disks	Frontier	DH4420	√	√	√	√	
Tillage	Disks	Frontier	TM4124	√	√	√	√	
Tillage	Disks	Frontier	TM4125	√	√	√	√	
Tillage	Disks	Frontier	TM4130	√	√	√	√	
Tillage	Disks	Frontier	DH5221F	√	√	√	√	
Tillage	Disks	Frontier	DH5222F	√	√	√	√	
Tillage	Disks	Frontier	DH5224F	√	√	√	√	
Tillage	Disks	Frontier	TM5118	√	√	√	√	
Tillage	Disks	Frontier	TM5120	√	√	√	√	
Tillage	Disks	Frontier	TM5121	√	√	√	√	
Tillage	Disks	Frontier	TM5124	√	√	√	√	
Tillage	Disks	Frontier	TM5129	√	√	√	√	
Tillage	Field Cultivators	Frontier	PC1072	√	√	√	√	
Tillage	Mulch Finishers	Frontier	MF1204	√	√	√	√	
Tillage	Mulch Finishers	Frontier	MF1204P	√	√	√	√	
Tillage	Mulch Finishers	Frontier	MF1206	√	√	√	√	
Tillage	Mulch Finishers	Frontier	MF1208	√	√	√	√	
Tillage	Mulch Finishers	Frontier	MF2204	√	√	√	√	
Tillage	Mulch Finishers	Frontier	MF2206	√	√	√	√	
Tillage	Mulch Finishers	Frontier	MF2208	√	√	√	√	
Tillage	Rippers	Frontier	PM1001	√	√	√	√	
Tillage	Rippers	Frontier	PS1001	√	√	√	√	
Tillage	Plows	Frontier	CP1104	√	√	√	√	
Tillage	Plows	Frontier	CP1106	√	√	√	√	
Tillage	Plows	Frontier	PB1001	√	√	√	√	
Tillage	Plows	Frontier	PB1002	√	√	√	√	
Tillage	Rotary Tiller	Frontier	RC1208	√	√	√	√	
Tillage	Rotary Tiller	Frontier	RC1208R	√	√	√	√	
Tillage	Rotary Tiller	Frontier	RC1210	√	√	√	√	
Tillage	Rotary Tiller	Frontier	RC1210R	√	√	√	√	
Tillage	Rotary Tiller	Frontier	RC1310	√	√	√	√	
Tillage	Rotary Tiller	Frontier	RC1310R	√	√	√	√	
Tillage	Rotary Tiller	Frontier	RC1313	√	√	√	√	
Tillage	Rotary Tiller	Frontier	RC1313R	√	√	√	√	
Tillage	Cultivator	Frontier	PC1001	√	√	√	√	
Planting and Seeding	seeders	Frontier	FP1204	√	√	√	√	
Planting and Seeding	seeders	Frontier	FP1204P	√	√	√	√	
Planting and Seeding	seeders	Frontier	FP1206	√	√	√	√	
Planting and Seeding	seeders	Frontier	FP1208	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Planting and Seeding	seeders	Frontier	FP2204	√	√	√	√	
Planting and Seeding	seeders	Frontier	FP2204P	√	√	√	√	
Planting and Seeding	seeders	Frontier	FP2206	√	√	√	√	
Planting and Seeding	seeders	Frontier	FP2208	√	√	√	√	
Mate. Hand Cut. and Shredders	Grinder Mixers	Frontier	GX1117	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreader	Frontier	MS1102G	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreader	Frontier	MS1105G	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreader	Frontier	MS1108G	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreader	Frontier	MS1108	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreader	Frontier	MS1112	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreader	Frontier	MS1117	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreader	Frontier	MS1337	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreader	Frontier	MS1354	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreader	Frontier	MS1368	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreader	Frontier	MS1442	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreader	Frontier	MS1455	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreader	Frontier	MS1223	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreader	Frontier	MS1227	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Mate. Hand Cut. and Shredders	Spreader	Frontier	MS1231	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreader	Frontier	MS1237	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreader	Frontier	MS1243	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreader	Frontier	MS1256	√	√	√	√	
Mate. Hand Cut. and Shredders	Spreader	Frontier	MS1266	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1CC	John Deere	H380	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1CC	John Deere	H360	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1P0	John Deere	H380	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1P0	John Deere	H360	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2307C	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2308C	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2309C	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2310C	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2408C	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2409C	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB2410C	√	√	√	√	
Landscaping	Scrapers	Frontier	LL1372C	√	√	√	√	
Landscaping	Scrapers	Frontier	LL1384C	√	√	√	√	
Landscaping	Scrapers	Frontier	LL1396C	√	√	√	√	
Landscaping	Blower	Frontier	BL2130	√	√	√	√	
Landscaping	Blower	Frontier	BL1130	√	√	√	√	
Landscaping	Blade	Frontier	BB4278C	√	√	√	√	
Landscaping	ROTARY BROOM	Frontier	SW2160	√	√	√	√	
Landscaping	ROTARY BROOM	Frontier	SW2172	√	√	√	√	
Landscaping	ROTARY BROOM	Frontier	SW2184	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1280C	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT2293	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT2383	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT2308	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT2310	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1265	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT1273	√	√	√	√	
Landscaping	Rotary Tiller	Frontier	RT2210	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Landscaping	Land Plane	Frontier	LP1184C	√	√	√	√	
Landscaping	Land Plane	Frontier	LP1196C	√	√	√	√	
Landscaping	Spreader	Frontier	SS1022B	√	√	√	√	
Landscaping	Spreader	Frontier	SS1023B	√	√	√	√	
Landscaping	Spreader	Frontier	SS1035B	√	√	√	√	
Landscaping	Spreader	Frontier	SS1036B	√	√	√	√	
Landscaping	Spreader	Frontier	SS1067B	√	√	√	√	
Landscaping	Spreader	Frontier	SS1079P	√	√	√	√	
Landscaping	Spreader	Frontier	SS1116P	√	√	√	√	
Landscaping	Spreader	Frontier	SS1180P	√	√	√	√	
Landscaping	Spreader	Frontier	SS1220P	√	√	√	√	
Landscaping	Spreader	Frontier	SS2036B	√	√	√	√	
Landscaping	Spreader	Frontier	SS2067B	√	√	√	√	
Landscaping	Spreader	Frontier	SS3067B	√	√	√	√	
Landscaping	Chipper_Shredder	Frontier	WC1103	√	√	√	√	
Landscaping	Chipper_Shredder	Frontier	WC1105	√	√	√	√	
Landscaping	Chipper_Shredder	Frontier	WC1205	√	√	√	√	
Landscaping	Chipper_Shredder	Frontier	WC1208	√	√	√	√	
Landscaping	seeders	Frontier	TR2058	√	√	√	√	
Landscaping	seeders	Frontier	TR1048	√	√	√	√	
Landscaping	seeders	Frontier	TR1060	√	√	√	√	
Landscaping	seeders	Frontier	TR1072	√	√	√	√	
Landscaping	Arena Rake	Frontier	RA1084	√	√	√	√	
Landscaping	Arena Rake	Frontier	RA1108	√	√	√	√	
Landscaping	Arena Rake	Frontier	RA1110	√	√	√	√	
Hay and Forage	Rotary Harvesting Units	John Deere	690	√	√	√	√	
Hay and Forage	Rotary Harvesting Units	John Deere	698	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB5072	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB5084	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB5096	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB5060L	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB5048L	√	√	√	√	
Landscaping	Blade	Frontier	BB5060	√	√	√	√	
Landscaping	Blade	Frontier	BB5072	√	√	√	√	
Landscaping	Blade	Frontier	BB5084	√	√	√	√	
Landscaping	Blade	Frontier	BB5096	√	√	√	√	
Landscaping	Blade	Frontier	BB5060L	√	√	√	√	
Landscaping	Blade	Frontier	BB5048L	√	√	√	√	
Landscaping	Landscape Rake	Frontier	LR5060	√	√	√	√	
Landscaping	Landscape Rake	Frontier	LR5072	√	√	√	√	
Landscaping	Landscape Rake	Frontier	LR5084	√	√	√	√	
Landscaping	Landscape Rake	Frontier	LR5096	√	√	√	√	
Landscaping	Landscape Rake	Frontier	LR5060L	√	√	√	√	
Landscaping	Landscape Rake	Frontier	LR5048L	√	√	√	√	
Hay and Forage	Square Balers	John Deere	1424	√	√	√	√	
Hay and Forage	Square Balers	John Deere	1424C	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Hay and Forage	Square Balers	John Deere	1433	√	√	√	√	
Hay and Forage	Square Balers	John Deere	1433C	√	√	√	√	
Hay and Forage	Square Balers	John Deere	1434	√	√	√	√	
Hay and Forage	Square Balers	John Deere	1434C	√	√	√	√	
Planting and Seeding	seeders	GreenSystem	DC1102	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT1207	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT1004	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT1005	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT1015	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT1006	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT1016	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT1204	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT1214	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT1205	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT1215	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT1225	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT1206	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT1216	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT1226	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT1227	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT1228	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT1229	√	√	√	√	
Tillage	Cultivator	GreenSystem	RC1009	√	√	√	√	
Tillage	Cultivator	GreenSystem	RC1011	√	√	√	√	
Tillage	Cultivator	GreenSystem	RC1013	√	√	√	√	
Tillage	Cultivator	GreenSystem	RC1209	√	√	√	√	
Tillage	Cultivator	GreenSystem	RC1211	√	√	√	√	
Tillage	Cultivator	GreenSystem	RC1213	√	√	√	√	
Tillage	Cultivator	GreenSystem	SC1009	√	√	√	√	
Tillage	Cultivator	GreenSystem	SC1011	√	√	√	√	
Tillage	Cultivator	GreenSystem	SC1013	√	√	√	√	
Tillage	Cultivator	GreenSystem	SC1209	√	√	√	√	
Tillage	Cultivator	GreenSystem	SC1211	√	√	√	√	
Tillage	Cultivator	GreenSystem	SC1213	√	√	√	√	
Planting and Seeding	Drills	GreenSystem	SD1009	√	√	√	√	
Planting and Seeding	Drills	GreenSystem	SD1011	√	√	√	√	
Planting and Seeding	Drills	GreenSystem	SD1013	√	√	√	√	
Planting and Seeding	Drills	GreenSystem	SD1009G	√	√	√	√	
Planting and Seeding	Drills	GreenSystem	SD1011G	√	√	√	√	
Planting and Seeding	Drills	GreenSystem	SD1013G	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Mate. Hand Cut. and Shredders	Wagons	GreenSystem	FT1006	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	GreenSystem	FT1010	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	GreenSystem	TT1006	√	√	√	√	
Sprayers	Mounted Sprayers	GreenSystem	MS1004	√	√	√	√	
Sprayers	Mounted Sprayers	GreenSystem	MS1006	√	√	√	√	
Sprayers	Trailed Sprayers	GreenSystem	DS1120	√	√	√	√	
Mate. Hand Cut. and Shredders	Flail Shredders	GreenSystem	SS1001	√	√	√	√	
Axles	TM 5	John Deere	1500	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6110RC	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6100RC	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6090RC	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6110MC	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6100MC	√	√	√	√	
Tractors	2WD or MFWD - European	John Deere	6090MC	√	√	√	√	
Tillage	Moldboard Plows	GreenSystem	RP1105	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT3016	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT3018	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT3220	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT3223	√	√	√	√	
Sprayers	Mounted Sprayers	GreenSystem	MS2108	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB5010	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB5015	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB5020	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB5110	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB5115	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB5120	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB5210	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB5215	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	AB5220	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	MB6110	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	MB6115	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Sprayers	Orchard & Vineyard Sprayers	Frontier	MB6120	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	MB6210	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	MB6215	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	MB6220	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	2054	√	√	√	√	
Tillage	Disks	Frontier	DH5108	√	√	√	√	
Tillage	Disks	Frontier	DH5110	√	√	√	√	
Tillage	Disks	Frontier	DH5112	√	√	√	√	
Tillage	Disks	Frontier	DH5114	√	√	√	√	
Tillage	Disks	Frontier	DH5116	√	√	√	√	
Tillage	Disks	Frontier	DH5210	√	√	√	√	
Tillage	Disks	Frontier	DH5212	√	√	√	√	
Tillage	Disks	Frontier	DH5214	√	√	√	√	
Tillage	Disks	Frontier	DH5216	√	√	√	√	
Tillage	Disks	Frontier	DH5217	√	√	√	√	
Tillage	Disks	Frontier	DH5219	√	√	√	√	
Tillage	Disks	Frontier	DH5221	√	√	√	√	
Tillage	Disks	Frontier	DH5308	√	√	√	√	
Tillage	Disks	Frontier	DH5310	√	√	√	√	
Tillage	Disks	Frontier	DH5312	√	√	√	√	
Tillage	Disks	Frontier	DH5314	√	√	√	√	
Tillage	Disks	Frontier	DH5316	√	√	√	√	
Landscaping	Rear Mounted Blades	Frontier	RB5060	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5042D	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5047D	√	√	√	√	
Tractors	PIN prefix PY - India	John Deere	5050D	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5080GH	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5100G	√	√	√	√	
Tractors	PIN prefix AT - Italy	John Deere	5100GH	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1CC	John Deere	H310	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1CC	John Deere	H340	√	√	√	√	
Worksite Pro Attachment	Mulching Head	John Deere	MH60C	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5100M	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5115ML	√	√	√	√	
Tractors	PIN prefix LV - USA	John Deere	5100MH	√	√	√	√	
Hay and Forage	Rotary Harvesting Units	John Deere	778	√	√	√	√	
Hay and Forage	Rotary Harvesting Units	John Deere	460plus	√	√	√	√	
Combines and Headers	Combines PIN Prefix MY - India	John Deere	W70	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tillage	Disk Plows	GreenSystem	DP1003	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	GreenSystem	TT1005	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	ab5130	√	√	√	√	
Sprayers	Orchard & Vineyard Sprayers	Frontier	ab5230	√	√	√	√	
Planting and Seeding	Planters 740101-745000	John Deere	DB74	√	√	√	√	
Planting and Seeding	Planters 740101-745000	John Deere	DB50	√	√	√	√	
Planting and Seeding	Planters 745101-XXXXXX	John Deere	DB44	√	√	√	√	
Planting and Seeding	Planters 745101-XXXXXX	John Deere	DB66	√	√	√	√	
Planting and Seeding	Planters 745101-XXXXXX	John Deere	DB90	√	√	√	√	
Planting and Seeding	Planters 745101-XXXXXX	John Deere	DB58	√	√	√	√	
Planting and Seeding	Planters 745101-XXXXXX	John Deere	DB88	√	√	√	√	
Planting and Seeding	Planters 745101-XXXXXX	John Deere	DB120	√	√	√	√	
Planting and Seeding	Planters 745101-XXXXXX	John Deere	DB74	√	√	√	√	
Planting and Seeding	Planters 745101-XXXXXX	John Deere	DB50	√	√	√	√	
Planting and Seeding	Planters 745101-XXXXXX	John Deere	DB60 36 Row	√	√	√	√	
Planting and Seeding	Planters 745101-XXXXXX	John Deere	DB60 47 Row	√	√	√	√	
Planting and Seeding	Planters 745101-XXXXXX	John Deere	DB60 24 Row	√	√	√	√	
Mate. Hand Cut. and Shredders	ATRB BROOM	John Deere	60HD	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1P0	John Deere	H340	√	√	√	√	
Information Management	John Deere Mobile Weather	John Deere	AMS Mobile Weather	√	√	√	√	
Information Management	Harvest Identification, Cotton	John Deere	AMS Harv ID,Cotton	√	√	√	√	
Planting and Seeding	Planters 745101-XXXXXX	John Deere	DB80 32 Row	√	√	√	√	
Planting and Seeding	Planters 745101-XXXXXX	John Deere	DB80 48 Row	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractors	2WD or MFWD - PIN prefix YH	John Deere	2204	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix YH	John Deere	4104	√	√	√	√	
Tractors	2WD or MFWD - PIN prefix YH	John Deere	2854	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1P0	John Deere	H310	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders - PIN Prefix 1P0	John Deere	H260	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix JZ	John Deere	7830	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix JZ	John Deere	7930	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix JZ	John Deere	8285R	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix JZ	John Deere	8310R	√	√	√	√	
Tractors	4WD PIN Prefix JZ	John Deere	9410R	√	√	√	√	
Planting and Seeding	Planters 745101-XXXXXX	John Deere	1770NT 16ROW	√	√	√	√	
Planting and Seeding	Planters 745101-XXXXXX	John Deere	1790	√	√	√	√	
Planting and Seeding	Planters 745101-XXXXXX	John Deere	1770NT 12ROW	√	√	√	√	
Planting and Seeding	Planters 745101-XXXXXX	John Deere	1770NT 24ROW	√	√	√	√	
Tractors	2WD or MFWD - PIN Prefix 1BM - Brazil	John Deere	5090E	√	√	√	√	
Information Management	John Deere CropSense	John Deere	AMS JD CropSense	√	√	√	√	
Combines and Headers	Platforms PIN Prefix MY	John Deere	314	√	√	√	√	
Combines and Headers	Draper Platforms PIN Prefix 1CQ	John Deere	640FD	√	√	√	√	
Combines and Headers	Draper Platforms PIN Prefix 1CQ	John Deere	635FD	√	√	√	√	
Combines and Headers	Combines 1JZ 745100-XXXXXX	John Deere	S690	√	√	√	√	
Combines and Headers	Combines 1JZ 745100-XXXXXX	John Deere	S550	√	√	√	√	
Combines and Headers	Combines 1JZ 745100-XXXXXX	John Deere	S660	√	√	√	√	
Combines and Headers	Combines 1JZ 745100-XXXXXX	John Deere	S670	√	√	√	√	
Combines and Headers	Combines 1JZ 745100-XXXXXX	John Deere	S680	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Combines and Headers	Combines 1YH 745100-XXXXXX	John Deere	S690	√	√	√	√	
Combines and Headers	Combines 1YH 745100-XXXXXX	John Deere	S550	√	√	√	√	
Combines and Headers	Combines 1YH 745100-XXXXXX	John Deere	S660	√	√	√	√	
Combines and Headers	Combines 1YH 745100-XXXXXX	John Deere	S670	√	√	√	√	
Combines and Headers	Combines 1YH 745100-XXXXXX	John Deere	S680	√	√	√	√	
Hay and Forage	3 Meter Pickups	John Deere	639	√	√	√	√	
Hay and Forage	4 Meter Pickups	John Deere	649	√	√	√	√	
Hay and Forage	4.5 Meter Pickups	John Deere	659	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	HX6	√	√	√	√	
Mate. Hand Cut. and Shredders	Rotary Cutters	John Deere	HX7	√	√	√	√	
Tractors	PIN prefix 1PY - India	John Deere	5050E	√	√	√	√	
AG Management Solutions	John Deere Implement Detection	John Deere	AMS Impl Detection	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	JD550-1	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	JD554-1	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	JD600-1	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	JD604-1	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	JD650-1	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	JD654-1	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	JD700-1	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	JD704-1	√	√	√	√	
Planting and Seeding	Planters 740101-745000	John Deere	DB55	√	√	√	√	
Planting and Seeding	Planters 740101-745000	John Deere	DB37	√	√	√	√	
Planting and Seeding	Planters 740101-745000	John Deere	DB83 36 Row	√	√	√	√	
Planting and Seeding	Planters XXXXXX - 740100	John Deere	DB55	√	√	√	√	
Planting and Seeding	Planters XXXXXX - 740100	John Deere	DB37	√	√	√	√	
Planting and Seeding	Planters XXXXXX - 740100	John Deere	DB83 36 Row	√	√	√	√	
Planting and Seeding	Planters 745101-XXXXXX	John Deere	DB55	√	√	√	√	
Planting and Seeding	Planters 745101-XXXXXX	John Deere	DB37	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Planting and Seeding	Planters 745101-XXXXXX	John Deere	DB83 36 Row	√	√	√	√	
Tillage	Rotary Tiller	GreenSystem	RT4019	√	√	√	√	
Mate. Hand Cut. and Shredders	Wagons	GreenSystem	tt1003	√	√	√	√	
Mate. Hand Cut. and Shredders	Front Blade	GreenSystem	FB1018	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	5-904	√	√	√	√	
Crawler	Dozer	John Deere	850C	√	√	√	√	
4WD Loader	None	John Deere	644H	√	√	√	√	
4WD Loader	None	John Deere	744H	√	√	√	√	
4WD Loader	Material Handler	John Deere	744H MH	√	√	√	√	
Motor Grader	None	John Deere	670CH	√	√	√	√	
Motor Grader	HFWD	John Deere	672CH	√	√	√	√	
Motor Grader	None	John Deere	770CH	√	√	√	√	
Motor Grader	HFWD	John Deere	772CH	√	√	√	√	
Landscape Loader	None	John Deere	210C	√	√	√	√	
Landscape Loader	None	John Deere	210LE	√	√	√	√	
Tractor	Utility Construction	John Deere	300B	√	√	√	√	
Backhoe	None	John Deere	300D	√	√	√	√	
Tractor	Utility Construction	John Deere	302A	√	√	√	√	
Backhoe	None	John Deere	310	√	√	√	√	
Backhoe	None	John Deere	310A	√	√	√	√	
Backhoe	None	John Deere	310B	√	√	√	√	
Backhoe	None	John Deere	310C	√	√	√	√	
Backhoe	None	John Deere	310D	√	√	√	√	
Backhoe	None	John Deere	310E	√	√	√	√	
Backhoe	None	John Deere	310SE	√	√	√	√	
Backhoe	Side Shift	John Deere	315C	√	√	√	√	
Backhoe	Side Shift	John Deere	315D	√	√	√	√	
Backhoe	Side Shift	John Deere	315SE	√	√	√	√	
Tractor	Utility Construction	John Deere	401D	√	√	√	√	
Backhoe	None	John Deere	410	√	√	√	√	
Backhoe	None	John Deere	410B	√	√	√	√	
Backhoe	None	John Deere	410C	√	√	√	√	
Backhoe	None	John Deere	410D	√	√	√	√	
Backhoe	None	John Deere	410E	√	√	√	√	
Backhoe	None	John Deere	500A	√	√	√	√	
Backhoe	None	John Deere	500B	√	√	√	√	
Backhoe	None	John Deere	500C	√	√	√	√	
Backhoe	None	John Deere	510	√	√	√	√	
Backhoe	None	John Deere	510B	√	√	√	√	
Backhoe	None	John Deere	510C	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Backhoe	None	John Deere	510D	√	√	√	√	
Backhoe	None	John Deere	610B	√	√	√	√	
Backhoe	None	John Deere	610C	√	√	√	√	
Backhoe	None	John Deere	710B	√	√	√	√	
Backhoe	None	John Deere	710C	√	√	√	√	
Backhoe	None	John Deere	710D	√	√	√	√	
Feller Buncher	Track	John Deere	493D	√	√	√	√	
Feller Buncher	Wheeled	John Deere	643	√	√	√	√	
Feller Buncher	Wheeled	John Deere	643D	√	√	√	√	
Feller Buncher	Wheeled	John Deere	643G	√	√	√	√	
Feller Buncher	Track	John Deere	653E	√	√	√	√	
Feller Buncher	Track	John Deere	693B	√	√	√	√	
Feller Buncher	Track	John Deere	693C	√	√	√	√	
Feller Buncher	Track	John Deere	693D	√	√	√	√	
Feller Buncher	Track	John Deere	793D	√	√	√	√	
Feller Buncher	Wheeled	John Deere	843G	√	√	√	√	
Crawler	Dozer	John Deere	350	√	√	√	√	
Crawler	Dozer	John Deere	350B	√	√	√	√	
Crawler	Dozer	John Deere	350C	√	√	√	√	
Crawler	Dozer	John Deere	350D	√	√	√	√	
Crawler	Dozer	John Deere	350WT	√	√	√	√	
Crawler	Loader	John Deere	355D	√	√	√	√	
Crawler	Dozer	John Deere	400G	√	√	√	√	
Crawler	Dozer	John Deere	450	√	√	√	√	
Crawler	Dozer	John Deere	450B	√	√	√	√	
Crawler	Dozer	John Deere	450C	√	√	√	√	
Crawler	Dozer	John Deere	450D	√	√	√	√	
Crawler	Dozer	John Deere	450E	√	√	√	√	
Crawler	Dozer	John Deere	450G	√	√	√	√	
Crawler	Dozer	John Deere	450H	√	√	√	√	
Crawler	Loader	John Deere	455D	√	√	√	√	
Crawler	Loader	John Deere	455E	√	√	√	√	
Crawler	Loader	John Deere	455G	√	√	√	√	
Crawler	Dozer	John Deere	550	√	√	√	√	
Crawler	Dozer	John Deere	550A	√	√	√	√	
Crawler	Dozer	John Deere	550B	√	√	√	√	
Crawler	Dozer	John Deere	550G	√	√	√	√	
Crawler	Dozer	John Deere	550H	√	√	√	√	
Crawler	Loader	John Deere	555	√	√	√	√	
Crawler	Loader	John Deere	555A	√	√	√	√	
Crawler	Loader	John Deere	555B	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Crawler	Loader	John Deere	555G	√	√	√	√	
Crawler	Dozer	John Deere	650G	√	√	√	√	
Crawler	Dozer	John Deere	650H	√	√	√	√	
Crawler	Loader	John Deere	655	√	√	√	√	
Crawler	Loader	John Deere	655B	√	√	√	√	
Crawler	Dozer	John Deere	750	√	√	√	√	
Crawler	Dozer	John Deere	750B	√	√	√	√	
Crawler	Dozer	John Deere	750C	√	√	√	√	
Crawler	Dozer	John Deere	750WT	√	√	√	√	
Crawler	Loader	John Deere	755	√	√	√	√	
Crawler	Loader	John Deere	755A	√	√	√	√	
Crawler	Loader	John Deere	755B	√	√	√	√	
Crawler	Dozer	John Deere	850	√	√	√	√	
Crawler	Dozer	John Deere	850B	√	√	√	√	
Crawler	Loader	John Deere	855	√	√	√	√	
Excavator	None	John Deere	110	√	√	√	√	
Excavator	None	John Deere	120	√	√	√	√	
Excavator	None	John Deere	160LC	√	√	√	√	
Excavator	None	John Deere	190E	√	√	√	√	
Excavator	None	John Deere	200LC	√	√	√	√	
Excavator	None	John Deere	230LC	√	√	√	√	
Excavator	None	John Deere	270LC	√	√	√	√	
Excavator	None	John Deere	290D	√	√	√	√	
Excavator	None	John Deere	30	√	√	√	√	
Excavator	None	John Deere	330LC	√	√	√	√	
Excavator	None	John Deere	450LC	√	√	√	√	
Excavator	None	John Deere	490	√	√	√	√	
Excavator	None	John Deere	490D	√	√	√	√	
Excavator	None	John Deere	490E	√	√	√	√	
Excavator	Wheeled	John Deere	495D	√	√	√	√	
Excavator	None	John Deere	50	√	√	√	√	
Excavator	None	John Deere	590D	√	√	√	√	
Excavator	Wheeled	John Deere	595	√	√	√	√	
Excavator	Wheeled	John Deere	595D	√	√	√	√	
Excavator	None	John Deere	690	√	√	√	√	
Excavator	None	John Deere	690A	√	√	√	√	
Excavator	None	John Deere	690B	√	√	√	√	
Excavator	None	John Deere	690C	√	√	√	√	
Excavator	Wheeled	John Deere	690CR	√	√	√	√	
Excavator	None	John Deere	690D	√	√	√	√	
Excavator	None	John Deere	690ELC	√	√	√	√	
Excavator	None	John Deere	70	√	√	√	√	
Excavator	None	John Deere	70D	√	√	√	√	
Excavator	None	John Deere	790	√	√	√	√	
Excavator	None	John Deere	790DLC	√	√	√	√	
Excavator	None	John Deere	790ELC	√	√	√	√	
Excavator	None	John Deere	792	√	√	√	√	
Excavator	None	John Deere	792DLC	√	√	√	√	
Excavator	None	John Deere	80	√	√	√	√	
Excavator	None	John Deere	890	√	√	√	√	
Excavator	None	John Deere	890A	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Excavator	None	John Deere	892DLC	√	√	√	√	
Excavator	None	John Deere	892ELC	√	√	√	√	
Excavator	None	John Deere	990	√	√	√	√	
Excavator	None	John Deere	992DLC	√	√	√	√	
Excavator	None	John Deere	992ELC	√	√	√	√	
Forklift	None	John Deere	380	√	√	√	√	
Forklift	None	John Deere	480	√	√	√	√	
Forklift	None	John Deere	480A	√	√	√	√	
Forklift	None	John Deere	480B	√	√	√	√	
Forklift	None	John Deere	480C	√	√	√	√	
Forklift	None	John Deere	482C	√	√	√	√	
Forklift	None	John Deere	485E	√	√	√	√	
Forklift	None	John Deere	486E	√	√	√	√	
Forklift	None	John Deere	488E	√	√	√	√	
4WD Loader	None	John Deere	244E	√	√	√	√	
4WD Loader	None	John Deere	244H	√	√	√	√	
4WD Loader	None	John Deere	344E	√	√	√	√	
4WD Loader	None	John Deere	344G	√	√	√	√	
4WD Loader	None	John Deere	344H	√	√	√	√	
4WD Loader	None	John Deere	444	√	√	√	√	
4WD Loader	None	John Deere	444C	√	√	√	√	
4WD Loader	None	John Deere	444CH	√	√	√	√	
4WD Loader	None	John Deere	444D	√	√	√	√	
4WD Loader	None	John Deere	444E	√	√	√	√	
4WD Loader	None	John Deere	444G	√	√	√	√	
4WD Loader	None	John Deere	444H	√	√	√	√	
4WD Loader	None	John Deere	544	√	√	√	√	
4WD Loader	None	John Deere	544A	√	√	√	√	
4WD Loader	None	John Deere	544B	√	√	√	√	
4WD Loader	None	John Deere	544C	√	√	√	√	
4WD Loader	None	John Deere	544D	√	√	√	√	
4WD Loader	None	John Deere	544E	√	√	√	√	
4WD Loader	None	John Deere	544G	√	√	√	√	
4WD Loader	None	John Deere	544GH	√	√	√	√	
4WD Loader	None	John Deere	544H	√	√	√	√	
4WD Loader	None	John Deere	624E	√	√	√	√	
4WD Loader	None	John Deere	624G	√	√	√	√	
4WD Loader	None	John Deere	624H	√	√	√	√	
4WD Loader	None	John Deere	644	√	√	√	√	
4WD Loader	None	John Deere	644A	√	√	√	√	
4WD Loader	None	John Deere	644B	√	√	√	√	
4WD Loader	None	John Deere	644C	√	√	√	√	
4WD Loader	None	John Deere	644D	√	√	√	√	
4WD Loader	None	John Deere	644E	√	√	√	√	
4WD Loader	None	John Deere	644G	√	√	√	√	
4WD Loader	None	John Deere	744E	√	√	√	√	
4WD Loader	None	John Deere	84	√	√	√	√	
4WD Loader	None	John Deere	844	√	√	√	√	
4WD Loader	Tool Carrier	John Deere	TC44H	√	√	√	√	
4WD Loader	Tool Carrier	John Deere	TC54H	√	√	√	√	
4WD Loader	Tool Carrier	John Deere	TC62H	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Motor Grader	None	John Deere	570	√	√	√	√	
Motor Grader	None	John Deere	570A	√	√	√	√	
Motor Grader	None	John Deere	570B	√	√	√	√	
Motor Grader	None	John Deere	670	√	√	√	√	
Motor Grader	None	John Deere	670A	√	√	√	√	
Motor Grader	None	John Deere	670B	√	√	√	√	
Motor Grader	None	John Deere	670C	√	√	√	√	
Motor Grader	HFWD	John Deere	672A	√	√	√	√	
Motor Grader	HFWD	John Deere	672B	√	√	√	√	
Motor Grader	None	John Deere	770	√	√	√	√	
Motor Grader	None	John Deere	770A	√	√	√	√	
Motor Grader	None	John Deere	770AH	√	√	√	√	
Motor Grader	None	John Deere	770B	√	√	√	√	
Motor Grader	None	John Deere	770BH	√	√	√	√	
Motor Grader	None	John Deere	770C	√	√	√	√	
Motor Grader	HFWD	John Deere	772A	√	√	√	√	
Motor Grader	HFWD	John Deere	772AH	√	√	√	√	
Motor Grader	HFWD	John Deere	772B	√	√	√	√	
Motor Grader	HFWD	John Deere	772BH	√	√	√	√	
Scraper	None	John Deere	760	√	√	√	√	
Scraper	None	John Deere	760A	√	√	√	√	
Scraper	None	John Deere	762	√	√	√	√	
Scraper	None	John Deere	762A	√	√	√	√	
Scraper	None	John Deere	762B	√	√	√	√	
Scraper	None	John Deere	762B-II	√	√	√	√	
Scraper	None	John Deere	860	√	√	√	√	
Scraper	None	John Deere	860A	√	√	√	√	
Scraper	None	John Deere	860B	√	√	√	√	
Scraper	None	John Deere	862	√	√	√	√	
Scraper	None	John Deere	862B	√	√	√	√	
Skidder	Cable	John Deere	340D	√	√	√	√	
Skidder	None	John Deere	440	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Skidder	None	John Deere	440A	√	√	√	√	
Skidder	None	John Deere	440B	√	√	√	√	
Skidder	None	John Deere	440C	√	√	√	√	
Skidder	Cable	John Deere	440D	√	√	√	√	
Skidder	Grapple	John Deere	448D	√	√	√	√	
Skidder	None	John Deere	540	√	√	√	√	
Skidder	None	John Deere	540A	√	√	√	√	
Skidder	None	John Deere	540B	√	√	√	√	
Skidder	Cable	John Deere	540D	√	√	√	√	
Skidder	Cable	John Deere	540E	√	√	√	√	
Skidder	Cable	John Deere	540G	√	√	√	√	
Skidder	Cable	John Deere	540G-II	√	√	√	√	
Skidder	Grapple	John Deere	548D	√	√	√	√	
Skidder	Grapple	John Deere	548E	√	√	√	√	
Skidder	Grapple	John Deere	548G	√	√	√	√	
Skidder	Grapple	John Deere	548G-II	√	√	√	√	
Skidder	None	John Deere	640	√	√	√	√	
Skidder	Cable	John Deere	640D	√	√	√	√	
Skidder	Cable	John Deere	640E	√	√	√	√	
Skidder	Cable	John Deere	640G	√	√	√	√	
Skidder	Cable	John Deere	640G-II	√	√	√	√	
Skidder	Grapple	John Deere	648D	√	√	√	√	
Skidder	Grapple	John Deere	648E	√	√	√	√	
Skidder	Grapple	John Deere	648G	√	√	√	√	
Skidder	Grapple	John Deere	648G-II	√	√	√	√	
Skidder	None	John Deere	740	√	√	√	√	
Skidder	None	John Deere	740A	√	√	√	√	
Skidder	Cable	John Deere	740E	√	√	√	√	
Skidder	Cable	John Deere	740G	√	√	√	√	
Skidder	Grapple	John Deere	748E	√	√	√	√	
Skidder	Grapple	John Deere	748G	√	√	√	√	
Skidder	Grapple	John Deere	748G-II	√	√	√	√	
Tractor	Utility Construction	John Deere	301	√	√	√	√	
Tractor	Utility Construction	John Deere	301A	√	√	√	√	
Tractor	Utility Construction	John Deere	302	√	√	√	√	
Tractor	Utility Construction	John Deere	401	√	√	√	√	
Tractor	Utility Construction	John Deere	401B	√	√	√	√	
Tractor	Utility Construction	John Deere	401C	√	√	√	√	
Compactor	None	John Deere	646	√	√	√	√	
Compactor	None	John Deere	646B	√	√	√	√	
Compactor	None	John Deere	646C	√	√	√	√	
Tree Harvester	Wheeled	John Deere	743	√	√	√	√	
Tree Harvester	Wheeled	John Deere	743A	√	√	√	√	
Crawler	Dozer	John Deere	1010	√	√	√	√	
Crawler	Dozer	John Deere	2010	√	√	√	√	
Backhoe	Side Shift	John Deere	315CH	√	√	√	√	
OEM Winch	None	John Deere	40	√	√	√	√	
Winch	None	John Deere	4000	√	√	√	√	
Backhoe	Side Shift	John Deere	415B	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Skidder	Grapple	John Deere	440CGS	√	√	√	√	
Crawler	Dozer	John Deere	450ELT	√	√	√	√	
Backhoe	Side Shift	John Deere	515B	√	√	√	√	
Skidder	Grapple	John Deere	540BGS	√	√	√	√	
4WD Loader	Feller Buncher	John Deere	544CFB	√	√	√	√	
4WD Loader	Feller Buncher	John Deere	544DFB	√	√	√	√	
4WD Loader	None	John Deere	544DH	√	√	√	√	
4WD Loader	None	John Deere	544EH	√	√	√	√	
4WD Loader	Log Loader	John Deere	544ELL	√	√	√	√	
4WD Loader	Tool Carrier	John Deere	544ETC	√	√	√	√	
4WD Loader	Log Loader	John Deere	544GL	√	√	√	√	
4WD Loader	Tool Carrier	John Deere	544GT	√	√	√	√	
4WD Loader	None	John Deere	624EH	√	√	√	√	
Skidder	Grapple	John Deere	640GS	√	√	√	√	
4WD Loader	None	John Deere	644EH	√	√	√	√	
4WD Loader	None	John Deere	644ER	√	√	√	√	
Excavator	Wheeled	John Deere	690DR	√	√	√	√	
Skidder	Grapple	John Deere	740AGS	√	√	√	√	
Skidder	Grapple	John Deere	740GS	√	√	√	√	
Crawler	Dozer	John Deere	750BLT	√	√	√	√	
Scraper	Prime Mover	John Deere	862PM	√	√	√	√	
4WD Loader	Material Handler	John Deere	644H MH	√	√	√	√	
Excavator	None	John Deere	370	√	√	√	√	
Excavator	None	John Deere	550LC	√	√	√	√	
Excavator	None	John Deere	750	√	√	√	√	
Truck	Articulated Dump	John Deere	250C	√	√	√	√	
Truck	Articulated Dump	John Deere	300C	√	√	√	√	
Truck	Articulated Dump	John Deere	350C	√	√	√	√	
Truck	Articulated Dump	John Deere	400C	√	√	√	√	
Feller Buncher	Track	John Deere	653G	√	√	√	√	
Scraper	None	John Deere	862B-II	√	√	√	√	
4WD Loader	None	John Deere	304H	√	√	√	√	
4WD Loader	None	John Deere	324H	√	√	√	√	
Crawler	Dozer	John Deere	700H	√	√	√	√	
Skidder	Cable XXXXXX-613178	John Deere	540G-III	√	√	√	√	
Skidder	Grapple XXXXXX-613178	John Deere	548G-III	√	√	√	√	
Skidder	Cable	John Deere	640G-III	√	√	√	√	
Skidder	Grapple	John Deere	648G-III	√	√	√	√	
Skidder	Grapple	John Deere	748G-III	√	√	√	√	
Feller Buncher	Wheeled	John Deere	643H	√	√	√	√	
Feller Buncher	Wheeled	John Deere	843H	√	√	√	√	
Logger	None	John Deere	200LC	√	√	√	√	
Logger	None	John Deere	330LC	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Logger	None	John Deere	370	√	√	√	√	
Truck	Articulated Dump	BELL	B25C	√	√	√	√	
Truck	Articulated Dump	BELL	B30C	√	√	√	√	
Truck	Articulated Dump	BELL	B35C	√	√	√	√	
Truck	Articulated Dump	BELL	B40C	√	√	√	√	
Feller Buncher	Track	John Deere	753G	√	√	√	√	
Feller Buncher	Track	John Deere	753GL	√	√	√	√	
Feller Buncher	Track	John Deere	853G	√	√	√	√	
Log Loader	Trailer Mount	John Deere	335	√	√	√	√	
Log Loader	Trailer Mount	John Deere	435	√	√	√	√	
Backhoe	None	John Deere	310G	√	√	√	√	
Backhoe	None	John Deere	310SG	√	√	√	√	
Backhoe	None	John Deere	410G	√	√	√	√	
Backhoe	Side Shift	John Deere	315SG	√	√	√	√	
Log Loader	Trailer Mount	John Deere	535	√	√	√	√	
Excavator	None	John Deere	450CLC	√	√	√	√	
Skidder	Grapple	John Deere	848G	√	√	√	√	
Harvester	Track	John Deere	753G	√	√	√	√	
Harvester	Track	John Deere	753GL	√	√	√	√	
Excavator	None	John Deere	800C	√	√	√	√	
Excavator	None	John Deere	600CLC	√	√	√	√	
Excavator	None	John Deere	200CLC	√	√	√	√	
Excavator	None	John Deere	230CLC	√	√	√	√	
Forwarder	Wheeled	John Deere	1058	√	√	√	√	
Forwarder	Wheeled	John Deere	1158	√	√	√	√	
Crawler	Dozer	John Deere	1050C	√	√	√	√	
Crawler	Loader	John Deere	655C	√	√	√	√	
Crawler	Loader	John Deere	755C	√	√	√	√	
Feller Buncher	Track	John Deere	953G	√	√	√	√	
Excavator	None	John Deere	270CLC	√	√	√	√	
Excavator	None	John Deere	370C	√	√	√	√	
Excavator	None	John Deere	330CLC	√	√	√	√	
Harvester	Wheeled	John Deere	1263	√	√	√	√	
Forwarder	Wheeled	John Deere	1458	√	√	√	√	
Forwarder	Wheeled	John Deere	1758	√	√	√	√	
Motor Grader	HFWD	John Deere	672CH Series II	√	√	√	√	
Motor Grader	HFWD	John Deere	772CH Series II	√	√	√	√	
Harvester	Wheeled	John Deere	1063	√	√	√	√	
Truck	Articulated Dump XXXXXX - 608489	John Deere	350D	√	√	√	√	
Truck	Articulated Dump XXXXXX - 608489	John Deere	400D	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Motor Grader	None	John Deere	670C Series II	√	√	√	√	
Motor Grader	None	John Deere	670CH Series II	√	√	√	√	
Motor Grader	None	John Deere	770C Series II	√	√	√	√	
Motor Grader	None	John Deere	770CH Series II	√	√	√	√	
Logger	Delimber	John Deere	2054	√	√	√	√	
Logger	Harvester	John Deere	2054	√	√	√	√	
Logger	Log Loader	John Deere	2054	√	√	√	√	
Logger	Road Builder	John Deere	2054	√	√	√	√	
Excavator	None	John Deere	120C	√	√	√	√	
Truck	Articulated Dump XXXXXX-609165	John Deere	300D	√	√	√	√	
Truck	Articulated Dump XXXXXX-609165	John Deere	250D	√	√	√	√	
Excavator	None	HITACHI	Zaxis330LC	√	√	√	√	
Excavator	None	HITACHI	Zaxis120	√	√	√	√	
Excavator	None	HITACHI	Zaxis160LC	√	√	√	√	
Excavator	None	HITACHI	Zaxis800	√	√	√	√	
Truck	Articulated Dump	HITACHI	AH350D	√	√	√	√	
Truck	Articulated Dump	HITACHI	AH400D	√	√	√	√	
Excavator	None	HITACHI	EX100	√	√	√	√	
Excavator	None	HITACHI	EX100-2	√	√	√	√	
Excavator	None	HITACHI	EX100-3	√	√	√	√	
Excavator	None	HITACHI	EX110-5	√	√	√	√	
Excavator	None	HITACHI	EX120-5	√	√	√	√	
Excavator	None	HITACHI	EX100M-3	√	√	√	√	
Excavator	None	HITACHI	EX200	√	√	√	√	
Excavator	None	HITACHI	EX150	√	√	√	√	
Excavator	None	HITACHI	EX160LC-5	√	√	√	√	
Excavator	None	HITACHI	EX230LC-5	√	√	√	√	
Excavator	None	HITACHI	EX200LC-5	√	√	√	√	
Excavator	Compact	HITACHI	EX27u	√	√	√	√	
Excavator	None	HITACHI	EX270LC-5	√	√	√	√	
Excavator	None	HITACHI	EX270	√	√	√	√	
Excavator	Compact	HITACHI	EX35u	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Excavator	None	HITACHI	EX370-5	√	√	√	√	
Excavator	None	HITACHI	EX450LC-5	√	√	√	√	
Excavator	Compact	HITACHI	EX50u	√	√	√	√	
Excavator	None	HITACHI	EX550LC-5	√	√	√	√	
Excavator	None	HITACHI	EX330LC-5	√	√	√	√	
Excavator	None	HITACHI	EX700	√	√	√	√	
Excavator	None	HITACHI	EX80-5	√	√	√	√	
Excavator	None	HITACHI	UH083	√	√	√	√	
Excavator	None	HITACHI	UH123	√	√	√	√	
Excavator	None	HITACHI	UH181	√	√	√	√	
Excavator	None	John Deere	80C	√	√	√	√	
Logger	Delimber	John Deere	2554	√	√	√	√	
Logger	Log Loader	John Deere	2554	√	√	√	√	
Logger	Road Builder	John Deere	2554	√	√	√	√	
Logger	Harvester	John Deere	2554	√	√	√	√	
Excavator	None	HITACHI	EX200-2	√	√	√	√	
Excavator	None	HITACHI	EX200-3	√	√	√	√	
Excavator	None	HITACHI	EX400-3	√	√	√	√	
Excavator	None	HITACHI	EX400-3C	√	√	√	√	
Excavator	None	HITACHI	EX550-3	√	√	√	√	
Excavator	None	HITACHI	UH122	√	√	√	√	
Excavator	None	HITACHI	EX300-2	√	√	√	√	
Excavator	None	HITACHI	EX300-3	√	√	√	√	
Excavator	None	HITACHI	EX300-3C	√	√	√	√	
Excavator	None	HITACHI	EX400	√	√	√	√	
Forester	Delimber	HITACHI	EX330LC-5	√	√	√	√	
Forester	Harvester	HITACHI	EX330LC-5	√	√	√	√	
Forester	Log Loader	HITACHI	EX330LC-5	√	√	√	√	
Forester	Road Builder	HITACHI	EX330LC-5	√	√	√	√	
Forester	Delimber	HITACHI	EX370-5	√	√	√	√	
Forester	Harvester	HITACHI	EX370-5	√	√	√	√	
Forester	Log Loader	HITACHI	EX370-5	√	√	√	√	
Forester	Road Builder	HITACHI	EX370-5	√	√	√	√	
Forester	Delimber	HITACHI	Zaxis250	√	√	√	√	
Forester	Log Loader	HITACHI	Zaxis250	√	√	√	√	
Forester	Road Builder	HITACHI	Zaxis250	√	√	√	√	
Forester	Harvester	HITACHI	Zaxis250	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Excavator	RTS	HITACHI	Zaxis135US	√	√	√	√	
Excavator	Compact	HITACHI	Zaxis27u	√	√	√	√	
Excavator	Compact	HITACHI	Zaxis35u	√	√	√	√	
Excavator	Compact	HITACHI	Zaxis50u	√	√	√	√	
Forester	Delimber	HITACHI	Zaxis200LC	√	√	√	√	
Forester	Harvester	HITACHI	Zaxis200LC	√	√	√	√	
Forester	Log Loader	HITACHI	Zaxis200LC	√	√	√	√	
Forester	Road Builder	HITACHI	Zaxis200LC	√	√	√	√	
Excavator	None	HITACHI	Zaxis200LC	√	√	√	√	
Excavator	None	HITACHI	Zaxis270LC	√	√	√	√	
Excavator	None	HITACHI	Zaxis370	√	√	√	√	
Excavator	None	John Deere	160CLC	√	√	√	√	
Backhoe	None	John Deere	710G	√	√	√	√	
4WD Loader	None	John Deere	744J	√	√	√	√	
4WD Loader	None	John Deere	824J	√	√	√	√	
Skidder	Cable	TIMBERJACK	360D	√	√	√	√	
Skidder	Single Arch Grapple	TIMBERJACK	360D	√	√	√	√	
Skidder	Cable	TIMBERJACK	460D	√	√	√	√	
Skidder	Grapple	TIMBERJACK	460D	√	√	√	√	
Skidder	Grapple	TIMBERJACK	560D	√	√	√	√	
Crawler	Dozer	John Deere	950C	√	√	√	√	
Excavator	RTS	John Deere	135C RTS	√	√	√	√	
Excavator	RTS	John Deere	225CLC RTS	√	√	√	√	
Skidder	Grapple	TIMBERJACK	660D	√	√	√	√	
Logger	Delimber	John Deere	3554	√	√	√	√	
Logger	Log Loader	John Deere	3554	√	√	√	√	
Logger	Road Builder	John Deere	3554	√	√	√	√	
Logger	Harvester	John Deere	3554	√	√	√	√	
Forester	Delimber	HITACHI	Zaxis350	√	√	√	√	
Forester	Log Loader	HITACHI	Zaxis350	√	√	√	√	
Forester	Road Builder	HITACHI	Zaxis350	√	√	√	√	
Forester	Harvester	HITACHI	Zaxis350	√	√	√	√	
Excavator	Wheeled	HITACHI	Zaxis210W	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Excavator	None	HITACHI	Zaxis450LC	√	√	√	√	
Excavator	None	HITACHI	Zaxis600LC	√	√	√	√	
Truck	Articulated Dump	HITACHI	AH300	√	√	√	√	
Truck	Articulated Dump	HITACHI	AH350	√	√	√	√	
Truck	Articulated Dump	HITACHI	AH400	√	√	√	√	
Feller Buncher	Track	TIMBERJACK	850	√	√	√	√	
Feller Buncher	Track	TIMBERJACK	950	√	√	√	√	
Harvester	Wheeled	TIMBERJACK	1070D	√	√	√	√	
Harvester	Wheeled	TIMBERJACK	1270D	√	√	√	√	
Forwarder	Wheeled	TIMBERJACK	1010D	√	√	√	√	
Forwarder	Wheeled	TIMBERJACK	1410D	√	√	√	√	
Forwarder	Wheeled	TIMBERJACK	1710D	√	√	√	√	
Forwarder	Wheeled	TIMBERJACK	810D	√	√	√	√	
Feller Buncher	Track	TIMBERJACK	608L	√	√	√	√	
Feller Buncher	Track	TIMBERJACK	608S	√	√	√	√	
Harvester	Track	TIMBERJACK	608L	√	√	√	√	
Forwarder	Wheeled	TIMBERJACK	1110D	√	√	√	√	
Harvester	Wheeled	TIMBERJACK	770D	√	√	√	√	
Felling Head	Disc Saw	TIMBERJACK	FD45	√	√	√	√	
Felling Head	Shear	TIMBERJACK	FB20	√	√	√	√	
Felling Head	Disc Saw	TIMBERJACK	FD18	√	√	√	√	
Felling Head	Disc Saw	TIMBERJACK	FD21	√	√	√	√	
Felling Head	Disc Saw	TIMBERJACK	FD22	√	√	√	√	
Felling Head	Disc Saw	TIMBERJACK	FG18	√	√	√	√	
Felling Head	Disc Saw	TIMBERJACK	FG22	√	√	√	√	
Felling Head	Disc Saw	TIMBERJACK	FS20	√	√	√	√	
Felling Head	Disc Saw	TIMBERJACK	FS24	√	√	√	√	
Bundler	Wheeled	TIMBERJACK	1490D	√	√	√	√	
Log Loader	Trailer Mount	TIMBERJACK	330	√	√	√	√	
Log Loader	Trailer Mount	TIMBERJACK	330B	√	√	√	√	
Log Loader	Trailer Mount	TIMBERJACK	430B	√	√	√	√	
Log Loader	Trailer Mount	TIMBERJACK	530	√	√	√	√	
Feller Buncher	Track	TIMBERJACK	608B	√	√	√	√	
Harvester	Track	TIMBERJACK	608B	√	√	√	√	
Harvester	Track	TIMBERJACK	608S	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Log Loader	Trailer Mount	TIMBERJACK	430B Series II	√	√	√	√	
Log Loader	Trailer Mount	John Deere	435 Series II	√	√	√	√	
Delimber	Dual Axis	TIMBERJACK	D245	√	√	√	√	
Feller Buncher	Track	John Deere	903G	√	√	√	√	
Feller Buncher	Track	TIMBERJACK	900	√	√	√	√	
4WD Loader	None	John Deere	444J	√	√	√	√	
4WD Loader	None	John Deere	544J	√	√	√	√	
4WD Loader	None	John Deere	624J	√	√	√	√	
4WD Loader	None	John Deere	644J	√	√	√	√	
Excavator	None	HITACHI	EX100-5	√	√	√	√	
Excavator	Backhoe	HITACHI	EX1200-5	√	√	√	√	
Excavator	Shovel	HITACHI	EX1200-5	√	√	√	√	
Truck	Articulated Dump	HITACHI	AH250	√	√	√	√	
Excavator	RTS	HITACHI	Zaxis225USLC	√	√	√	√	
Excavator	Backhoe	HITACHI	EX1900-5	√	√	√	√	
Excavator	Shovel	HITACHI	EX1900-5	√	√	√	√	
Excavator	Backhoe	HITACHI	EX2500-5	√	√	√	√	
Excavator	Shovel	HITACHI	EX2500-5	√	√	√	√	
Excavator	Backhoe	HITACHI	EX3600-5	√	√	√	√	
Excavator	Shovel	HITACHI	EX3600-5	√	√	√	√	
Excavator	Backhoe	HITACHI	EX5500-5	√	√	√	√	
Excavator	Shovel	HITACHI	EX5500-5	√	√	√	√	
Excavator	None	HITACHI	Zaxis80	√	√	√	√	
Excavator	None	HITACHI	Zaxis230LC	√	√	√	√	
Excavator	None	HITACHI	EX750-5	√	√	√	√	
Excavator	Backhoe	HITACHI	EX1100-3	√	√	√	√	
Excavator	Backhoe	HITACHI	EX1000	√	√	√	√	
Excavator	Shovel	HITACHI	EX1000	√	√	√	√	
Excavator	Backhoe	HITACHI	EX1100	√	√	√	√	
Excavator	Shovel	HITACHI	EX1100	√	√	√	√	
Excavator	None	HITACHI	EX220	√	√	√	√	
Excavator	Backhoe	HITACHI	EX2500	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Excavator	Shovel	HITACHI	EX2500	√	√	√	√	
Excavator	Backhoe	HITACHI	EX5500	√	√	√	√	
Excavator	Shovel	HITACHI	EX5500	√	√	√	√	
Excavator	Wheeled	HITACHI	EX100WD	√	√	√	√	
Excavator	None	HITACHI	EX300	√	√	√	√	
Excavator	Compact	HITACHI	EX17u	√	√	√	√	
Excavator	None	HITACHI	EX550	√	√	√	√	
Excavator	Backhoe	HITACHI	EX1800-2	√	√	√	√	
Excavator	Shovel	HITACHI	EX1800-2	√	√	√	√	
Excavator	Backhoe	HITACHI	EX3500-2	√	√	√	√	
Excavator	Shovel	HITACHI	EX3500-2	√	√	√	√	
Excavator	None	HITACHI	EX220-3	√	√	√	√	
Excavator	Backhoe	HITACHI	EX1800-3	√	√	√	√	
Excavator	Shovel	HITACHI	EX1800-3	√	√	√	√	
Excavator	Backhoe	HITACHI	EX3500-3	√	√	√	√	
Excavator	Shovel	HITACHI	EX3500-3	√	√	√	√	
Excavator	Shovel	HITACHI	EX1100-3	√	√	√	√	
Excavator	Backhoe	HITACHI	UH261	√	√	√	√	
Excavator	Shovel	HITACHI	UH261	√	√	√	√	
Excavator	Backhoe	HITACHI	UH501	√	√	√	√	
Excavator	Shovel	HITACHI	UH501	√	√	√	√	
Excavator	Backhoe	HITACHI	UH801	√	√	√	√	
Excavator	Shovel	HITACHI	UH801	√	√	√	√	
Excavator	None	HITACHI	UH02	√	√	√	√	
Excavator	None	HITACHI	UH062	√	√	√	√	
Excavator	None	HITACHI	UH07-3	√	√	√	√	
Excavator	None	HITACHI	UH121	√	√	√	√	
Excavator	None	HITACHI	UH171	√	√	√	√	
Excavator	None	HITACHI	UH172	√	√	√	√	
Excavator	None	HITACHI	UH20	√	√	√	√	
Excavator	None	HITACHI	UH081	√	√	√	√	
OEM Engines	Diesel	John Deere	3179	√	√	√	√	
OEM Engines	Diesel	John Deere	4239	√	√	√	√	
OEM Engines	Diesel	John Deere	6359	√	√	√	√	
OEM Engines	Diesel	John Deere	4276	√	√	√	√	
OEM Engines	Diesel	John Deere	6414	√	√	√	√	
OEM Engines	Diesel	John Deere	6466	√	√	√	√	
OEM Engines	Diesel	John Deere	6101	√	√	√	√	
Log Loader	Trailer Mount	TIMBERJACK	530B	√	√	√	√	
Log Loader	Trailer Mount	John Deere	535 Series II	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Slasher	Bar Saw	TIMBERJACK	S240	√	√	√	√	
Slasher	Bar Saw	TIMBERJACK	S260	√	√	√	√	
Motor Grader	None	John Deere	670D	√	√	√	√	
Motor Grader	HFWD	John Deere	672D	√	√	√	√	
Motor Grader	None	John Deere	770D	√	√	√	√	
Motor Grader	HFWD	John Deere	772D	√	√	√	√	
Motor Grader	HFWD	John Deere	872D	√	√	√	√	
Crawler	Dozer XXXXXX-159986	John Deere	450J	√	√	√	√	
Crawler	Dozer XXXXXX-159986	John Deere	550J	√	√	√	√	
Crawler	Dozer XXXXXX-159986	John Deere	650J	√	√	√	√	
Crawler	Dozer XXXXXX-139435	John Deere	700J	√	√	√	√	
Excavator	Shovel	HITACHI	EX1200-5C	√	√	√	√	
Excavator	Shovel	HITACHI	EX2500E-5	√	√	√	√	
Excavator	Backhoe	HITACHI	EX2500E-5	√	√	√	√	
Forwarder	Wheeled	John Deere	1010D	√	√	√	√	
Forwarder	Wheeled	John Deere	1110D	√	√	√	√	
Forwarder	Wheeled	John Deere	1410D	√	√	√	√	
Forwarder	Wheeled	John Deere	1710D	√	√	√	√	
Harvester	Wheeled	John Deere	1070D	√	√	√	√	
Harvester	Wheeled	John Deere	1270D	√	√	√	√	
Forwarder	Wheeled	TIMBERJACK	1010B	√	√	√	√	
Feller Buncher	Track	John Deere	759G	√	√	√	√	
Feller Buncher	Track	TIMBERJACK	759G	√	√	√	√	
Harvester	Track	John Deere	759GH	√	√	√	√	
Harvester	Track	TIMBERJACK	759GH	√	√	√	√	
Excavator	Wheeled	HITACHI	Zaxis180W	√	√	√	√	
Excavator	Wheeled	John Deere	180CW	√	√	√	√	
Excavator	Wheeled	John Deere	210CW	√	√	√	√	
Excavator	Compact	HITACHI	Zaxis35u-2	√	√	√	√	
Excavator	Compact	HITACHI	Zaxis50u-2	√	√	√	√	
Log Loader	Trailer Mount	John Deere	435C	√	√	√	√	
Log Loader	Trailer Mount	TIMBERJACK	435C	√	√	√	√	
Log Loader	Trailer Mount	John Deere	437C	√	√	√	√	
Log Loader	Trailer Mount	TIMBERJACK	437C	√	√	√	√	
Log Loader	Trailer Mount	John Deere	335C	√	√	√	√	
Log Loader	Trailer Mount	TIMBERJACK	335C	√	√	√	√	
Crawler	Dozer	John Deere	750J	√	√	√	√	
Crawler	Engine 6090HT001	John Deere	850J	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Motor Grader	None	John Deere	870D	√	√	√	√	
Feller Buncher	Track	John Deere	703G	√	√	√	√	
Feller Buncher	Track	John Deere	853J	√	√	√	√	
Feller Buncher	Track	John Deere	903J	√	√	√	√	
Feller Buncher	Track	John Deere	953J	√	√	√	√	
4WD Loader	None	John Deere	844J	√	√	√	√	
Feller Buncher	Wheeled	John Deere	643J	√	√	√	√	
Feller Buncher	Wheeled	John Deere	843J	√	√	√	√	
Felling Head	Disc Saw	John Deere	FD22B	√	√	√	√	
Felling Head	Disc Saw	John Deere	FS22B	√	√	√	√	
Harvester	Track	John Deere	703GH	√	√	√	√	
Feller Buncher	Wheeled	TIMBERJACK	740	√	√	√	√	
Feller Buncher	Wheeled	TIMBERJACK	840	√	√	√	√	
Forwarder	Wheeled	John Deere	810D	√	√	√	√	
Harvester	Wheeled	John Deere	770D	√	√	√	√	
Harvester	Wheeled	John Deere	1470D	√	√	√	√	
Harvester	Wheeled	TIMBERJACK	1470D	√	√	√	√	
Crawler	Loader	John Deere	605C	√	√	√	√	
Harvester Head	Bar Saw	TIMBERJACK	758HD	√	√	√	√	
Harvester Head	Bar Saw	TIMBERJACK	H742	√	√	√	√	
Harvester Head	Bar Saw	TIMBERJACK	H752	√	√	√	√	
Harvester Head	Bar Saw	John Deere	H270	√	√	√	√	
Harvester Head	Bar Saw	John Deere	H480	√	√	√	√	
Harvester Head	Bar Saw	TIMBERJACK	H762C	√	√	√	√	
Forwarder	Wheeled	John Deere	1711D	√	√	√	√	
Forwarder	Wheeled	TIMBERJACK	1711D	√	√	√	√	
Crawler	Dozer	John Deere	950J	√	√	√	√	
4WD Loader	None	John Deere	344J	√	√	√	√	
Backhoe	None	John Deere	310J	√	√	√	√	
Backhoe	None	John Deere	310SJ	√	√	√	√	
Backhoe	None	John Deere	410J	√	√	√	√	
Backhoe	None	John Deere	710J	√	√	√	√	
Excavator	None	John Deere	650DLC	√	√	√	√	
Excavator	None	John Deere	450DLC	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Excavator	None	John Deere	850DLC	√	√	√	√	
Excavator	None	John Deere	240DLC	√	√	√	√	
Excavator	None	John Deere	270DLC	√	√	√	√	
Excavator	None	John Deere	350DLC	√	√	√	√	
Excavator	None	HITACHI	Zaxis240LC-3	√	√	√	√	
Excavator	None	HITACHI	Zaxis270LC-3	√	√	√	√	
Excavator	None	HITACHI	Zaxis350LC-3	√	√	√	√	
Excavator	None	HITACHI	Zaxis450LC-3	√	√	√	√	
Excavator	None	HITACHI	Zaxis650LC-3	√	√	√	√	
Excavator	None	HITACHI	Zaxis850LC-3	√	√	√	√	
Backhoe	TMC	John Deere	410J TC	√	√	√	√	
Harvester Head	Bar Saw	TIMBERJACK	745	√	√	√	√	
Excavator	Backhoe	HITACHI	EX1200-5D	√	√	√	√	
Excavator	Shovel	HITACHI	EX1200-5D	√	√	√	√	
Excavator	RTS	John Deere	75C	√	√	√	√	
Truck	Rigid Frame	Euclid	EH750-3	√	√	√	√	
Truck	Rigid Frame	Euclid	EH1100-3	√	√	√	√	
Truck	Rigid Frame	Euclid	EH700-2	√	√	√	√	
Excavator	RTS	HITACHI	Zaxis75US	√	√	√	√	
Truck	Rigid Frame	Euclid	EH750-2	√	√	√	√	
Feller Buncher	Track	John Deere	909J	√	√	√	√	
Feller Buncher	Track	John Deere	959J	√	√	√	√	
Truck	Articulated Dump 608490 - XXXXXX	John Deere	350D	√	√	√	√	
Truck	Articulated Dump 608490 - XXXXXX	John Deere	400D	√	√	√	√	
Winch	None	John Deere	4000S	√	√	√	√	
Excavator	Compact	HITACHI	Zaxis27u-2	√	√	√	√	
Truck	Articulated Dump 609166-XXXXXX	John Deere	250D	√	√	√	√	
Truck	Articulated Dump 609166-XXXXXX	John Deere	300D	√	√	√	√	
Crawler	Loader	John Deere	755D	√	√	√	√	
Crawler	Dozer	John Deere	1050J	√	√	√	√	
Excavator	None	John Deere	225DLC	√	√	√	√	
Excavator	Compact	HITACHI	Zaxis17u-2	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Backhoe	TMC	John Deere	310SJ	√	√	√	√	
Backhoe	TMC	John Deere	310SJ TC	√	√	√	√	
Backhoe	TMC	John Deere	410J	√	√	√	√	
Excavator	None	John Deere	200DLC	√	√	√	√	
Excavator	None	John Deere	160DLC	√	√	√	√	
Excavator	None	HITACHI	Zaxis200LC-3	√	√	√	√	
Excavator	None	HITACHI	Zaxis225USLC-3	√	√	√	√	
Excavator	None	HITACHI	Zaxis160LC-3	√	√	√	√	
Excavator	Backhoe	HITACHI	EX3600-6	√	√	√	√	
Excavator	Shovel	HITACHI	EX3600-6	√	√	√	√	
Felling Head	Disc Saw	John Deere	FR22B	√	√	√	√	
Felling Head	Disc Saw	John Deere	FR24B	√	√	√	√	
Crawler	Dozer 139436-XXXXX	John Deere	700J	√	√	√	√	
Harvester	Wheeled	John Deere	970D	√	√	√	√	
Harvester Head	Bar Saw	John Deere	H290	√	√	√	√	
Harvester Head	Bar Saw	TIMBERJACK	H270	√	√	√	√	
Harvester Head	Bar Saw	TIMBERJACK	H290	√	√	√	√	
Harvester Head	Bar Saw	John Deere	745	√	√	√	√	
Harvester Head	Bar Saw	John Deere	H752	√	√	√	√	
Harvester Head	Bar Saw	John Deere	H754	√	√	√	√	
Harvester Head	Bar Saw	John Deere	H742	√	√	√	√	
Harvester Head	Bar Saw	John Deere	758HD	√	√	√	√	
Harvester Head	Bar Saw	John Deere	762C	√	√	√	√	
Harvester Head	Bar Saw	TIMBERJACK	762C	√	√	√	√	
Excavator	None	HITACHI	EX8000	√	√	√	√	
Backhoe	Side Shift	John Deere	315SJ	√	√	√	√	
Skidder	Cable	John Deere	640H	√	√	√	√	
Skidder	Grapple	John Deere	648H	√	√	√	√	
Skidder	Grapple	John Deere	748H	√	√	√	√	
Skidder	Grapple	John Deere	848H	√	√	√	√	
Skidder	Cable 613179-XXXXXX	John Deere	540G-III	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Skidder	Grapple 613179-XXXXXX	John Deere	548G-III	√	√	√	√	
4WD Loader	None	John Deere	724J	√	√	√	√	
Other	Machine Information Center	John Deere	ICX	√	√	√	√	
Other	Machine Information Center	HITACHI	ICX	√	√	√	√	
Feller Buncher	Track	John Deere	753J	√	√	√	√	
Feller Buncher	Track	John Deere	759J	√	√	√	√	
Harvester	Track	John Deere	753JH	√	√	√	√	
Harvester	Track	John Deere	759JH	√	√	√	√	
Excavator	Shovel	HITACHI	EX1900-6	√	√	√	√	
Excavator	Shovel	HITACHI	EX2500-6	√	√	√	√	
Excavator	Backhoe	HITACHI	EX5500-6	√	√	√	√	
Excavator	Shovel	HITACHI	EX5500-6	√	√	√	√	
Other	Machine Information Center	John Deere	ICF	√	√	√	√	
Other	Machine Information Center	HITACHI	ICF	√	√	√	√	
Truck	Rigid Frame	Euclid	EH1000	√	√	√	√	
Truck	Rigid Frame	Euclid	EH1100	√	√	√	√	
Truck	Rigid Frame	Euclid	EH1600	√	√	√	√	
Truck	Rigid Frame	Euclid	EH1700	√	√	√	√	
Truck	Rigid Frame	Euclid	EH1700-3	√	√	√	√	
Truck	Rigid Frame	Euclid	EH3000	√	√	√	√	
Truck	Rigid Frame	Euclid	EH3500	√	√	√	√	
Truck	Rigid Frame	Euclid	EH4500	√	√	√	√	
Truck	Rigid Frame	Euclid	EH5000	√	√	√	√	
Truck	Rigid Frame	Euclid	EH700	√	√	√	√	
Truck	Rigid Frame	Euclid	EH750	√	√	√	√	
Truck	Rigid Frame	Euclid	EH4500-1	√	√	√	√	
Truck	Rigid Frame	Euclid	EH4500-2	√	√	√	√	
CF Management Solutions	Telematics	HITACHI	ZXLink	√	√	√	√	
Harvester Head	Bar Saw	Waratah	HTH624C	√	√	√	√	
Crawler	High Speed Dozer	John Deere	764	√	√	√	√	
Excavator	Wheeled	John Deere	190DW	√	√	√	√	
Excavator	Wheeled	John Deere	220DW	√	√	√	√	
Excavator	None	John Deere	120D	√	√	√	√	
Excavator	RTS	John Deere	135D	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Harvester	Track	John Deere	853JH	√	√	√	√	
Harvester	Track	John Deere	903JH	√	√	√	√	
Harvester	Track	John Deere	909JH	√	√	√	√	
Harvester	Track	John Deere	703JH	√	√	√	√	
Excavator	None	John Deere	75D	√	√	√	√	
Excavator	None	John Deere	85D	√	√	√	√	
Landscape Loader	None	John Deere	210LJ	√	√	√	√	
OEM Winch	None	John Deere	60	√	√	√	√	
Winch	None	John Deere	6000	√	√	√	√	
4WD Loader	None	John Deere	624KR	√	√	√	√	
Excavator	Wheeled	HITACHI	Zaxis190W-3	√	√	√	√	
Excavator	Wheeled	HITACHI	Zaxis220W-3	√	√	√	√	
Crawler	Dozer	John Deere	850JR	√	√	√	√	
Forestry Swing Machine	Processor	John Deere	2954D	√	√	√	√	
Forestry Swing Machine	Processor	John Deere	2454D	√	√	√	√	
Forester	Processor	HITACHI	Zaxis240-3	√	√	√	√	
Forester	Processor	HITACHI	Zaxis290-3	√	√	√	√	
Forestry Swing Machine	Road Builder	John Deere	2454D	√	√	√	√	
Forestry Swing Machine	Delimber	John Deere	2454D	√	√	√	√	
Forestry Swing Machine	Log Loader	John Deere	2454D	√	√	√	√	
Forestry Swing Machine	Road Builder	John Deere	2954D	√	√	√	√	
Forestry Swing Machine	Delimber	John Deere	2954D	√	√	√	√	
Forestry Swing Machine	Log Loader	John Deere	2954D	√	√	√	√	
Forester	Road Builder	HITACHI	Zaxis240-3	√	√	√	√	
Forester	Delimber	HITACHI	Zaxis240-3	√	√	√	√	
Forester	Log Loader	HITACHI	Zaxis240-3	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Forester	Road Builder	HITACHI	Zaxis290-3	√	√	√	√	
Forester	Delimber	HITACHI	Zaxis290-3	√	√	√	√	
Forester	Log Loader	HITACHI	Zaxis290-3	√	√	√	√	
Excavator	None	HITACHI	Zaxis120-3	√	√	√	√	
Excavator	RTS	HITACHI	Zaxis135US-3	√	√	√	√	
Excavator	None	HITACHI	Zaxis75US-3	√	√	√	√	
Excavator	None	HITACHI	Zaxis85USB-3	√	√	√	√	
Crawler	Dozer 159987-XXXXXX	John Deere	450J	√	√	√	√	
Crawler	Dozer 159987-XXXXXX	John Deere	550J	√	√	√	√	
Crawler	Dozer 159987-XXXXXX	John Deere	650J	√	√	√	√	
4WD Loader	None	John Deere	544K	√	√	√	√	
4WD Loader	None	John Deere	444K	√	√	√	√	
4WD Loader	(-XXXXXX) Engine 6068HDW80, 6068HDW83	John Deere	644K	√	√	√	√	
4WD Loader	None	John Deere	524K	√	√	√	√	
4WD Loader	None	John Deere	624K	√	√	√	√	
4WD Loader	(-XXXXXX) Engine 6090HDW03, 6090HDW09	John Deere	724K	√	√	√	√	
4WD Loader	(-641273) Engine 6135HDW01, 6135HDW03	John Deere	824K	√	√	√	√	
4WD Loader	None	John Deere	844K	√	√	√	√	
Transmission	DF Series	John Deere	DF150	√	√	√	√	
Transmission	DF Series	John Deere	DF250	√	√	√	√	
Excavator	Compact	HITACHI	Zaxis60USB-3	√	√	√	√	
Forestry Swing Machine	Delimber	John Deere	2154D	√	√	√	√	
Forestry Swing Machine	Log Loader	John Deere	2154D	√	√	√	√	
Forestry Swing Machine	Processor	John Deere	2154D	√	√	√	√	
Forestry Swing Machine	Road Builder	John Deere	2154D	√	√	√	√	
Forester	Road Builder	HITACHI	Zaxis210-3	√	√	√	√	
Forester	Delimber	HITACHI	Zaxis210-3	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Forester	Log Loader	HITACHI	Zaxis210-3	√	√	√	√	
Forester	Processor	HITACHI	Zaxis210-3	√	√	√	√	
Feller Buncher	Track	TIMBERJACK	608	√	√	√	√	
Excavator	None	John Deere	200D	√	√	√	√	
4WD Loader	None	John Deere	444JR	√	√	√	√	
Excavator	Backhoe	HITACHI	EX1900-6	√	√	√	√	
Excavator	Backhoe	HITACHI	EX2500-6	√	√	√	√	
Excavator	None	HITACHI	Zaxis200-3	√	√	√	√	
Forwarder	Wheeled	John Deere	810E	√	√	√	√	
Forwarder	Wheeled	John Deere	1010E	√	√	√	√	
Forwarder	Wheeled	John Deere	1110E	√	√	√	√	
Harvester	Wheeled	John Deere	1070E	√	√	√	√	
Harvester	Wheeled	John Deere	1270E	√	√	√	√	
Harvester	Wheeled	John Deere	1470E	√	√	√	√	
Forestry Swing Machine	Road Builder	John Deere	3754D	√	√	√	√	
Forestry Swing Machine	Log Loader	John Deere	3754D	√	√	√	√	
Excavator	Backhoe	HITACHI	EX1200-6	√	√	√	√	
Excavator	Shovel	HITACHI	EX1200-6	√	√	√	√	
Excavator	None	HITACHI	EX8000-6	√	√	√	√	
Truck	Rigid Frame	Euclid	EH3500ACII	√	√	√	√	
Forester	Road Builder	HITACHI	Zaxis370-3	√	√	√	√	
Forester	Log Loader	HITACHI	Zaxis370-3	√	√	√	√	
Backhoe	Side Shift	John Deere	325J	√	√	√	√	
Other	None	John Deere	Super Caddy	√	√	√	√	
Excavator	Compact	HITACHI	Zaxis27u-3	√	√	√	√	
Excavator	Compact	HITACHI	Zaxis35u-3	√	√	√	√	
Excavator	Compact	HITACHI	Zaxis50u-3	√	√	√	√	
Skidder	Cable	John Deere	540H	√	√	√	√	
Skidder	Grapple	John Deere	548H	√	√	√	√	
Harvester	Wheeled	John Deere	1170E	√	√	√	√	
Forwarder	Wheeled	John Deere	1510E	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Truck	Rigid Frame	Euclid	EH5000ACII	√	√	√	√	
OEM Engines	Diesel	John Deere	3009	√	√	√	√	
OEM Engines	Diesel	John Deere	3011	√	√	√	√	
OEM Engines	Diesel	John Deere	3164	√	√	√	√	
OEM Engines	Diesel	John Deere	4219	√	√	√	√	
OEM Engines	Diesel	John Deere	6329	√	√	√	√	
Pump Drive	Series	John Deere	28000	√	√	√	√	
Pump Drive	Series	John Deere	56000	√	√	√	√	
Pump Drive	Series	John Deere	57000	√	√	√	√	
Pump Drive	Series	John Deere	59000	√	√	√	√	
Pump Drive	Series	John Deere	61000	√	√	√	√	
Forwarder	Wheeled	John Deere	1210E	√	√	√	√	
Feller Buncher	Wheeled	John Deere	643K	√	√	√	√	
Feller Buncher	Wheeled	John Deere	843K	√	√	√	√	
Truck	Articulated Dump	John Deere	250D Series II	√	√	√	√	
Truck	Articulated Dump	John Deere	300D Series II	√	√	√	√	
Truck	Articulated Dump	John Deere	350D Series II	√	√	√	√	
Truck	Articulated Dump	John Deere	400D Series II	√	√	√	√	
Harvester Head	Bar Saw	Waratah	HTH616C	√	√	√	√	
Felling Head	Bar Saw	Waratah	FL85	√	√	√	√	
Harvester Head	Bar Saw	Waratah	HTD316C	√	√	√	√	
Harvester Head	Bar Saw	Waratah	HTH616	√	√	√	√	
Harvester Head	Bar Saw	Waratah	HTH618C	√	√	√	√	
Harvester Head	Bar Saw	Waratah	HTH622B	√	√	√	√	
Harvester Head	Bar Saw	Waratah	HTH623C	√	√	√	√	
Harvester Head	Bar Saw	Waratah	HTH626	√	√	√	√	
PTO	Series	John Deere	F30	√	√	√	√	
Excavator	None	XCG	210LC-8B	√	√	√	√	
Excavator	None	XCG	240LC-8B	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Excavator	None	XCG	330LC-8B	√	√	√	√	
Feller Buncher	Track	John Deere	903K	√	√	√	√	
Feller Buncher	Track	John Deere	909K	√	√	√	√	
Log Loader	Trailer Mount	John Deere	335D	√	√	√	√	
Log Loader	Trailer Mount	John Deere	437D	√	√	√	√	
Feller Buncher	Track	John Deere	953K	√	√	√	√	
Feller Buncher	Track	John Deere	959K	√	√	√	√	
Harvester	Track	John Deere	903KH	√	√	√	√	
Harvester	Track	John Deere	909KH	√	√	√	√	
OEM Engines	Marine PowerTech	John Deere	6068	√	√	√	√	
OEM Engines	Marine PowerTech	John Deere	6090	√	√	√	√	
OEM Engines	Marine PowerTech	John Deere	6125	√	√	√	√	
OEM Engines	Marine PowerTech	John Deere	6135	√	√	√	√	
Felling Head	Disc Saw	John Deere	FR21B	√	√	√	√	
4WD Loader	(630720-) Engine 6090HDW12	John Deere	744K	√	√	√	√	
4WD Loader	(632968-) Engine 6090HDW06, 6090HDW08	John Deere	744K	√	√	√	√	
Forwarder	Wheeled	John Deere	1910E	√	√	√	√	
Harvester Head	Bar Saw	John Deere	H270E	√	√	√	√	
Harvester Head	Bar Saw	John Deere	H412	√	√	√	√	
Harvester Head	Bar Saw	John Deere	H414	√	√	√	√	
Truck	Rigid Frame	Euclid	EH4000ACII	√	√	√	√	
Crawler	Dozer	John Deere	850K	√	√	√	√	
4WD Loader	(634315-) Engine 6090HDW13	John Deere	724K	√	√	√	√	
4WD Loader	(634315-) Engine 6090HDW13	John Deere	644K	√	√	√	√	
Crawler	Loader	John Deere	755K	√	√	√	√	
Excavator	None	John Deere	250GLC	√	√	√	√	
Excavator	None	John Deere	290GLC	√	√	√	√	
Excavator	None	John Deere	350GLC	√	√	√	√	
Excavator	Engine 4HK1XZSA-01	HITACHI	Zaxis250LC-5N	√	√	√	√	
Excavator	Engine 4HK1XZSA-01	HITACHI	Zaxis290LC-5N	√	√	√	√	
Excavator	Engine 6HK1XZSA-01	HITACHI	Zaxis350LC-5N	√	√	√	√	
4WD Loader	(-632967) Engine 6090HDW06, 6090HDW08	John Deere	744K	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Motor Grader	(-634753) Engine 6090HDW01, 6068HDW75	John Deere	670G	√	√	√	√	
Motor Grader	(-634753) Engine 6090HDW01, 6068HDW75	John Deere	670GP	√	√	√	√	
Motor Grader	(-634753) Engine 6090HDW01, 6068HDW75	John Deere	672G	√	√	√	√	
Motor Grader	(-634753) Engine 6090HDW01, 6068HDW75	John Deere	672GP	√	√	√	√	
Motor Grader	(634754-) Engine 6090HDW01, 6068HDW75	John Deere	670G	√	√	√	√	
Motor Grader	(634754-) Engine 6090HDW01, 6068HDW75	John Deere	670GP	√	√	√	√	
Motor Grader	(634754-) Engine 6090HDW01, 6068HDW75	John Deere	672G	√	√	√	√	
Motor Grader	(634754-) Engine 6090HDW01, 6068HDW75	John Deere	672GP	√	√	√	√	
Motor Grader	(-634753) Engine 6090HDW01, 6090HDW04	John Deere	870G	√	√	√	√	
Motor Grader	(-634753) Engine 6090HDW01, 6090HDW04	John Deere	770G	√	√	√	√	
Motor Grader	(-634753) Engine 6090HDW01, 6090HDW04	John Deere	770GP	√	√	√	√	
Motor Grader	(-634753) Engine 6090HDW01, 6090HDW04	John Deere	772G	√	√	√	√	
Motor Grader	(-634753) Engine 6090HDW01, 6090HDW04	John Deere	772GP	√	√	√	√	
Motor Grader	(-634753) Engine 6090HDW01, 6090HDW04	John Deere	870GP	√	√	√	√	
Motor Grader	(-634753) Engine 6090HDW01, 6090HDW04	John Deere	872G	√	√	√	√	
Motor Grader	(-634753) Engine 6090HDW01, 6090HDW04	John Deere	872GP	√	√	√	√	
Motor Grader	(634754-) Engine 6090HDW01, 6090HDW04	John Deere	870G	√	√	√	√	
Motor Grader	(634754-) Engine 6090HDW01, 6090HDW04	John Deere	770G	√	√	√	√	
Motor Grader	(634754-) Engine 6090HDW01, 6090HDW04	John Deere	770GP	√	√	√	√	
Motor Grader	(634754-) Engine 6090HDW01, 6090HDW04	John Deere	772G	√	√	√	√	
Motor Grader	(634754-) Engine 6090HDW01, 6090HDW04	John Deere	772GP	√	√	√	√	
Motor Grader	(634754-) Engine 6090HDW01, 6090HDW04	John Deere	870GP	√	√	√	√	
Motor Grader	(634754-) Engine 6090HDW01, 6090HDW04	John Deere	872G	√	√	√	√	
Motor Grader	(634754-) Engine 6090HDW01, 6090HDW04	John Deere	872GP	√	√	√	√	
Motor Grader	(634380-) Engine 6090HDW16	John Deere	670G	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Motor Grader	(634380-) Engine 6090HDW16	John Deere	670GP	√	√	√	√	
Motor Grader	(634380-) Engine 6090HDW16	John Deere	672G	√	√	√	√	
Motor Grader	(634380-) Engine 6090HDW16	John Deere	672GP	√	√	√	√	
Motor Grader	(634380-) Engine 6090HDW16	John Deere	770G	√	√	√	√	
Motor Grader	(634380-) Engine 6090HDW16	John Deere	770GP	√	√	√	√	
Motor Grader	(634380-) Engine 6090HDW11	John Deere	870G	√	√	√	√	
Motor Grader	(634380-) Engine 6090HDW11	John Deere	772G	√	√	√	√	
Motor Grader	(634380-) Engine 6090HDW11	John Deere	772GP	√	√	√	√	
Motor Grader	(634380-) Engine 6090HDW11	John Deere	870GP	√	√	√	√	
Motor Grader	(634380-) Engine 6090HDW11	John Deere	872G	√	√	√	√	
Motor Grader	(634380-) Engine 6090HDW11	John Deere	872GP	√	√	√	√	
Felling Head	Disc Saw	John Deere	FD45	√	√	√	√	
Harvester Head	Bar Saw	Waratah	HTH620	√	√	√	√	
Harvester Head	Bar Saw	Waratah	HTH622	√	√	√	√	
Harvester Head	Bar Saw	Waratah	HTH624	√	√	√	√	
Measuring System	Automatic Control	John Deere	TimberMatic F-09	√	√	√	√	
Measuring System	Automatic Control	John Deere	TimberMatic H-09	√	√	√	√	
Software	Automatic Control	John Deere	TimberLink	√	√	√	√	
Excavator	Engine 6UZ1XZSA-01	John Deere	470GLC	√	√	√	√	
Excavator	Engine 6UZ1XZSA-01	HITACHI	Zaxis470LC-5B	√	√	√	√	
Excavator	Engine 6WG1XZSA-02	John Deere	670GLC	√	√	√	√	
Excavator	Engine 6WG1XZSA-02	John Deere	870GLC	√	√	√	√	
Excavator	Engine 6WG1XZSA-02	HITACHI	Zaxis670LC-5B	√	√	√	√	
Excavator	Engine 6WG1XZSA-02	HITACHI	Zaxis870LC-5B	√	√	√	√	
OEM Engines	Marine PowerTech	John Deere	Sea Trial	√	√	√	√	
4WD Loader	(641274-) Engine 6135HDW01, 6135HDW03	John Deere	824K	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Tractors	PIN prefix LV - USA	John Deere	5200	√	√	√	√	
Tractors	Compact Utility	John Deere	4100	√	√	√	√	
Tractors	Compact Utility	John Deere	4200	√	√	√	√	
Tractors	Compact Utility	John Deere	4300	√	√	√	√	
Tractors	Compact Utility	John Deere	4400	√	√	√	√	
Tractors	Compact Utility	John Deere	4500	√	√	√	√	
Tractors	Compact Utility	John Deere	4600	√	√	√	√	
Tractors	Compact Utility	John Deere	4700	√	√	√	√	
Utility Vehicles	Gator	John Deere	4X2	√	√	√	√	
Utility Vehicles	Gator	John Deere	6X4	√	√	√	√	
Utility Vehicles	Gator Trail	John Deere	4X2Trail	√	√	√	√	
Utility Vehicles	Gator Trail	John Deere	6X4Trail	√	√	√	√	
Utility Vehicles	Gator Diesel Trail	John Deere	6X4DTrail	√	√	√	√	
Tractors	Compact Utility	John Deere	4110	√	√	√	√	
Tractors	Compact Utility	John Deere	4115	√	√	√	√	
Tractors	Compact Utility	John Deere	4510	√	√	√	√	
Tractors	Compact Utility	John Deere	4610	√	√	√	√	
Tractors	Compact Utility	John Deere	4710	√	√	√	√	
Tractors	Compact Utility	John Deere	4010	√	√	√	√	
Tractors	Compact Utility Hydro	John Deere	655	√	√	√	√	
Tractors	Compact Utility Hydro	John Deere	755	√	√	√	√	
Tractors	Compact Utility Hydro	John Deere	855	√	√	√	√	
Tractors	Compact Utility Hydro	John Deere	955	√	√	√	√	
Tractors	Compact Utility	John Deere	670	√	√	√	√	
Tractors	Compact Utility	John Deere	770	√	√	√	√	
Tractors	Compact Utility	John Deere	870	√	√	√	√	
Tractors	Compact Utility	John Deere	970	√	√	√	√	
Tractors	Compact Utility	John Deere	1070	√	√	√	√	
Tractors	Compact Utility	John Deere	790	√	√	√	√	
Tractors	Compact Utility	John Deere	990HC	√	√	√	√	
Commercial	Utility Vehicle	John Deere	1800	√	√	√	√	
Commercial	Utility Vehicle	John Deere	E-GATOR	√	√	√	√	
Utility Vehicles	ProGator Gas	John Deere	2020	√	√	√	√	
Utility Vehicles	ProGator Diesel	John Deere	2030	√	√	√	√	
Commercial Mowing	Wide Area Mower	John Deere	1600	√	√	√	√	
Commercial Mowing	Wide Area Mower	John Deere	1620	√	√	√	√	
Commercial Mowing	Wide Area Mower	John Deere	1600 Turbo	√	√	√	√	
Commercial Mowing	QuikTrak Mower	John Deere	647	√	√	√	√	
Commercial Mowing	QuikTrak Mower	John Deere	657	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Commercial Mowing	QuikTrak Mower	John Deere	667	√	√	√	√	
Commercial Mowing	Front Mower	John Deere	1400	√	√	√	√	
Commercial Mowing	Front Mower	John Deere	1435	√	√	√	√	
Commercial Mowing	Front Mower	John Deere	1445	√	√	√	√	
Commercial Mowing	Front Mower	John Deere	1565	√	√	√	√	
Commercial Mowing	Mini-Mount ZTRAK Mower	John Deere	717	√	√	√	√	
Commercial Mowing	Mini-Mount ZTRAK Mower	John Deere	727	√	√	√	√	
Commercial Mowing	Mid-Mount ZTRAK Mower	John Deere	737	√	√	√	√	
Commercial Mowing	Mid-Mount ZTRAK Mower	John Deere	757	√	√	√	√	
Commercial Mowing	Front Mowers and Equipment	John Deere	F1145	√	√	√	√	
Commercial Mowing	ZTRAK Mowers and Equipment	John Deere	F620	√	√	√	√	
Commercial Mowing	ZTRAK Mowers and Equipment	John Deere	F680	√	√	√	√	
Commercial Mowing	Front-Mount ZTRAK Mower	John Deere	F687	√	√	√	√	
Commercial Mowing	Front Mowers and Equipment	John Deere	F710	√	√	√	√	
Commercial Mowing	Front Mowers and Equipment	John Deere	F725	√	√	√	√	
Commercial Mowing	Front Mowers and Equipment	John Deere	F735	√	√	√	√	
Commercial Mowing	Front Mowers and Equipment	John Deere	F911	√	√	√	√	
Commercial Mowing	Front Mowers and Equipment	John Deere	F915	√	√	√	√	
Commercial Mowing	Front Mowers and Equipment	John Deere	F925	√	√	√	√	
Commercial Mowing	Front Mowers and Equipment	John Deere	F932	√	√	√	√	
Commercial Mowing	Front Mowers and Equipment	John Deere	F935	√	√	√	√	
Commercial Mowing	Max-Mount ZTRAK Mower	John Deere	777	√	√	√	√	
Commercial Mowing	Max-Mount ZTRAK Mower	John Deere	797	√	√	√	√	
Commercial Mowing	ZTRAK Mowers and Equipment	John Deere	M653	√	√	√	√	
Commercial Mowing	ZTRAK Mowers and Equipment	John Deere	M655	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Commercial Mowing	ZTRAK Mowers and Equipment	John Deere	M665	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	12PC	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	14SC	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	GS25	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	GS30	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	GS45	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	GS75	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	HD45	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	HD75	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JX85	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	L100	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	L110	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	L120	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	L130	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	G100	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	130	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	160	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	165	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	170	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	175	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	180	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	185	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LT133	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LT155	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LT160	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LT166	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LTR180	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LX172	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LX173	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LX176	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LX178	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LX188	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LX255	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LX266	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LX277	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LX277AWS	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LX279	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LX288	√	√	√	√	
Zero-Turn Riding Lawn Equipment	JD Lawn Tractors	John Deere	SST15	√	√	√	√	
Zero-Turn Riding Lawn Equipment	JD Lawn Tractors	John Deere	SST16	√	√	√	√	
Zero-Turn Riding Lawn Equipment	JD Lawn Tractors	John Deere	SST18	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	STX30	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	STX38	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	STX46	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	240	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	260	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	265	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	285	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	320	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	316	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	318	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	420	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	322	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	330	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	332	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	430	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	325	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	345	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	355D	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	415	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	425	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	445	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	455	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	GT235	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	GT235E	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	GT245	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	GT242	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	GT262	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	GT275	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	GX325	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	GX335	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	GX345	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	GX355D	√	√	√	√	
Riding Lawn Equipment	Sabre Yard Tractors	John Deere	1842GV	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Riding Lawn Equipment	Sabre Yard Tractors	John Deere	1842HV	√	√	√	√	
Riding Lawn Equipment	Sabre Yard and Garden Tractors	John Deere	2048HV	√	√	√	√	
Riding Lawn Equipment	Sabre Yard and Garden Tractors	John Deere	2254HV	√	√	√	√	
Riding Lawn Equipment	Sabre Yard and Garden Tractors	John Deere	2554HV	√	√	√	√	
Riding Lawn Equipment	Sabre Yard and Garden Tractors	John Deere	1948GV	√	√	√	√	
Riding Lawn Equipment	Sabre Yard and Garden Tractors	John Deere	1948HV	√	√	√	√	
Riding Lawn Equipment	Sabre Yard and Garden Tractors	John Deere	2148HV	√	√	√	√	
Riding Lawn Equipment	Sabre Yard and Garden Tractors	John Deere	2354HV	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LT150	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LT170	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LT180	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	GT225	√	√	√	√	
Tractors	Compact Utility	John Deere	2210	√	√	√	√	
Special Utility Vehicles	Sprayer Attachment	John Deere	200	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LTR166	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	335	√	√	√	√	
Scotts Equipment	Scotts Yard Tractor	John Deere	S2048H	√	√	√	√	
Scotts Equipment	Scotts Garden Tractor	John Deere	S2554H	√	√	√	√	
Scotts Equipment	Scotts Garden Tractor	John Deere	S2348H	√	√	√	√	
Riding Lawn Equipment	JD Riding Mowers	John Deere	GX70	√	√	√	√	
Riding Lawn Equipment	JD Riding Mowers	John Deere	GX75	√	√	√	√	
Riding Lawn Equipment	JD Riding Mowers	John Deere	GX85	√	√	√	√	
Riding Lawn Equipment	JD Riding Mowers	John Deere	GX95	√	√	√	√	
Riding Lawn Equipment	JD Riding Mowers	John Deere	SX85	√	√	√	√	
Riding Lawn Equipment	JD Riding Mowers	John Deere	SRX75	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Riding Lawn Equipment	JD Riding Mowers	John Deere	SRX95	√	√	√	√	
Riding Lawn Equipment	JD Riding Mowers	John Deere	RX63	√	√	√	√	
Riding Lawn Equipment	JD Riding Mowers	John Deere	RX73	√	√	√	√	
Riding Lawn Equipment	JD Riding Mowers	John Deere	RX75	√	√	√	√	
Riding Lawn Equipment	JD Riding Mowers	John Deere	SX75	√	√	√	√	
Riding Lawn Equipment	JD Riding Mowers	John Deere	RX95	√	√	√	√	
Riding Lawn Equipment	JD Riding Mowers	John Deere	SX95	√	√	√	√	
Riding Lawn Equipment	Residential Front Mowers	John Deere	F510	√	√	√	√	
Riding Lawn Equipment	Residential Front Mowers	John Deere	F525	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	12PB	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	12SB	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	14PB	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	14SB	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	14SE	√	√	√	√	
Walk-Behind Products	Sabre Walk-Behind Mowers	John Deere	14PS	√	√	√	√	
Walk-Behind Products	Sabre Walk-Behind Mowers	John Deere	14SS	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	14PT	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	14ST	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	14PZ	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	14SZ	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	14SX	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JA62	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JA65	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JX75	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JE75	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JS60	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JS60H	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JS61	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JS63	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JS63C	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JS63E	√	√	√	√	
Walk-Behind Products	Sabre Walk-Behind Mowers	John Deere	M10	√	√	√	√	
Walk-Behind Products	Sabre Walk-Behind Mowers	John Deere	M21	√	√	√	√	
Walk-Behind Products	Sabre Walk-Behind Mowers	John Deere	M23	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowthrowers	John Deere	TRS21	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblowers	John Deere	TRS22	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblowers	John Deere	TRS24	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblowers	John Deere	TRS26	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblowers	John Deere	TRX24	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblowers	John Deere	TRX26	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblowers	John Deere	TRS27	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblowers	John Deere	TRS32	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblower	John Deere	924DE	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblower	John Deere	1128DE	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblower	John Deere	1128DDE	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblower	John Deere	1332DDE	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblowers	John Deere	526	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblowers	John Deere	726	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblowers	John Deere	732	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowthrowers	John Deere	826	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Walk-Behind Products	Walk-Behind Snowblower	John Deere	832	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblower	John Deere	1032	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblowers	John Deere	524D	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblowers	John Deere	724D	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblowers	John Deere	826D	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblowers	John Deere	828D	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblower	John Deere	1032D	√	√	√	√	
Walk-Behind Products	Walk-Behind Tillers	John Deere	314	√	√	√	√	
Walk-Behind Products	Walk-Behind Tillers	John Deere	324	√	√	√	√	
Walk-Behind Products	Walk-Behind Tillers	John Deere	518R	√	√	√	√	
Walk-Behind Products	Walk-Behind Tillers	John Deere	524	√	√	√	√	
Walk-Behind Products	Walk-Behind Tillers	John Deere	624	√	√	√	√	
Walk-Behind Products	Walk-Behind Tillers	John Deere	820R	√	√	√	√	
JD Miscellaneous Equipment	Edger	John Deere	SE23	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	T23S	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	TS26	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	TB26SB	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	T30C	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	T30S	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
JD Hand-Held Portable Products	Trimmers String	John Deere	T30SB	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	T40SB	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	XT105	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	XT105SB	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	XT120	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	XT120SB	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	XT140SB	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	XT140B	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	XT140	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	XT250B	√	√	√	√	
JD Miscellaneous Equipment	Genset	John Deere	250G	√	√	√	√	
JD Miscellaneous Equipment	Genset	John Deere	440G	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
JD Miscellaneous Equipment	Genset	John Deere	G4400K	√	√	√	√	
JD Miscellaneous Equipment	Genset	John Deere	G5500K	√	√	√	√	
JD Miscellaneous Equipment	Genset	John Deere	G5500KE	√	√	√	√	
JD Miscellaneous Equipment	Genset	John Deere	DP6000	√	√	√	√	
JD Hand-Held Portable Products	Hedge Trimmer	John Deere	113	√	√	√	√	
JD Hand-Held Portable Products	Hedge Trimmer	John Deere	172	√	√	√	√	
JD Hand-Held Portable Products	Blower	John Deere	5E	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	110G	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	240G	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	260G	√	√	√	√	
JD Hand-Held Portable Products	Hedge Trimmer	John Deere	162	√	√	√	√	
JD Hand-Held Portable Products	Hedge Trimmer	John Deere	21HC	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
JD Hand-Held Portable Products	Blower	John Deere	45BP	√	√	√	√	
JD Hand-Held Portable Products	Saw Chain	John Deere	200CS	√	√	√	√	
JD Hand-Held Portable Products	Saw Chain	John Deere	230CS	√	√	√	√	
JD Hand-Held Portable Products	Saw Chain	John Deere	300CS	√	√	√	√	
JD Hand-Held Portable Products	Saw Chain	John Deere	350CS	√	√	√	√	
JD Hand-Held Portable Products	Saw Chain	John Deere	550CS	√	√	√	√	
JD Hand-Held Portable Products	Saw Chain	John Deere	CS36	√	√	√	√	
JD Hand-Held Portable Products	Saw Chain	John Deere	CS40	√	√	√	√	
JD Hand-Held Portable Products	Saw Chain	John Deere	CS46	√	√	√	√	
JD Hand-Held Portable Products	Saw Chain	John Deere	CS52	√	√	√	√	
JD Hand-Held Portable Products	Saw Chain	John Deere	CS56	√	√	√	√	
JD Hand-Held Portable Products	Saw Chain	John Deere	CS62	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
JD Hand-Held Portable Products	Saw Chain	John Deere	CS71	√	√	√	√	
JD Hand-Held Portable Products	Saw Chain	John Deere	CS81	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	21C	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	21S	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	25S	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	30S	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	38B	√	√	√	√	
JD Hand-Held Portable Products	Hedge Trimmer	John Deere	213E	√	√	√	√	
Riding Lawn Equipment	2002 Sabre Lawn Tractors	John Deere	14542GS	√	√	√	√	
Riding Lawn Equipment	2002 Sabre Lawn Tractors	John Deere	1642HS	√	√	√	√	
Riding Lawn Equipment	2002 Sabre Lawn Tractors	John Deere	17542HS	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	X465	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	X475	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	X485	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	X575	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	X585	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	X495	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	X595	√	√	√	√	
Scotts Equipment	Scotts Lawn Tractor	John Deere	S1642H	√	√	√	√	
Scotts Equipment	Scotts Garden Tractor	John Deere	S1742H	√	√	√	√	
Scotts Equipment	Scotts Lawn Tractor	John Deere	S2046H	√	√	√	√	
Scotts Equipment	Scotts Lawn Tractor	John Deere	S2546H	√	√	√	√	
Scotts Equipment	2002 Scotts Lawn Tractor	John Deere	L1642	√	√	√	√	
Scotts Equipment	2002 Scotts Lawn Tractor	John Deere	L17.542	√	√	√	√	
Scotts Equipment	2002 Scotts Lawn Tractor	John Deere	L2048	√	√	√	√	
Scotts Equipment	2002 Scotts Lawn Tractor	John Deere	L2548	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	3812	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	3814	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	3817	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	4812	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	4811	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	4813	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	4814	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	4816	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	4817	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	5412	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	5413	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	5414	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	5417	√	√	√	√	
Tractors	Compact Utility Hydro	John Deere	756	√	√	√	√	
Tractors	Compact Utility Hydro	John Deere	856	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowthrowers	John Deere	TRS21E	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JA60	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Commercial Mowing	Front Mower	John Deere	1420	√	√	√	√	
Commercial Mowing	Front Mower	John Deere	1545	√	√	√	√	
Walk-Behind Products	Walk-Behind Tillers	John Deere	314F	√	√	√	√	
JD Miscellaneous Equipment	Genset	John Deere	550GE	√	√	√	√	
JD Miscellaneous Equipment	Genset	John Deere	GS2500K	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LX186	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	245	√	√	√	√	
Riding Lawn Equipment	Sabre Lawn Tractors	John Deere	1338GS	√	√	√	√	
Riding Lawn Equipment	Sabre Lawn Tractors	John Deere	1538GS	√	√	√	√	
Riding Lawn Equipment	Sabre Lawn Tractors	John Deere	1538HS	√	√	√	√	
Riding Lawn Equipment	Sabre Lawn Tractors	John Deere	15538GS	√	√	√	√	
Riding Lawn Equipment	Sabre Lawn Tractors	John Deere	15538HS	√	√	√	√	
Riding Lawn Equipment	Sabre Lawn Tractors	John Deere	1546GS	√	√	√	√	
Riding Lawn Equipment	Sabre Lawn Tractors	John Deere	1638HS	√	√	√	√	
Riding Lawn Equipment	Sabre Lawn Tractors	John Deere	1646GS	√	√	√	√	
Riding Lawn Equipment	Sabre Lawn Tractors	John Deere	1646HS	√	√	√	√	
Riding Lawn Equipment	Sabre Lawn Tractors	John Deere	1438GS	√	√	√	√	
Riding Lawn Equipment	Sabre Lawn Tractors	John Deere	1542GS	√	√	√	√	
Riding Lawn Equipment	Sabre Lawn Tractors	John Deere	1542HS	√	√	√	√	
Riding Lawn Equipment	Sabre Lawn Tractors	John Deere	15542HS	√	√	√	√	
Riding Lawn Equipment	Sabre Lawn Tractors	John Deere	15542GS	√	√	√	√	
Riding Lawn Equipment	Sabre Lawn Tractors	John Deere	1642GS	√	√	√	√	
Riding Lawn Equipment	Sabre Lawn Tractors	John Deere	1642HV	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Riding Lawn Equipment	Sabre Lawn Tractors	John Deere	1646HV	√	√	√	√	
Tractor Attachments	Backhoe	John Deere	7	√	√	√	√	
Tractor Attachments	Backhoe	John Deere	8	√	√	√	√	
Tractor Attachments	Backhoe	John Deere	8A	√	√	√	√	
Tractor Attachments	Backhoe	John Deere	10	√	√	√	√	
Tractor Attachments	Backhoe	John Deere	10A	√	√	√	√	
LG Attachments	Loader	John Deere	40	√	√	√	√	
LG Attachments	Loader	John Deere	44	√	√	√	√	
Tractor Attachments	Loader	John Deere	51	√	√	√	√	
Tractor Attachments	Loader	John Deere	52	√	√	√	√	
Tractor Attachments	Loader	John Deere	60	√	√	√	√	
Tractor Attachments	Loader	John Deere	67	√	√	√	√	
Tractor Attachments	Loader	John Deere	70	√	√	√	√	
Tractor Attachments	Loader	John Deere	70A	√	√	√	√	
Tractor Attachments	Blade	John Deere	365	√	√	√	√	
Tractor Attachments	Blade	John Deere	375	√	√	√	√	
Tractor Attachments	Blade	John Deere	380	√	√	√	√	
Tractor Attachments	Blade	John Deere	380A	√	√	√	√	
Tractor Attachments	Blade	John Deere	390	√	√	√	√	
LG Attachments	Tiller	John Deere	30	√	√	√	√	
Tractor Attachments	Attachments	John Deere	MCS	√	√	√	√	
LG Attachments	Rotary Mower	John Deere	48	√	√	√	√	
LG Attachments	Rotary Mower	John Deere	50	√	√	√	√	
LG Attachments	Rotary Mower	John Deere	54	√	√	√	√	
LG Attachments	Rotary Mower	John Deere	60	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Commercial Mowing	Front Mower Attachment	John Deere	72	√	√	√	√	
Commercial Mowing Attachment	Rotary Mower	John Deere	76	√	√	√	√	
Tractor Attachments	Rotary Mower	John Deere	172	√	√	√	√	
Tractor Attachments	Rear Mounted Mower	John Deere	261	√	√	√	√	
Tractor Attachments	Rear Mounted Mower	John Deere	272	√	√	√	√	
LG Attachments	Snowblower	John Deere	47	√	√	√	√	
Tractor Attachments	Snowblower	John Deere	59	√	√	√	√	
Tractor Attachments	Snowblower	John Deere	359	√	√	√	√	
LG Attachments	Snowthrower	John Deere	46	√	√	√	√	
LG Attachments	Snowthrower	John Deere	49	√	√	√	√	
LG Attachments	Snowthrower	John Deere	50	√	√	√	√	
Tractor Attachments	Post Hole Digger	John Deere	3	√	√	√	√	
Tractor Attachments	Post Hole Digger	John Deere	31	√	√	√	√	
Tractor Attachments	Post Hole Digger	John Deere	31A	√	√	√	√	
Tractor Attachments	Post Hole Digger	John Deere	31B	√	√	√	√	
LG Attachments	Tiller	John Deere	48	√	√	√	√	
LG Attachments	Tiller	John Deere	450	√	√	√	√	
Tractor Attachments	Tiller	John Deere	550	√	√	√	√	
Tractor Attachments	Tiller	John Deere	660	√	√	√	√	
LG Attachments	ROTARY BROOM	John Deere	51	√	√	√	√	
LG Attachments	ROTARY BROOM	John Deere	246	√	√	√	√	
Tractor Attachments	Attachments	John Deere	2000	√	√	√	√	
Tractor Attachments	Attachments	John Deere	540	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	317	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LX280	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LX280AWS	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LX289	√	√	√	√	
Utility Vehicles	Gator C Series	John Deere	CS	√	√	√	√	
Utility Vehicles	Gator C Series	John Deere	CX	√	√	√	√	
Utility Vehicles	ATV	John Deere	Buck	√	√	√	√	
Utility Vehicles	ATV	John Deere	Trail Buck	√	√	√	√	
Tractor Attachments	Backhoe	John Deere	447	√	√	√	√	
Tractor Attachments	Backhoe	John Deere	448	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	7H17	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	7H19	√	√	√	√	
Commercial Mowing	Rakes	John Deere	1200	√	√	√	√	
Commercial Mowing	Mowers	John Deere	1905	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	LT190	√	√	√	√	
Golf and Turf Products	Professional Turf Mower	John Deere	3365	√	√	√	√	
Golf and Turf Products	Lightweight Fairway Mower	John Deere	3215	√	√	√	√	
Golf and Turf Products	Lightweight Fairway Mower	John Deere	3235	√	√	√	√	
Golf and Turf Products	Lightweight Fairway Mower	John Deere	3215A	√	√	√	√	
Golf and Turf Products	Lightweight Fairway Mower	John Deere	3235A	√	√	√	√	
Golf and Turf Products	Lightweight Fairway Mower	John Deere	3215B	√	√	√	√	
Golf and Turf Products	Lightweight Fairway Mower	John Deere	3225B	√	√	√	√	
Golf and Turf Products	Lightweight Fairway Mower	John Deere	3225C	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Golf and Turf Products	Lightweight Fairway Mower	John Deere	3235C	√	√	√	√	
Golf and Turf Products	Lightweight Fairway Mower	John Deere	3245C	√	√	√	√	
Golf and Turf Products	Professional Utility Mower	John Deere	2653	√	√	√	√	
Golf and Turf Products	Professional Utility Mower	John Deere	2653A	√	√	√	√	
Golf and Turf Products	Professional Greensmower	John Deere	2243	√	√	√	√	
Golf and Turf Products	Greens Mower	John Deere	2500	√	√	√	√	
Golf and Turf Products	Greens Mower	John Deere	2500a	√	√	√	√	
Golf and Turf Products	Greens Mower	John Deere	22R	√	√	√	√	
Golf and Turf Products	Greens Mower	John Deere	220	√	√	√	√	
Golf and Turf Products	Walk Behind Greensmower	John Deere	180A	√	√	√	√	
Golf and Turf Products	Walk Behind Greensmower	John Deere	180B	√	√	√	√	
Golf and Turf Products	Walk Behind Greensmower	John Deere	220B	√	√	√	√	
Golf and Turf Products	Walk Behind Greensmower	John Deere	260B	√	√	√	√	
Commercial	Utility Cart	John Deere	22	√	√	√	√	
Commercial	Trailer	John Deere	22B	√	√	√	√	
Commercial	Bunker and Field Rake	John Deere	1200	√	√	√	√	
Golf and Turf Products	Bunker and Field Rake	John Deere	1200A	√	√	√	√	
Golf and Turf Products	Aerator	John Deere	132	√	√	√	√	
Golf and Turf Products	Aerator	John Deere	232	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Golf and Turf Products	Aerator	John Deere	270	√	√	√	√	
Golf and Turf Products	Aerator	John Deere	800	√	√	√	√	
Golf and Turf Products	Aerator	John Deere	140S	√	√	√	√	
Golf and Turf Products	Aerator	John Deere	260S	√	√	√	√	
Golf and Turf Products	Aerator	John Deere	290s	√	√	√	√	
Golf and Turf Products	Aerator	John Deere	1000	√	√	√	√	
Golf and Turf Products	Aerator	John Deere	1500	√	√	√	√	
Golf and Turf Products	Aerator	John Deere	2000	√	√	√	√	
Golf and Turf Products	Core Pulverizer	John Deere	CP48	√	√	√	√	
Golf and Turf Products	Root Zone Injection	John Deere	700rzi	√	√	√	√	
Golf and Turf Products	Gang Mower-Hyd Pull	John Deere	303	√	√	√	√	
Golf and Turf Products	Gang Mower-Hyd Pull	John Deere	305	√	√	√	√	
Golf and Turf Products	Hydraulic Gang Mower	John Deere	365	√	√	√	√	
Golf and Turf Products	Walk-Behind Vertical Mower	John Deere	519	√	√	√	√	
Commercial Mowing	5-plex Reel Mower	John Deere	1905	√	√	√	√	
Golf and Turf Products	Walk Behind Greensmower	John Deere	220A	√	√	√	√	
Commercial Mowing	QuikTrak Mower	John Deere	647A	√	√	√	√	
Commercial Mowing	QuikTrak Mower	John Deere	657A	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Commercial Mowing	QuikTrak Mower	John Deere	667A	√	√	√	√	
Tractors	Compact Utility	John Deere	2305	√	√	√	√	
Riding Lawn Equipment	Select Series Lawn Tractor	John Deere	X300	√	√	√	√	
Commercial Mowing	Mid-Mount ZTRAK Mower	John Deere	997	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	110	√	√	√	√	
Riding Lawn Equipment	Select Series Ultimate L and G	John Deere	X700	√	√	√	√	
Riding Lawn Equipment	Select Series Ultimate L and G	John Deere	X720	√	√	√	√	
Riding Lawn Equipment	Select Series Ultimate L and G	John Deere	X724	√	√	√	√	
Riding Lawn Equipment	Select Series Ultimate L and G	John Deere	X728	√	√	√	√	
Riding Lawn Equipment	Select Series Lawn Tractor	John Deere	X304	√	√	√	√	
Riding Lawn Equipment	Select Series Lawn Tractor	John Deere	X320	√	√	√	√	
Riding Lawn Equipment	Select Series Lawn Tractor	John Deere	X324	√	√	√	√	
Riding Lawn Equipment	Select Series Lawn Tractor	John Deere	X340	√	√	√	√	
Riding Lawn Equipment	100 Series Lawn Tractor	John Deere	105	√	√	√	√	
Riding Lawn Equipment	100 Series Lawn Tractor	John Deere	115	√	√	√	√	
Riding Lawn Equipment	100 Series Lawn Tractor	John Deere	145	√	√	√	√	
Riding Lawn Equipment	100 Series Lawn Tractor	John Deere	102	√	√	√	√	
Riding Lawn Equipment	100 Series Lawn Tractor	John Deere	125	√	√	√	√	
Riding Lawn Equipment	100 Series Lawn Tractor	John Deere	135	√	√	√	√	
Riding Lawn Equipment	100 Series Lawn Tractor	John Deere	155C	√	√	√	√	
Riding Lawn Equipment	100 Series Yard Tractor	John Deere	190C	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JS20	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JS30	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JS40	√	√	√	√	
Riding Lawn Equipment	Select Series MultiTerrain L and G	John Deere	X500	√	√	√	√	
Riding Lawn Equipment	Select Series MultiTerrain L and G	John Deere	X520	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Riding Lawn Equipment	Select Series MultiTerrain L and G	John Deere	X534	√	√	√	√	
Riding Lawn Equipment	Select Series MultiTerrain L and G	John Deere	X540	√	√	√	√	
Tractor Attachments	Backhoe	John Deere	260	√	√	√	√	
Riding Lawn Equipment	EZtrak Residential Mower	John Deere	Z225	√	√	√	√	
Riding Lawn Equipment	EZtrak Residential Mower	John Deere	Z425	√	√	√	√	
Riding Lawn Equipment	EZtrak Residential Mower	John Deere	Z445	√	√	√	√	
Tractors	Compact Utility	John Deere	3203	√	√	√	√	
Riding Lawn Equipment	X100 Series Lawn Tractors EXPORT	John Deere	X110	√	√	√	√	
Riding Lawn Equipment	X100 Series Lawn Tractors EXPORT	John Deere	X120	√	√	√	√	
Riding Lawn Equipment	X100 Series Lawn Tractors EXPORT	John Deere	X140	√	√	√	√	
Golf and Turf Products	Walk Behind Greensmower	John Deere	180C	√	√	√	√	
Golf and Turf Products	Walk Behind Greensmower	John Deere	220C	√	√	√	√	
Golf and Turf Products	Walk Behind Greensmower	John Deere	260C	√	√	√	√	
Tractor Attachments	Tiller	John Deere	647	√	√	√	√	
Tractor Attachments	Tiller	John Deere	655	√	√	√	√	
Tractor Attachments	Tiller	John Deere	665	√	√	√	√	
Tractor Attachments	Tiller	John Deere	673	√	√	√	√	
Tractor Attachments	Tiller	John Deere	681	√	√	√	√	
Golf and Turf Products	Trim and Surrounds Mower	John Deere	2653B	√	√	√	√	
Utility Vehicles	ProGator Gas	John Deere	2020A	√	√	√	√	
Utility Vehicles	ProGator Diesel	John Deere	2030A	√	√	√	√	
Golf and Turf Products	Greens Mower	John Deere	2500B	√	√	√	√	
Utility Vehicles	Gator Military	John Deere	M-Gator A1	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Utility Vehicles	Gator X Series	John Deere	620I	√	√	√	√	
Utility Vehicles	Gator X Series	John Deere	850D	√	√	√	√	
Utility Vehicles	ProGator Attachment	John Deere	HD200 Sprayer	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	LA105	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	LA115	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	LA125	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	LA135	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	LA145	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	LA155	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	LA165	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	LA175	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JS25	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JS35	√	√	√	√	
Tractors	Specialty Tractor	John Deere	20A	√	√	√	√	
Utility Vehicles	Gator T Series	John Deere	TX_Turf	√	√	√	√	
Golf and Turf Products	Lightweight Fairway Mower	John Deere	7500	√	√	√	√	
Golf and Turf Products	Lightweight Fairway Mower	John Deere	7700	√	√	√	√	
Golf and Turf Products	Lightweight Fairway Mower	John Deere	8500	√	√	√	√	
Golf and Turf Products	Lightweight Fairway Mower	John Deere	8700	√	√	√	√	
Golf and Turf Products	Lightweight Fairway Mower	John Deere	8800	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	LA100	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	LA110	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	LA120	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	LA130	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	LA140	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	LA150	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JS45	√	√	√	√	
Commercial Equipment	Z-Trak Estate	John Deere	Z510A	√	√	√	√	
Commercial Equipment	Z-Trak Estate	John Deere	Z520A	√	√	√	√	
Commercial Equipment	Z-Trak Pro	John Deere	Z810A	√	√	√	√	
Commercial Equipment	Z-Trak Pro	John Deere	Z820A	√	√	√	√	
Commercial Equipment	Z-Trak Pro	John Deere	Z830A	√	√	√	√	
Commercial Equipment	Z-Trak Pro	John Deere	Z840A	√	√	√	√	
Commercial Equipment	Z-Trak Pro	John Deere	Z850A	√	√	√	√	
LG Attachments	Rotary Mower	John Deere	42C	√	√	√	√	
LG Attachments	Rotary Mower	John Deere	48C	√	√	√	√	
Tractor Attachments	Backhoe	John Deere	375	√	√	√	√	
Tractor Attachments	Backhoe	John Deere	385	√	√	√	√	
Mate. Hand Cut. and Shredders	Loaders	John Deere	305	√	√	√	√	
Riding Lawn Equipment	Select Series Ultimate L and G	John Deere	X740	√	√	√	√	
Riding Lawn Equipment	Select Series Ultimate L and G	John Deere	X744	√	√	√	√	
Riding Lawn Equipment	Select Series Ultimate L and G	John Deere	X748	√	√	√	√	
Riding Lawn Equipment	Select Series Ultimate L and G	John Deere	X749	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	7G18	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	G15	√	√	√	√	
Golf and Turf Products	Greensmower	John Deere	2500E Hybrid Gas	√	√	√	√	
Golf and Turf Products	Fairway Mower	John Deere	7500 E-Cut Hybrid	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Golf and Turf Products	Fairway Mower	John Deere	8500 E-Cut Hybrid	√	√	√	√	
Golf and Turf Products	Fairway Mower	John Deere	8000 E-Cut Hybrid	√	√	√	√	
Golf and Turf Products	Walk Behind Greensmower	John Deere	220 E-Cut Hybrid	√	√	√	√	
Golf and Turf Products	Greensmower	John Deere	2500E Diesel	√	√	√	√	
Golf and Turf Products	Greensmower	John Deere	2500E Hybrid Dsl	√	√	√	√	
Golf and Turf Products	Greensmower	John Deere	2500E Gas	√	√	√	√	
Utility Vehicles	Gator T Series	John Deere	TX4X2	√	√	√	√	
Golf and Turf Products	Trim and Surrounds Mower	John Deere	7200	√	√	√	√	
Golf and Turf Products	Trim and Surrounds Mower	John Deere	7400	√	√	√	√	
Tractor Attachments	Backhoe	John Deere	485	√	√	√	√	
LG Attachments	Rotary Mower	John Deere	54C	√	√	√	√	
LG Attachments	Rotary Mower	John Deere	64C	√	√	√	√	
Tractor Attachments	ATRM MID-MOUNT ROTARY MOWER	John Deere	54D	√	√	√	√	
Tractor Attachments	ATRM MID-MOUNT ROTARY MOWER	John Deere	62D	√	√	√	√	
Commercial Equipment	Z-Trak Pro	John Deere	Z910A	√	√	√	√	
Commercial Equipment	Z-Trak Pro	John Deere	Z920A	√	√	√	√	
Commercial Equipment	Z-Trak Pro	John Deere	Z925A	√	√	√	√	
Commercial Equipment	Z-Trak Pro	John Deere	Z930A	√	√	√	√	
Commercial Equipment	Z-Trak Pro	John Deere	Z950A	√	√	√	√	
Commercial Equipment	Z-Trak Pro	John Deere	Z960A	√	√	√	√	
Commercial Equipment	Z-Trak Pro	John Deere	Z970A	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
LG Attachments	Rotary Mower	John Deere	Power Flow	√	√	√	√	
LG Attachments	ROTARY BROOM	John Deere	60	√	√	√	√	
Collection System	Aerator Collection System	John Deere	TC125	√	√	√	√	
Commercial Mowing	Triplex Reel Mower	John Deere	500	√	√	√	√	
Commercial Mowing	Rotary Mower	John Deere	1505	√	√	√	√	
Commercial Mowing	Extended Rotary Mower	John Deere	1515	√	√	√	√	
Tractor Attachments	ATRM MID-MOUNT ROTARY MOWER	John Deere	60	√	√	√	√	
Tractor Attachments	ATRM MID-MOUNT ROTARY MOWER	John Deere	72	√	√	√	√	
Tractor Attachments	ATRM MID-MOUNT ROTARY MOWER	John Deere	60D	√	√	√	√	
Tractor Attachments	ATRM MID-MOUNT ROTARY MOWER	John Deere	72D	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	L108	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	L111	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	L118	√	√	√	√	
Tractor Attachments	Backhoe	John Deere	46	√	√	√	√	
Utility Vehicles	Gator T Series	John Deere	TE4X2	√	√	√	√	
Commercial Mowing	Triplex Reel Mower	John Deere	900	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	L107	√	√	√	√	
Riding Lawn Equipment	JD Lawn Tractors	John Deere	L105	√	√	√	√	
Riding Lawn Equipment	Select Series Lawn Tractor	John Deere	X300R	√	√	√	√	
John Deere by Sabo	Sabo Lawn Tractor	John Deere	LR135	√	√	√	√	
John Deere by Sabo	Sabo Lawn Tractor	John Deere	LR175	√	√	√	√	
Tractors	Specialty Tractor	John Deere	20C	√	√	√	√	
Tractors	Specialty Tractor	John Deere	25C	√	√	√	√	
Tractor Attachments	Snow Blower	John Deere	54	√	√	√	√	
Riding Lawn Equipment	Select Series Ultimate L and G	John Deere	X729	√	√	√	√	
Commercial Mowing	5-plex Reel Mower	John Deere	1903	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Commercial Mowing	Triplex Reel Mower	John Deere	1203	√	√	√	√	
Riding Lawn Equipment	Attachments	John Deere	2 Bag Bagger	√	√	√	√	
Commercial Mowing	Triplex Reel Mower	John Deere	8400	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	214	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	216	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	200	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	208	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	210	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	212	√	√	√	√	
Commercial Equipment	Z-Trak Pro	John Deere	Z860A	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JM26	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JM36	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JM46	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JS26	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JS36	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JS46	√	√	√	√	
Golf and Turf Products	Walk Behind Greensmower	John Deere	180SL	√	√	√	√	
Golf and Turf Products	Walk Behind Greensmower	John Deere	220SL	√	√	√	√	
Golf and Turf Products	Walk Behind Greensmower	John Deere	260SL	√	√	√	√	
Riding Lawn Equipment	X100 Series Lawn Tractors EXPORT	John Deere	X130R	√	√	√	√	
Riding Lawn Equipment	Select Series MultiTerrain L and G	John Deere	X530	√	√	√	√	
Commercial Mowing	ZTRAK Mowers and Equipment	John Deere	Z710A	√	√	√	√	
Commercial Mowing	ZTRAK Mowers and Equipment	John Deere	Z720A	√	√	√	√	
Commercial Mowing	JD Walk-Behind Mowers	John Deere	WE85	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Commercial Mowing	JD Walk-Behind Mowers	John Deere	WE80	√	√	√	√	
Riding Lawn Equipment	EZtrak Residential Mower	John Deere	Z245	√	√	√	√	
LG Attachments	Rotary Mower	John Deere	62C	√	√	√	√	
Roberine Products	Roberine Rotary Mowers	John Deere	1500	√	√	√	√	
Riding Lawn Equipment	Select Series Lawn Tractor	John Deere	X360	√	√	√	√	
Licensed Products	Blower	John Deere	B635	√	√	√	√	
Licensed Products	Blower	John Deere	B940	√	√	√	√	
Licensed Products	Lawn Vacuum	John Deere	V627SP	√	√	√	√	
Licensed Products	Brush Cutter	John Deere	BC1324E	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	904	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	1054	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	1204	√	√	√	√	
Tractors	2WD or MFWD - China	John Deere	1354	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	314	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblower	John Deere	522E	√	√	√	√	
John Deere by Sabo	Robotic Mower	John Deere	XT3	√	√	√	√	
John Deere by Sabo	Robotic Mower	John Deere	E5	√	√	√	√	
John Deere by Sabo	Robotic Mower	John Deere	XT7	√	√	√	√	
Sabo	Robotic Mower	John Deere	S300	√	√	√	√	
Sabo	Robotic Mower	John Deere	500F	√	√	√	√	
Sabo	Robotic Mower	John Deere	F700	√	√	√	√	
Riding Lawn Equipment	Walk-Behind Commercial Mower	John Deere	Z465	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	WG32A	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	WG36A	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	WG48A	√	√	√	√	
Tractors	Compact Utility	John Deere	1023E	√	√	√	√	
Tractors	Compact Utility	John Deere	1026R	√	√	√	√	
Utility Vehicles	Gator Military	John Deere	6X4M	√	√	√	√	
Utility Vehicles	Gator Turf	John Deere	4X2Turf	√	√	√	√	
Utility Vehicles	Gator Worksite	John Deere	6X4W	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Commercial Mowing	Front Mowers and Equipment	John Deere	F910	√	√	√	√	
Commercial Mowing	Front Mowers and Equipment	John Deere	F930	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	WH36A	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	WH48A	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	WH52A	√	√	√	√	
Walk-Behind Products	Walk-Behind Snowblower	John Deere	1028E	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	GX255	√	√	√	√	
Riding Lawn Equipment	JD Lawn and Garden Tractors	John Deere	G110	√	√	√	√	
Riding Lawn Equipment	EZtrak Residential Mower	John Deere	Z465	√	√	√	√	
Riding Lawn Equipment	EZtrak Residential Mower	John Deere	Z645	√	√	√	√	
Riding Lawn Equipment	EZtrak Residential Mower	John Deere	Z655	√	√	√	√	
Riding Lawn Equipment	X100 Series Lawn Tractors EXPORT	John Deere	X125	√	√	√	√	
Riding Lawn Equipment	X100 Series Lawn Tractors EXPORT	John Deere	X145	√	√	√	√	
Riding Lawn Equipment	X100 Series Lawn Tractors EXPORT	John Deere	X155R	√	√	√	√	
Riding Lawn Equipment	X100 Series Lawn Tractors EXPORT	John Deere	X165	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	D120	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	D100	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	D110	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	D130	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	D140	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	D150	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	D160	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	D170	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	T105C	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
JD Hand-Held Portable Products	Trimmers String	John Deere	T105CLE	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	T105S	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	T105SLE	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	T26SB	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	XT105SBLE	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	XT120LE	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	XT120SE	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	XT140LE	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	XT140SBLE	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	XT170LE	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	XT250BLE	√	√	√	√	
JD Hand-Held Portable Products	Trimmers String	John Deere	XT140SSELE	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
JD Hand-Held Portable Products	Blower	John Deere	BH25	√	√	√	√	
JD Hand-Held Portable Products	Blower	John Deere	BH25LE	√	√	√	√	
Tractor Attachments	Backhoe	John Deere	8B	√	√	√	√	
LG Attachments	Snow Blower	John Deere	54	√	√	√	√	
LG Attachments	2 bag bagger	John Deere	BAG7bushel	√	√	√	√	
LG Attachments	3 bag Bagger	John Deere	BAG14bushel	√	√	√	√	
Golf and Turf Products	Bunker and Field Rake	John Deere	1200H	√	√	√	√	
Golf and Turf Products	ProGator Attachment	John Deere	TD100 Topdresser	√	√	√	√	
Golf and Turf Products	Lightweight Fairway Mower	John Deere	3235B	√	√	√	√	
Golf and Turf Products	Greensmower	John Deere	2500A Diesel	√	√	√	√	
Golf and Turf Products	Greensmower	John Deere	2500A Gas	√	√	√	√	
Golf and Turf Products	Greensmower	John Deere	2500B Gas	√	√	√	√	
Golf and Turf Products	Greensmower	John Deere	2500B Diesel	√	√	√	√	
Golf and Turf Products	Lightweight Rotary Mower	John Deere	3245C	√	√	√	√	
Commercial Mowing Attachment	MCS MATERIAL COLLECTION SYSTEM	John Deere	600L	√	√	√	√	
LT Attachments	100 Series Snowblower	John Deere	44	√	√	√	√	
L100 Series Attachment	2 bag bagger	John Deere	BAG	√	√	√	√	
Golf and Turf Products	WBGM Trailer	John Deere	22B	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Commercial Equipment	Z-Trak Pro	John Deere	Z925A EFI	√	√	√	√	
Riding Lawn Equipment	X100 Series Lawn Tractors EXPORT	John Deere	107H	√	√	√	√	
Riding Lawn Equipment	X100 Series Lawn Tractors EXPORT	John Deere	107S	√	√	√	√	
Riding Lawn Equipment	X100 Series Lawn Tractors EXPORT	John Deere	6933	√	√	√	√	
Lesco Products	Trimmers String	John Deere	Trimmer	√	√	√	√	
Lesco Products	Blower	John Deere	Backpack Leak Blow	√	√	√	√	
Lesco Products	Blower	John Deere	WB Leaf Blower	√	√	√	√	
Lesco Products	Aerator	John Deere	30 Aerator	√	√	√	√	
Lesco Products	Snow Blower	John Deere	Snow Blower	√	√	√	√	
Lesco Products	Ride On Mower	John Deere	6028 Z-Two	√	√	√	√	
Lesco Products	Ride On Mower	John Deere	7227 Z-Two	√	√	√	√	
Lesco Products	Ride On Mower	John Deere	Greens Mower	√	√	√	√	
Lesco Products	Ride On Mower	John Deere	5423 Viper	√	√	√	√	
Lesco Products	Ride On Mower	John Deere	6023 Viper	√	√	√	√	
Lesco Products	Ride On Mower	John Deere	5225 ZTR	√	√	√	√	
Lesco Products	Walk Behind Mower	John Deere	52″ Hydro	√	√	√	√	
Lesco Products	Walk Behind Mower	John Deere	48″ Hydro Float	√	√	√	√	
Lesco Products	Walk Behind Mower	John Deere	54″ Hydro Float	√	√	√	√	
Lesco Products	Walk Behind Mower	John Deere	60″ Hydro Float	√	√	√	√	
Lesco Products	Walk Behind Mower	John Deere	WBM Attachments	√	√	√	√	
Lesco Products	Walk Behind Mower	John Deere	21″ Push Mower	√	√	√	√	
Lesco Products	Truck Loader	John Deere	18/22 Truck Loader	√	√	√	√	

CANDO Diagnostic List John Deere_v7.00

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Category	Subcategory	Make	Model	Function				Actuation Test & Special Function
				Read ECU Information	Read Fault Code	Erase Fault Code	Live Data	
Lesco Products	Ornamental Feeders	John Deere	Lesco Feeder	√	√	√	√	
Lesco Products	Ornamental Feeders	John Deere	Chapin Feeder	√	√	√	√	
Utility Vehicles	ProGator Gas	John Deere	2020A EFI	√	√	√	√	
Riding Lawn Equipment	Select Series Lawn Tractor	John Deere	X310	√	√	√	√	
Riding Lawn Equipment	Select Series Lawn Tractor	John Deere	X305R	√	√	√	√	
Riding Lawn Equipment	EZtrak Residential Mower	John Deere	Z665	√	√	√	√	
Licensed Products	Cart	John Deere	MC542	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JS28	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JS38	√	√	√	√	
Walk-Behind Products	JD Walk-Behind Mowers	John Deere	JS48	√	√	√	√	
John Deere by Sabo	Sabo Walk Behind Mowers	John Deere	SA915	√	√	√	√	
Golf and Turf Products	Walk Behind Greensmower	John Deere	180 E-Cut Hybrid	√	√	√	√	
Utility Vehicles	Gator X Series	John Deere	855D S4	√	√	√	√	
Utility Vehicles	Gator X Series	John Deere	825i S4	√	√	√	√	
Licensed Products	Cart	John Deere	8Y	√	√	√	√	
Riding Lawn Equipment	EZtrak Residential Mower	John Deere	Z235	√	√	√	√	
Riding Lawn Equipment	X100 Series Lawn Tractors EXPORT	John Deere	X135R	√	√	√	√	
Riding Lawn Equipment	LA Series Lawn Tractors	John Deere	D105	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	WHP 36	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	WHP 48	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	WHP 52	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	WHP36	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	WHP48	√	√	√	√	
Commercial Mowing	Walk-Behind Commercial Mower	John Deere	WHP52	√	√	√	√	

Remarks: √ means the system has this function - means not supported at this moment.