CANDO Diagnostic List Paccar_v5.0

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle menu		Function					
Models	Engine Type	ECU Info	Read Codes	Erase Codes	Read Data	Active Test	Special Function
ENGINE	PMCI	√	√	√	√	√	–
	PMCI2	√	√	√	√	√	–
	PCI	√	√	√	√	–	–
	ECS-DC5	√	√	√	√	√	–
Aftertreatment	EAS	√	√	√	√	√	–
Tachograph	MTCO	√	√	√	√	–	–